



INSTRUCTIONS

This manual contains important warnings and information.  
**READ AND KEEP FOR REFERENCE.**

*First choice when quality counts.™*

## 2 kW (2.7 HP), EXPLOSION PROOF **TRIUMPH® DC Motor**

### FOR USE WITH THE GRACO 9000 RECIPROCATOR

Includes adjustable torque motor with gear output, electronic controls, power and signal access junction boxes. Pre-engineered and ready to use.


**Part No. 239338, Series A**  
**100 to 240VAC, 15 Ampere,**  
**50/60 Hz, single-phase**

DESIGNED FOR HAZARDOUS LOCATIONS.  
ISSeP Group II B  
FM and CSA Class I, Div. 1, Groups C and D  
Temperature Class T5 (100°C)

**Part No. 239339, Series A**  
**240 to 480VAC, 15 Ampere,**  
**50/60 Hz, three-phase**

DESIGNED FOR HAZARDOUS LOCATIONS.  
ISSeP Group II B  
FM and CSA Class I, Div. 1, Groups C and D  
Temperature Class T4 (135°C)

US Patent No. 5,220,259.  
Other US and Foreign Patents Pending.



01868A



**APPROVED**



ISSeP  
EEx d II B T5 for Part No. 239338  
EEx d II B T4 for Part No. 239339



**GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441**

©COPYRIGHT 1994, GRACO INC.

Graco Inc. is registered to I.S. EN ISO 9001

# Table of Contents

Symbols .....	3	Troubleshooting (Model 239339) .....	23
Warnings .....	3	Service (Model 239339) .....	24
Introduction .....	5	Tools Required .....	24
Typical Installations .....	6	Replacing the Electronic Control Module .....	24
Installation (Model 239338) .....	8	Replacing the Signal Cover .....	26
Installation (Model 239339) .....	12	Replacing the Capacitors .....	27
Operation .....	15	Parts (Model 239338) .....	28
Starting and Adjusting the Motor .....	15	Parts (Model 239339) .....	29
Shutdown .....	15	Technical Data .....	30
Maintenance .....	15	Dimensions .....	31
Troubleshooting (Model 239338) .....	17	Warranty .....	32
Service (Model 239338) .....	18	Graco Phone Number .....	32
Tools Required .....	18		
Replacing the Electronic Control Module .....	18		
Replacing the Signal Cover .....	20		
Replacing the Capacitors .....	21		

# Symbols

## Warning Symbol



This symbol alerts you to the possibility of serious injury or death if you do not follow the instructions.

## Caution Symbol



This symbol alerts you to the possibility of damage to or destruction of equipment if you do not follow the instructions.

## WARNING



INSTRUCTIONS

### EQUIPMENT MISUSE HAZARD

Equipment misuse can cause the equipment to rupture or malfunction and result in serious injury.

- This equipment is for professional use only.
- Read all instruction manuals, tags, and labels before operating the equipment.
- Use the equipment only for its intended purpose. If you are uncertain about usage, call your Graco distributor.
- Do not alter or modify this equipment. Use only genuine Graco parts and accessories.
- Check equipment daily. Repair or replace worn or damaged parts immediately.
- Do not attempt to repair the electronic control module. To service the module, replace the entire assembly.
- Route hoses away from traffic areas, sharp edges, moving parts, and hot surfaces. Do not expose Graco hoses to temperatures above 82°C (180°F) or below -40°C (-40°F).
- Wear hearing protection when operating this equipment.
- Always wear protective eyewear, gloves, clothing and respirator as recommended by the fluid and solvent manufacturer.
- Comply with all applicable local, state, and national fire, electrical, and safety regulations.

# WARNING



## FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD

Improper grounding, poor ventilation, open flames or sparks can cause a hazardous condition and result in a fire, explosion, or electric shock.



When installed and operated in accordance with its instructions, the TRIUMPH DC Motor is approved for operation in Class I, Division 1, Group C and D (ISSeP Group II B) hazardous locations.



- Electrical equipment must be installed, operated, and serviced only by trained, qualified personnel who fully understand the requirements stated in this instruction manual.
- Ground the equipment and all other electrically conductive objects in the spray area. Refer to **Ground the System** on pages 11 and 14.
- Keep all covers tight while the motor is energized.
- *To reduce the risk of fire or explosion when the motor is located in a hazardous area, disconnect the electric power and wait 60 minutes for the capacitors to discharge before removing any covers. If the motor is located in a non-hazardous area, disconnect electric power and wait 15 minutes, to reduce the risk of electric shock.*



## HOT SURFACE HAZARD

- The electric motor becomes hot during operation, and the heat may be transferred to other connected equipment. To reduce the risk of burning yourself, do not touch the motor surfaces while it is operating. Before servicing, allow the motor to cool.
- Keep flammable material and debris away from the equipment.

# Introduction

## Introduction

Read this manual and all separate component manuals thoroughly before installing or operating the motor or any other system equipment.

Reference letters and numbers used in the text refer to the callouts in the illustrations and the parts lists on pages 28 and 29.

## Component Description

Major components of the Triumph Electric Motor are the electronic control module (1), signal cover (12), power access cover (13), capacitors (15), torque control (E), power indicator (L), power inlet (M), and motor housing (D). See Fig. 1.

## Typical Installation

Figs. 2 and 3 are only guides to help you select system components and accessories. Contact your Graco distributor for assistance in designing a system to meet your particular needs. Also refer to manual 308366.

## ⚠ WARNING



### FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD


*To reduce the risk of fire or explosion when the motor is located in a hazardous area, disconnect the electric power and wait 60 minutes for the capacitors to discharge before removing any covers. If the motor is located in a non-hazardous area, disconnect electric power and wait 15 minutes, to reduce the risk of electric shock.*

Be sure to install all covers correctly and torque all fasteners as specified. Incorrect assembly creates an explosion hazard when located in a hazardous area. Never operate the motor with loose, removed, or damaged covers.

### KEY

- 1 Electronic Control Module
- 12 Signal Cover
- 13 Power Access Cover
- 14 Capacitor Covers
- 15 Capacitors
- D Motor Housing
- E Torque Control
- L Power Indicator
- M Power Inlet

⚠ 1 Capacitors (15) are located inside the covers (14).



01868A

Fig. 1

# Typical Installation

## Installation Using a Power Cord, for Non-Hazardous Areas Only

**NOTE:** When installing in a flammable atmosphere (hazardous location), refer to Article 500 of the US National Electric Code or other applicable agency standard. Use only components that are approved for use in hazardous locations.

### KEY

- |   |   |   |  |
|---|---|---|--|
| A | Flexible Power Cord   | P | Start/Emergency Stop Pushbutton (must be approved for use in hazardous locations)                          |
| C | EMI Line Filter (locate in non-hazardous area).<br>Refer to pages 9 and 13 for specifications for different voltages.   | R | Standard Electrical Plug (for use in non-hazardous areas only)   |
| H | Wall Outlet   | S | Surge Tank   |
| J | Fused Safety Switch, with lock (locate in non-hazardous area)   | Y | Ground Wires for Pump and Surge Tank   |
| K | Strain Relief (must be approved for use in hazardous locations)   | Z | Inrush Current Limiter   |
| N | Motor Starter Switch (locate in non-hazardous area).<br>Refer to pages 9 and 13 for specifications for different voltages.<br>Required for use with Model 239339 Triumph Motor. |   | Refer to page 12 for suggested placement information.<br>Required for use with Model 239339 Triumph Motor. |




Fig. 2

01874A


# Typical Installation

## Hardwired Installation

**NOTE:** When installing in a flammable atmosphere (hazardous location), refer to Article 500 of the US National Electric Code or other applicable agency standard. Use only components that are approved for use in hazardous locations.

### KEY

- |   |   |   |  |
|---|---|---|--|
| A | Electrical Supply (must be sealed rigid conduit)  | P | Start/Emergency Stop Pushbutton (must be approved for use in hazardous locations)                          |
| C | EMI Line Filter (locate in non-hazardous area).<br>Refer to pages 9 and 13 for specifications for different voltages.   | S | Surge Tank   |
| J | Fused Safety Switch, with lock  | Y | Ground Wires for Pump and Surge Tank   |
| K | Strain Relief (must be approved for use in hazardous locations)   | Z | Inrush Current Limiter   |
| N | Motor Starter Switch (locate in non-hazardous area).<br>Refer to pages 9 and 13 for specifications for different voltages.<br>Required for use with Model 239339 Triumph Motor. |   | Refer to page 12 for suggested placement information.<br>Required for use with Model 239339 Triumph Motor. |



**Fig. 3**

01874A

# Installation (Model 239338)

## Startup Check List

Before installing and operating the motor, perform the following checks. Detailed instructions for each follow.

1. When installing in a flammable atmosphere (hazardous location) refer to Article 500 of the US National Electric Code or other applicable agency standards to plan the work. See the **WARNING** at right.
2. Mount the motor in the desired location. See **Motor Location** below.
3. Install the electrical service. See below.
4. Connect the electrical wiring. See page 11.
5. Ground the system. See page 11.

## Motor Location

Locate the motor so there is sufficient space around it for easy operating and service access, and for adequate ventilation to reduce buildup of heat in the motor.

Route all cables and electrical lines away from traffic areas.

## Electrical Service

Electrical power to the pump may be supplied by a power cord (A, see Fig. 2) or it may be hardwired (A, see Fig. 3).

## WARNING



### FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD

The electrical wiring shall be performed only by trained and qualified personnel to reduce the risk of serious injury and electric shock.



Observe all local codes and regulations regarding electrical wiring. Some localities require that certified hazardous location motor shops perform all maintenance and service.

When installing in a flammable atmosphere (hazardous location) refer to Article 500 of the US National Electric Code or other applicable agency standards to plan the work.

The minimum operating voltage is 100VAC; the maximum operating voltage is 240VAC. This motor requires a 50/60 Hz, single-phase, 15 Ampere grounded power supply.

Use 14 gauge grounded 3-wire cable per the installation category to bring power to the motor. The electric motor is grounded through the cable.

Conduit must be sealed off to prevent gases from escaping from the hazardous area into non-hazardous areas. Refer to Article 500 of the US National Electric Code or other applicable agency standards.

*Continued on page 9.*



# Installation (Model 239338)

Install the following components on the motor circuit:

- Install a fused safety switch (J) on the circuit to the motor, to lock out power to the motor when it is being serviced or when it is shut down. This switch must be lockable and must be in a non-hazardous area.
- To comply with EMC directive EN 50081–2 (1994) for line-conducted noise, install an EMI line filter (C) in the system. Part No. F1760AA20 is available from Curtis Industries, P.O. Box 343925, Milwaukee, WI, 43234–3925, USA; telephone 414–649–4200.

This filter is rated for 240VAC, 15 Ampere. See the following table for minimum insertion losses. If you use an equivalent filter, the limits on line-conducted emissions in EN5011 must be met and verified.

**Minimum Insertion Losses**

MHz					
0.15	0.50	1.00	5.00	10.0	30.0
15 dB	25 dB	31 dB	42 dB	47 dB	40 dB

## **WARNING**



### **FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD**

If using a power cord plugged into a wall socket, a motor starter switch must be installed to control power to the plug. Use only a 3–terminal ground plug. Do not alter the plug by removing the grounding terminal. Do not use with an adapter or extension cord.

- Install a motor starter switch (N) on the circuit to the motor. This switch must be in a non-hazardous area. Use a 2–pole magnetic AC contactor, size NEMA 1, 30 Ampere. The switch is not required for Model 239338 when the motor is hardwired.
- Install a start/emergency stop pushbutton (P) within reach of the motor. This pushbutton must be approved for use in a hazardous area.


[illegible]

# Installation (Model 239338)

## Connect the Electrical Wiring

1. Remove the power access cover (13) to expose the wiring terminals. Inspect the inner flame path surface of the cover and the mating outer surface of the motor housing (D). These surfaces must be smooth, with no nicks or scratches. Do not operate the motor if these surfaces are damaged.
2. Install a strain relief (K) in the 1/2 npt(f) power inlet. The strain relief must be approved for use in hazardous locations. Bring the power cable into the power compartment. See Fig. 4.

**⚠ WARNING**



**FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD**

If using a power cord plugged into a wall socket, a motor starter switch must be installed to control power to the plug. Use only a 3-terminal ground plug. Do not alter the plug by removing the grounding terminal. Do not use with an adapter or extension cord.


**NOTE:** Using a flexible power cord voids the Division 1 rating of the motor.

3. Connect the common and the neutral leadwires (B, W) of the cable to the top two terminals (T).
4. Connect the green ground wire (G) of the cable to the bottom ground terminal (U). **The ground wire must be connected to the bottom terminal, and must be longer than the line leads, to prevent pullout.**


### KEY

- B Common Leadwire (black)
- D Motor Housing
- F Explosion-Proof Flame Path Surface
- G Ground Wire (green)
- K Power Inlet and Strain Relief (must be approved for use in hazardous locations)
- T Power Terminals
- U Ground Terminal
- W Neutral Leadwire (white)

**⚠ 1** Mating flame path surfaces of the cover and housing must be smooth, with no nicks or scratches. Use a feeler gauge to check that the gap does not exceed 0.04 mm (.0015 in.).



**⚠ WARNING**



**FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD**

Be sure to install the power access cover (13) correctly and torque all fasteners as specified. Incorrect assembly or damage to the cover and housing flame path surfaces (F, Fig. 4) creates an explosion hazard when located in a hazardous area. Never operate the motor if the cover is loose, removed, or damaged.

5. Reattach the power access cover (13). Use a feeler gauge to check that the gap between the power access cover (13) and the motor housing (D) does not exceed 0.04 mm (.0015 in.). Torque screws (22) to 10–15 N•m (89–133 in-lb).

## Ground the System

The electric motor is grounded through the electrical wiring (see the instructions at left). Redundant grounding of any equipment connected to the motor is recommended to further reduce the risk of electric shock.

To reduce the risk of static sparking, ground all equipment used or located in the work area. Check your local electrical code for detailed grounding instructions for your area and type of equipment.

Equipment connected to the motor should be redundantly grounded. Use Graco Part No. 237569 Ground Wire and Clamp (Y, Figs. 2 and 3), connected to a true earth ground.

Fig. 4

# Installation (Model 239339)

## Startup Check List

Before installing and operating the motor, perform the following checks. Detailed instructions for each follow.

1. When installing in a flammable atmosphere (hazardous location) refer to Article 500 of the US National Electric Code or other applicable agency standards to plan the work. See the **WARNING** at right.
2. Mount the motor in the desired location. See **Motor Location** below.
3. Install the electrical service. See below.
4. Connect the electrical wiring. See page 14.
5. Ground the system. See page 14.

## Motor Location

Locate the motor so there is sufficient space around it for easy operating and service access, and for adequate ventilation to reduce buildup of heat in the motor.

Route all cables and electrical lines away from traffic areas.


## Electrical Service

Electrical power to the pump may be supplied by a power cord (A, see Fig. 2) or it may be hardwired (A, see Fig. 3).

When installing in a flammable atmosphere (hazardous location) refer to Article 500 of the US National Electric Code or other applicable agency standards to plan the work.

The minimum operating voltage is 240VAC; the maximum operating voltage is 480VAC. This motor requires a 50/60 Hz, 3-phase, 15 Ampere grounded power supply.

**NOTE:** It is necessary that an inrush current limiter be installed to prevent damage from high inrush current. Fig. 5 shows a suggested placement for the inrush current limiters. Order Ametherm Part No. SL32 10015 with 10 ohms resistance and a maximum current of 15 Amperes or equivalent.



**NOTE:** Place inrush limiters inline with the fuses and power leads.

**Fig. 5**

Use 14 gauge grounded 4-wire cable per the installation category to bring power to the motor. The electric motor is grounded through the cable.

Conduit must be sealed off to prevent gases from escaping from the hazardous area into non-hazardous areas. Refer to Article 500 of the US National Electric Code or other applicable agency standards.

*Continued on page 13.*

## WARNING



### FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD

The electrical wiring shall be performed only by trained and qualified personnel to reduce the risk of serious injury and electric shock.



Observe all local codes and regulations regarding electrical wiring. Some localities require that certified hazardous location motor shops perform all maintenance and service.

# Installation (Model 239339)

Install the following components on the motor circuit:

- Install a fused safety switch (J) on the circuit to the motor, to lock out power to the motor when it is being serviced or when it is shut down. This switch must be lockable and must be in a non-hazardous area.
- To comply with EMC directive EN 50081–2 (1994) for line-conducted noise, install an EMI line filter (C) in the system. Part No. 3V16F is available from Filter Concepts, Inc., 2624 S. Roussele St., Santa Ana, CA, 92707, USA; telephone 714–545–7003.

This filter is rated for 440VAC, 16 Ampere. See the following table for minimum insertion losses. If you use an equivalent filter, the limits on line-conducted emissions in EN5011 must be met and verified.

**Minimum Insertion Losses**

MHz					
0.05	0.15	0.50	1.50	5.00	20.0
40 dB	55 dB	60 dB	65 dB	50 dB	55 dB

## **WARNING**



### **FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD**

If using a power cord plugged into a wall socket, a motor starter switch must be installed to control power to the plug. Use only a 4–terminal ground plug. Do not alter the plug by removing the grounding terminal. Do not use with an adapter or extension cord.

- Install a motor starter switch (N) on the circuit to the motor. This switch must be in a non-hazardous area. It is required for all installations of Model 239339. Use a 3–pole magnetic AC contactor, size NEMA 1, 30 Ampere.
- Install a start/emergency stop pushbutton (P) within reach of the motor. This pushbutton must be approved for use in a hazardous area.

# Installation (Model 239339)

## Connect the Electrical Wiring

1. Remove the power access cover (13) to expose the wiring terminals. Inspect the inner flame path surface of the cover and the mating outer surface of the motor housing (D). These surfaces must be smooth, with no nicks or scratches. Do not operate the motor if these surfaces are damaged.
2. Install a strain relief (K) in the 1/2 npt(f) power inlet. The strain relief must be approved for use in hazardous locations. Bring the power cable into the power compartment. See Fig. 6.

### WARNING



#### FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD


If using a power cord plugged into a wall socket, a motor starter switch must be installed to control power to the plug. Use only a 4-terminal ground plug. Do not alter the plug by removing the grounding terminal. Do not use with an adapter or extension cord.


**NOTE:** Using a flexible power cord voids the Division 1 rating of the motor.

3. Connect the three power leadwires (B) of the cable to the three terminals (T).
4. Insert the green ground wire (G) of the cable into the slot in the terminal lug (U) and tighten the locknut securely. **The ground wire must be longer than the line leads, to prevent pullout.**

#### KEY

- B Common Leadwires (black)
- D Motor Housing
- F Explosion-Proof Flame Path Surface
- G Ground Wire (green)
- K Power Inlet and Strain Relief (must be approved for use in hazardous locations)
- T Power Terminals
- U Ground Terminal
- W Neutral Leadwire (white)



 Mating flame path surfaces of the cover and housing must be smooth, with no nicks or scratches. Use a feeler gauge to check that the gap does not exceed 0.04 mm (.0015 in.).

### WARNING



#### FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD

Be sure to install the power access cover (13) correctly and torque all fasteners as specified. Incorrect assembly or damage to the cover and housing flame path surfaces (F, Fig. 6) creates an explosion hazard when located in a hazardous area. Never operate the motor if the cover is loose, removed, or damaged.

5. Reattach the power access cover (13). Use a feeler gauge to check that the gap between the power access cover (13) and the motor housing (D) does not exceed 0.04 mm (.0015 in.). Torque screws (22) to 10–15 N•m (89–133 in-lb).

## Ground the System

The electric motor is grounded through the electrical wiring (see the instructions at left). Redundant grounding of any equipment connected to the motor is recommended to further reduce the risk of electric shock.

To reduce the risk of static sparking, ground all equipment used or located in the work area. Check your local electrical code for detailed grounding instructions for your area and type of equipment.

Equipment connected to the motor should be redundantly grounded. Use Graco Part No. 237569 Ground Wire and Clamp (Y, Figs. 2 and 3), connected to a true earth ground.

Fig. 6

# Operation

## Starting and Adjusting the Motor

1. Set the torque control (E) to zero (0). See Fig. 7.
2. Turn on the power source to the motor. The power indicator (L) will light.

**NOTE:** The motor requires about 1 second to start after applying power, to allow the circuit boards to power up.

3. Turn the torque control (E) slowly clockwise until the pump starts.

4. Use the torque control (E) to adjust the speed of the pump. Always use the lowest speed necessary to get the desired results. At speeds over 60 cycles per minute the motor will shut off automatically to prevent premature wear. To restart, shut off power to the motor, set the torque control to zero (0), turn on power to the motor, and turn the torque control slowly clockwise until the pump runs at less than 60 cycles per minute.

## Shutdown

1. Follow the shutdown procedure for the pump. Refer to the separate instructions provided with the pump.
2. Turn the torque control (E) to zero (0). See Fig. 7.
3. Shut off the electrical power source to the motor.

# Maintenance

Always set the torque control (E) to zero (0) and disconnect power when shutting down the motor.

Keep dirt and dust from accumulating on the motor. Clean the cooling fins (V) as required.

Covers must remain tight to ensure explosion proof rating. Torque all cover screws (22) to 10–15 N•m (89–133 in-lb).

### KEY

- E Torque Control
- L Power Indicator
- V Cooling Fins
- 22 Cover Screws

1 Torque to 10–15 N•m (89–133 in-lb).

2 Screws are out of view.




Fig. 7

[illegible]



# Troubleshooting (Model 239338)

## **WARNING**



### **FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD**



*To reduce the risk of fire or explosion when the motor is located in a hazardous area, disconnect the electric power and wait 60 minutes for the capacitors to discharge before removing any covers. If the motor is located in a non-hazardous area, disconnect electric power and wait 15 minutes, to reduce the risk of electric shock.*

Be sure to install all covers correctly and torque all fasteners as specified. Incorrect assembly or damage to the cover and housing flame path surfaces (F, Fig. 8) creates an explosion hazard when located in a hazardous area. Never operate the motor with loose, removed, or damaged covers.

PROBLEM	CAUSE	SOLUTION
Motor does not run (green power indicator will not light).	Power source is shut off.	Turn power source on.
	Defective electronic control module.	Contact your Graco distributor for proper service.
	Power wires hooked up incorrectly.	Refer to page 11 for proper installation.
Motor runs but green power indicator will not light.	Bad signal cover.	Replace signal cover. See page 20.
Motor is vibrating.	Bad capacitor.	Replace capacitors. See page 21.
Motor running slowly.	Motor has overheated and has automatically slowed down to reduce temperature.	Motor will return to normal speed when temperature drops to factory set level. You may shut off motor and allow it to cool, or reduce the ambient temperature in the operating area.
	Motor external surfaces are dirty.	Clean motor surfaces and cooling fins, for proper cooling.
Motor running slowly or erratically.	Motor sensors (optos) are bad.	Contact your Graco distributor for proper service.
Motor does not run, and green power indicator is on.	Motor has shut off because pump speed exceeded 60 cycles per minute.	<p>Correct system causes of excessive pump speed (exhausted fluid supply, broken supply line, worn seals, etc.).</p> <p>To restart, shut off power to the motor, set the torque control to zero (0), turn on power to the motor, and turn the torque control slowly clockwise until the pump runs at less than 60 cycles per minute.</p>

# Service (Model 239338)

## WARNING



### FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD

Only the electronic control module (1), signal cover (12), and capacitors (15) are user-replaceable parts. See below for replacement procedures for these parts.



Do not attempt to repair the electronic control module (1) or the signal cover (12). If service is required, replace these assemblies.

There are no user-serviceable parts in the motor housing (D). For housing replacement, contact your Graco distributor.

## Tools Required

- 6 mm Allen wrench
- Torque wrench
- Feeler gauge
- Graco Part No. 110293 Lithium Base Grease  
Use to repack bearings (34, 35, see the parts drawing on page 28) and gears. For complete rebuild, order two 0.38 pint (0.18 liter) containers.

## Replacing the Electronic Control Module

## WARNING



### FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD

*To reduce the risk of fire or explosion when the motor is located in a hazardous area, disconnect the electric power and wait 60 minutes for the capacitors to discharge before removing any covers. If the motor is located in a non-hazardous area, disconnect electric power and wait 15 minutes, to reduce the risk of electric shock.*



Be sure to install the electronic control module (1) correctly and torque all fasteners as specified. Incorrect assembly or damage to the module and housing flame path surfaces (F, Fig. 8) creates an explosion hazard when located in a hazardous area. Inspect the inner flame path surface of the module and the mating outer surface of the motor housing (D). These surfaces must be smooth, with no nicks or scratches. Never operate the motor if the module is loose, removed, or damaged.

1. Before removing any covers or performing any service, disconnect power and wait for the capacitors to discharge. See the **WARNING** at left.
2. Remove the screws (22) and washers (23) holding the control module (1) to the motor housing (D). Carefully move the module away from the housing. See Fig. 8.
3. Pull the two power leads (J1, K1) off the tabs (J2, K2) on the module.
4. Disconnect the 6-pin (M1) and 7-pin (P1) connectors from their mating connectors (M2, P2) on the module (1).
5. Disconnect the two halves of the large green connector (S1, S2).
6. Remove the electronic control module (1). There are no user-serviceable parts on the module.
7. Inspect the inner flame path surface of the new electronic control module (1) and the mating outer surface of the motor housing (D). These surfaces must be smooth, with no nicks or scratches. Do not operate the motor if these surfaces are damaged.
8. Install the new electronic control module (1) in the reverse order of disassembly. Push all the wires well up into the motor housing (D), to avoid pinching them when reattaching the module.
9. Use a feeler gauge to check that the gap between the electronic control module (1) and the motor housing (D) does not exceed 0.04 mm (.0015 in.). Torque screws (22) to 10–15 N•m (89–133 in-lb).

# Service (Model 239338)

## KEY

1 Electronic Control Module  
12 Signal Cover  
14 Capacitor Covers  
15 Capacitors  
22 Screws  
23 Washers  
31 Capacitor Insulators  
D Motor Housing  
F Flame Path Surfaces

J1, K1 Power Leads  
J2, K2 Power Tabs  
M1, M2 6-Pin Connectors  
P1, P2 7-Pin Connectors  
S1, S2 Green Connectors  
V1, V2 Signal Cover Connectors  
R2 Bleed Resistor  
X Capacitor + Wires  
Z Capacitor - Wires

1 Torque to 10–15 N•m (89–133 in-lb).

2 Torque to 2.7–3.4 N•m (24–30 in-lb).

3 Inner flame path surfaces of the covers must be smooth, with no nicks or scratches. Use a feeler gauge to check that the gap does not exceed 0.04 mm (.0015 in.).

4 Outer flame path surfaces of the motor housing must be smooth, with no nicks or scratches.




Fig. 8

01869A

# Service (Model 239338)

## Replacing the Signal Cover

### **WARNING**



#### **FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD**

*To reduce the risk of fire or explosion when the motor is located in a hazardous area, disconnect the electric power and wait 60 minutes for the capacitors to discharge before removing any covers. If the motor is located in a non-hazardous area, disconnect electric power and wait 15 minutes, to reduce the risk of electric shock.*







Be sure to install the signal cover (12) correctly and torque all fasteners as specified. Incorrect assembly or damage to the cover and housing flame path surfaces (F, Fig. 8) creates an explosion hazard when located in a hazardous area. Inspect the inner flame path surface of the cover and the mating outer surface of the motor housing (D). These surfaces must be smooth, with no nicks or scratches. Never operate the motor if the cover is loose, removed, or damaged.

1. Before removing any covers or performing any service, disconnect power and wait for the capacitors to discharge. See the **WARNING** at left.
2. Remove the screws (22) and washers (23) holding the signal cover (12) to the motor. Carefully move the cover away from the motor. See Fig. 8.
3. Disconnect the signal cover connector (V2) from its mating connector (V1) in the motor housing (D).
4. Remove the signal cover (12). There are no user-serviceable parts on the signal cover.
5. Inspect the inner flame path surface of the new signal cover (12) and the mating outer surface of the motor housing (D). These surfaces must be smooth, with no nicks or scratches. Do not operate the motor if these surfaces are damaged.
6. Install the new signal cover (12) in the reverse order of disassembly. Push all the wires well into the motor housing (D), to avoid pinching them when reattaching the cover. Make sure the capacitor covers (14) do not obstruct the signal cover.
7. Use a feeler gauge to check that the gap between the signal cover (12) and the motor housing (D) does not exceed 0.04 mm (.0015 in.). Torque screws (22) to 10–15 N•m (89–133 in-lb).

# Service (Model 239338)

## Replacing the Capacitors

**WARNING**



**FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD**  
*To reduce the risk of fire or explosion when the motor is located in a hazardous area, disconnect the electric power and wait 60 minutes for the capacitors to discharge before removing any covers. If the motor is located in a non-hazardous area, disconnect electric power and wait 15 minutes, to reduce the risk of electric shock.*

Be sure to reinstall the bleed resistor (R2) when you replace the capacitors. The resistor discharges the capacitors. Failure to reinstall the resistor will cause the capacitors to retain up to 600V.

Be sure to install all covers correctly and torque all fasteners as specified. Incorrect assembly or damage to the cover and housing flame path surfaces (F, Fig. 8) creates an explosion hazard when located in a hazardous area. Never operate the motor with loose, removed, or damaged covers.

1. Before removing any covers or performing any service, disconnect power and wait for the capacitors to discharge. See the **WARNING** above.
2. Remove the signal cover (12) as explained under **Replacing the Signal Cover**. Set the cover aside.

3. Unscrew the two capacitor covers (14) from the motor housing (D). See Fig. 8.
4. Carefully pull the capacitors (15; C1 and C2) away from the motor housing, enough to see the wire connections. The capacitors are wired together in parallel. Note that one capacitor (C2) has one + wire (X), one – wire (Z), and a bleed resistor (R2) connected to it; disconnect this capacitor first.
5. The free wires of capacitor C2 will allow you to pull capacitor C1 away from the motor housing far enough to access the wire connections. Be sure not to pull the free wires all the way out of the capacitor C2 cavity.

**NOTE:** If you pull the free wires out of the capacitor C2 cavity, you may have to remove the electronic control module (1) to retrieve them.

6. Disconnect capacitor C1.
7. Install the capacitors in the reverse order of removal. Be sure the wires feed through the slot in the plastic insulators (31). Be sure to connect the + wires (X) to the + terminals and the – wires (Z) to the – terminals. Be sure to reinstall the bleed resistor (R2) on capacitor C2, as shown in Fig. 8. Torque the terminal screws to 2.7–3.4 N•m (24–30 in-lb). See Fig. 9 for the capacitor wiring diagram.
8. Turn the capacitor covers (14) in completely to ensure that they do not prevent the signal cover (12) and housing flanges from mating.




Fig. 9

7348A

[illegible]

# Troubleshooting (Model 239339)

## WARNING



### **FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD**



*To reduce the risk of fire or explosion when the motor is located in a hazardous area, disconnect the electric power and wait 60 minutes for the capacitors to discharge before removing any covers. If the motor is located in a non-hazardous area, disconnect electric power and wait 15 minutes, to reduce the risk of electric shock.*

Be sure to install all covers correctly and torque all fasteners as specified. Incorrect assembly or damage to the cover and housing flame path surfaces (F, Fig. 10) creates an explosion hazard when located in a hazardous area. Never operate the motor with loose, removed, or damaged covers.

PROBLEM	CAUSE	SOLUTION
Motor does not run (green power indicator will not light).	Power source is shut off.	Turn power source on.
	Defective electronic control module.	Contact your Graco distributor for proper service.
	Power wires hooked up incorrectly.	Refer to page 14 for proper installation.
Motor runs but green power indicator will not light.	Bad signal cover.	Replace signal cover. See page 24.
Motor is vibrating.	Bad capacitor.	Replace capacitors. See page 27.
Motor running slowly.	Motor has overheated and has automatically slowed down to reduce temperature.	Motor will return to normal speed when temperature drops to factory set level. You may shut off motor and allow it to cool, or reduce the ambient temperature in the operating area.
	Motor external surfaces are dirty.	Clean motor surfaces and cooling fins, for proper cooling.
Motor running slowly or erratically.	Motor sensors (optos) are bad.	Contact your Graco distributor for proper service.
Motor does not run, and green power indicator is on.	Motor has shut off because pump speed exceeded 60 cycles per minute.	<p>Correct system causes of excessive pump speed (exhausted fluid supply, broken supply line, worn seals, etc.).</p> <p>To restart, shut off power to the motor, set the torque control to zero (0), turn on power to the motor, and turn the torque control slowly clockwise until the pump runs at less than 60 cycles per minute.</p>

# Service (Model 239339)

## **WARNING**



### **FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD**

Only the electronic control module (1), signal cover (12), and capacitors (15) are user-replaceable parts. See below for replacement procedures for these parts.



Do not attempt to repair the electronic control module (1) or the signal cover (12). If service is required, replace these assemblies.

There are no user-serviceable parts in the motor housing (D). For housing replacement, contact your Graco distributor.

## **Tools Required**

- 6 mm Allen wrench
- Torque wrench
- Feeler gauge
- Graco Part No. 110293 Lithium Base Grease  
Use to repack bearings (34, 35, see the parts drawing on page 29) and gears. For complete rebuild, order two 0.38 pint (0.18 liter) containers.

## **Replacing the Electronic Control Module**

## **WARNING**



### **FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD**

*To reduce the risk of fire or explosion when the motor is located in a hazardous area, disconnect the electric power and wait 60 minutes for the capacitors to discharge before removing any covers. If the motor is located in a non-hazardous area, disconnect electric power and wait 15 minutes, to reduce the risk of electric shock.*



Be sure to install the electronic control module (1) correctly and torque all fasteners as specified. Incorrect assembly or damage to the module and housing flame path surfaces (F, Fig. 10) creates an explosion hazard when located in a hazardous area. Inspect the inner flame path surface of the module and the mating outer surface of the motor housing (D). These surfaces must be smooth, with no nicks or scratches. Never operate the motor if the module is loose, removed, or damaged.

1. Before removing any covers or performing any service, disconnect power and wait for the capacitors to discharge. See the **WARNING** at left.
2. Remove the screws (22) and washers (23) holding the control module (1) to the motor housing (D). Carefully move the module away from the housing. See Fig. 10.
3. Disconnect plug (J2) from connector (J1). Disconnect connector (K2) from plug (K1).
4. Disconnect the 6-pin (M1) and 7-pin (P1) connectors from their mating connectors (M2, P2) on the module (1).
5. Disconnect the two halves of the large green connector (S1, S2).
6. Remove the electronic control module (1). There are no user-serviceable parts on the module.
7. Inspect the inner flame path surface of the new electronic control module (1) and the mating outer surface of the motor housing (D). These surfaces must be smooth, with no nicks or scratches. Do not operate the motor if these surfaces are damaged.
8. Install the new electronic control module (1) in the reverse order of disassembly. Push all the wires well up into the motor housing (D), to avoid pinching them when reattaching the module.
9. Use a feeler gauge to check that the gap between the electronic control module (1) and the motor housing (D) does not exceed 0.04 mm (.0015 in.). Torque screws (22) to 10–15 N•m (89–133 in-lb).



# Service (Model 239339)

## KEY

1 Electronic Control Module  
12 Signal Cover  
14 Capacitor Covers  
15 Capacitors  
22 Screws  
23 Washers  
31 Capacitor Insulators  
D Motor Housing  
F Flame Path Surfaces  
J1, K1 Power Leads

J2, K2 Power Tabs  
M1, M2 6-Pin Connectors  
P1, P2 7-Pin Connectors  
S1, S2 Green Connectors  
V1, V2 Signal Cover Connectors  
R2, R3 Bleed Resistors  
X Capacitor + Wire  
Y Capacitor +/- Wire  
Z Capacitor - Wire

1 Torque to 10–15 N•m (89–133 in-lb).

2 Torque to 2.7–3.4 N•m (24–30 in-lb).

3 Inner flame path surfaces of the covers must be smooth, with no nicks or scratches. Use a feeler gauge to check that the gap does not exceed 0.04 mm (.0015 in.).

4 Outer flame path surfaces of the motor housing must be smooth, with no nicks or scratches.




Fig. 10

7347A

# Service (Model 239339)

## Replacing the Signal Cover

### **WARNING**



#### **FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD**

*To reduce the risk of fire or explosion when the motor is located in a hazardous area, disconnect the electric power and wait 60 minutes for the capacitors to discharge before removing any covers. If the motor is located in a non-hazardous area, disconnect electric power and wait 15 minutes, to reduce the risk of electric shock.*



Be sure to install the signal cover (12) correctly and torque all fasteners as specified. Incorrect assembly or damage to the cover and housing flame path surfaces (F, Fig. 10) creates an explosion hazard when located in a hazardous area. Inspect the inner flame path surface of the cover and the mating outer surface of the motor housing (D). These surfaces must be smooth, with no nicks or scratches. Never operate the motor if the cover is loose, removed, or damaged.

1. Before removing any covers or performing any service, disconnect power and wait for the capacitors to discharge. See the **WARNING** at left.
2. Remove the screws (22) and washers (23) holding the signal cover (12) to the motor. Carefully move the cover away from the motor. See Fig. 10.
3. Disconnect the signal cover connector (V2) from its mating connector (V1) in the motor housing (D).
4. Remove the signal cover (12). There are no user-serviceable parts on the signal cover.
5. Inspect the inner flame path surface of the new signal cover (12) and the mating outer surface of the motor housing (D). These surfaces must be smooth, with no nicks or scratches. Do not operate the motor if these surfaces are damaged.
6. Install the new signal cover (12) in the reverse order of disassembly. Push all the wires well into the motor housing (D), to avoid pinching them when reattaching the cover. Make sure the capacitor covers (14) do not obstruct the signal cover.
7. Use a feeler gauge to check that the gap between the signal cover (12) and the motor housing (D) does not exceed 0.04 mm (.0015 in.). Torque screws (22) to 10–15 N•m (89–133 in-lb).

# Service (Model 239339)

## Replacing the Capacitors

### WARNING



#### FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD



To reduce the risk of fire or explosion when the motor is located in a hazardous area, disconnect the electric power and wait 60 minutes for the capacitors to discharge before removing any covers. If the motor is located in a non-hazardous area, disconnect electric power and wait 15 minutes, to reduce the risk of electric shock.

Be sure to reinstall the bleed resistors (R2 and R3) when you replace the capacitors. The resistors discharge the capacitors. Failure to reinstall the resistors will cause the capacitors to retain up to 600V.

Be sure to install all covers correctly and torque all fasteners as specified. Incorrect assembly or damage to the cover and housing flame path surface (F, Fig. 10) creates an explosion hazard when located in a hazardous area. Never operate the motor with loose, removed, or damaged covers.

1. Before removing any covers or performing any service, disconnect power and wait for the capacitors to discharge. See the **WARNING** above.
2. Remove the signal cover (12) as explained under **Replacing the Signal Cover**. Set the cover aside.

3. Unscrew the two capacitor covers (14) from the motor housing (D). See Fig. 10.
4. Carefully pull the capacitors (15; C1 and C2) away from the motor housing, enough to see the wire connections. The capacitors are wired together in series. Both capacitors have a bleed resistor (R2 and R3).
5. Disconnect one of the capacitors.
6. The free wires of the removed capacitor will allow you to pull the other capacitor away from the motor housing far enough to access the wire connections. Be sure not to pull the free wires all the way out of the capacitor cavity.

**NOTE:** If you pull the free wires out of the capacitor cavity, you may have to remove the electronic control module (1) to retrieve them.

7. Disconnect the other capacitor.
8. Install the capacitors in the reverse order of removal. Be sure the wires feed through the slot in the plastic insulators (31). Be sure to connect the + wire (X) to the + terminals and the – wire (Z) to the – terminals. Connect the +/- wire (Y) to the – terminal of C1 and the + terminal of C2. Be sure to reinstall the bleed resistors (R2 and R3) on the capacitors, as shown in Fig. 10. Torque the terminal screws to 2.7–3.4 N•m (24–30 in-lb). See Fig. 11 for the capacitor wiring diagram.
9. Turn the capacitor covers (14) in completely to ensure that they do not prevent the signal cover (12) and housing flanges from mating.




Fig. 11

# Parts (Model 239338)

## 239338 TRIUMPH® Electric Motor, Series A

1 Press fit.


2 Pack with lithium base grease.

3 Inner flame path surfaces of the covers must be smooth, with no nicks or scratches. Use a feeler gauge to check that the gap does not exceed 0.04 mm (.0015 in.).


4 Outer flame path surfaces of the motor housing must be smooth, with no nicks or scratches.

5 Lubricate gear teeth.

6 Part of item 15.



MOTOR HOUSING CONTAINS NO USER-SERVICEABLE PARTS, except for bearings (34 and 35, see left)



01867

Ref No.	Part No.	Description	Qty
1	239467	MODULE, electronic control	1
12	239418	COVER, signal	1
13	192251	COVER, power access	1
14	187012	COVER, capacitor	2
15	111398	CAPACITOR, main motor	2
22	109114	SCREW, socket hd; M8 x 1.25; 30 mm long	27
23	104008	WASHER, lock; 8 mm	27
28	112414	SCREW, ground; M5 x 8; 6 mm long	1

Ref No.	Part No.	Description	Qty
29	100718	WASHER, lock; no. 10	1
31	276482	INSULATOR, capacitor	2
34	107088	BEARING, needle	1
35	108692	BEARING, roller	1
41▲	188069	LABEL, caution	2
42▲	187305	LABEL, warning	1
59▲	189285	LABEL, caution	2

▲ Replacement Danger and Warning labels, tags and cards are available at no cost.

28 308254

# Parts (Model 239339)

## 239339 TRIUMPH® Electric Motor, Series A

△1 Press fit.


△2 Pack with lithium base grease.

△3 Inner flame path surfaces of the covers must be smooth, with no nicks or scratches. Use a feeler gauge to check that the gap does not exceed 0.04 mm (.0015 in.).


△4 Outer flame path surfaces of the motor housing must be smooth, with no nicks or scratches.

△5 Lubricate gear teeth.

△6 Part of item 15.



MOTOR HOUSING CONTAINS NO USER-SERVICEABLE PARTS, except for bearings (34 and 35, see left)



7346A

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
1	239397	MODULE, electronic control	1	31	276482	INSULATOR, capacitor	2
12	239418	COVER, signal	1	34	107088	BEARING, needle	1
13	192251	COVER, power access	1	35	108692	BEARING, roller	1
14	187012	COVER, capacitor	2	41▲	188069	LABEL, caution	2
15	111398	CAPACITOR, main motor	2	42▲	187305	LABEL, warning	1
22	109114	SCREW, socket hd; M8 x 1.25; 30 mm long	27	59▲	189285	LABEL, caution	2
23	104008	WASHER, lock; 8 mm	27	▲ Replacement Danger and Warning labels, tags and cards are available at no cost.			
28	104029	STUD, ground	1				

# Technical Data

Category	Data
Operating Voltage Range	<i>Model 239338:</i> 100 to 240 VAC <i>Model 239339:</i> 240 to 480 VAC
Cycles	<i>Model 239338:</i> 50/60 Hz, single-phase <i>Model 239339:</i> 50/60 Hz, three-phase
Maximum Current Draw	15 Amperes rms
Power Output at 2500 rpm, 25°C ambient	2.7 H.P. (2 kW) out
Power Output at 2500 rpm, 40°C ambient	1.7 H.P. (1.3 kW) out
Torque	8.5 N•m (75 in-lb) continuous
Ambient Temperature Range	–40 to 40°C (–40 to 104°F)
Maximum Operating Temperature	85°C (185°F) (motor automatically slows down to cool down, then returns to speed)
Output Shaft	16 tooth gear mates to 239398 Gear Reducer


# Dimensions

<b>A</b>	393 mm (15.47 in.) Overall Height
<b>B</b>	280 mm (11.02 in.) Width at Top Fins
<b>C</b>	266 mm (10.45 in.) Front Cover to Back Plate
<b>D</b>	252 mm (9.92 in.) Width of Bottom Cover
<b>E</b>	184 mm (7.24 in.) Length of Bottom Cover
<b>F</b>	298 mm (11.74 in.) Width at Bottom Fins

## Port Sizes

<b>G</b>	3/818 npt(f) Signal Access Port
<b>H</b>	1/2-14 npt(f) Power Supply Inlet

**Weight** 36.3 kg (80 lb)



01868A

# Graco Standard Warranty

Graco warrants all equipment manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale by an authorized Graco distributor to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

**THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.**

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

Graco makes no warranty, and disclaims all implied warranties of merchantability and fitness for a particular purpose in connection with accessories, equipment, materials or components sold but not manufactured by Graco. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

## **FOR GRACO CANADA CUSTOMERS**

The parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

# Graco Phone Numbers

**TO PLACE AN ORDER**, contact your Graco distributor, or call one of the following numbers to identify the distributor closest to you:

**1-800-367-4023 Toll Free**

**612-623-6921**

**612-378-3505 Fax**

*All written and visual data contained in this document reflects the latest product information available at the time of publication.  
Graco reserves the right to make changes at any time without notice.*

**Sales Offices:** Minneapolis, Detroit  
**International Offices:** Belgium, Korea, Hong Kong, Japan

**GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441**

**[www.graco.com](http://www.graco.com)**

PRINTED IN U.S.A. 308254 February 1994, Revised July 2001