

Uni-Drum™ Supply System

309169

Bulk Supply System for 300 Gallon (1200 Liter) Magnadrum *rev.R*

See the List of Models on page 2 for Maximum Outlet Pressure and Maximum Fluid Flow.

The Uni-Drum supply system evacuates 300 gallon (1200 liter) magnadrum and other tote drums of the same size and capacity. The Uni-Drum pumps and transfers flowable and highly viscous materials such as sealant, adhesives, and sound deadeners from bulk drums with maximum efficiency.



The Uni-Drum is built to work with other high pressure equipment to optimize material use.



Important Safety Instructions

Read all warnings and instructions in this manual.
Save these instructions.

See page 2 for **List of Models** and
page 3 for **Table of Contents**.



T10418

List of Models

The Uni-Drum supply units listed below are covered in this manual. For specific pump information, refer to the chart in **Servicing the Pumps** on page 35.

Supply Unit Part No.	Pump	Ratio	Max. Outlet Pressure	Max. Fluid Flow	Pump Manual	Used in Systems
C59784 (Left Hand)	King, carbon steel	20:1	1800 psi (12.0 MPa, 124 bar)	12.0 gpm (46 lpm) @ 50 cpm	308151	970152, 970157
C59785 (Right Hand)						
C58607 (Left Hand)	King, carbon steel	56:1	5000 psi (34.0 MPa, 345 bar)	3.4 gpm (18.26 lpm) @ 60 cpm	308353	970153, 970158
C58608 (Right Hand)						
249311 (Left Hand)	King, carbon steel (less manifold, fluid head and fittings)	56:1	5000 psi (34.0 MPa, 345 bar)	3.4 gpm (18.26 lpm) @ 60 cpm	308353	249313
249312 (Right Hand)						
C58338 (Left Hand)	Premier, carbon steel	67:1	5000 psi (34.0 MPa, 345 bar)	4.8 gpm (12.8 lpm) @ 60 cpm	308812	970065, 970154
C58601 (Right Hand)						
C58461 (Left Hand)	Premier, carbon steel	34:1	3400 psi (24 MPa, 235 bar)	9.2 gpm (34.8 lpm) @ 60 cpm	308151	970123, 970151
C58462 (Right Hand)						
C59807 (Left Hand)	Premier carbon steel (with carbide balls)	34:1	3400 psi (24 MPa, 235 bar)	9.2 gpm (34.8 lpm) @ 60 cpm	308151	970156, 970188
C59808 (Right Hand)						
C59778 (Left Hand)	Premier carbon steel	45:1	4500 psi (31.0 MPa, 310 bar)	6.9 gpm (26.2 lpm) @ 60 cpm	308148	970150, 970155
C59779 (Right Hand)						
C59793 (Left Hand)	Premier stainless steel	45:1	4500 psi (31.0 MPa, 310 bar)	6.9 gpm (26.2 lpm) @ 60 cpm	308148	970140, 970141
C59794 (Right Hand)						
246983 (Left Hand)	Premier stainless steel (with silicon nitride balls)	45:1	4500 psi (31.0 MPa, 310 bar)	6.9 gpm (26.2 lpm) @ 60 cpm	308148	246985, 246986
246984 (Right Hand)						
249154 (Left Hand)	Premier stainless steel (with silicon nitride balls)	34:1	3400 psi (23.1 MPa, 231 bar)	9.2 gpm (34.8 lpm) @ 60 cpm	308152	N/A
2494155 (Right Hand)						

Table of Contents

List of Models	2	Routine Maintenance	30
Warnings	4	Flushing the System	30
Uncrating the System	7	Cleaning the System	30
Overview	7	Wiper Lubrication	30
Installation Overview	7	Pneumatic Layout Panel Service	31
Operation Overview	7	Filter/Element Replacement	31
General Description	8	Ram Assembly Service	32
System Components	8	Piston Rod Seal Service	32
Pneumatic Layout Panel	9	Ram Piston Service	33
Installation	10	Low/Empty Limit Switch Replacement	34
Preparing the Site	10	Servicing the Pumps	35
Selecting a Location for the Uni-Drum	10	Replacing Wipers	36
Preparing to Install the System	10	Pump Removal	37
Installing the Uni-Drum	11	System Parts	38
Grounding the System	12	Uni-Drum Supply Units	40
Checking the Resistance Between the		233041 Follower Plate	51
Pumps and the True Earth Ground	12	Recommended Spare Parts	59
Connecting Air Supply Lines to the Uni-Drum ..	13	Spare Parts List	59
Connecting Output Hose to the Pumps	14	Pneumatic Diagram	60
Operation	15	Pneumatic Layout Panel	60
Prepare the Operator	15	Technical Data	61
Overview	15	Graco Standard Warranty	66
Pneumatic Layout Panel Switches		Graco Information	66
and Indicators	16		
Flushing the System Before Initial Use	18		
Initial System Startup Procedure	19		
Emergency Stop	23		
Pressure Relief Procedure	24		
Preventive Maintenance Schedule	24		
Changing Empty Drums	25		
Ram Assembly Troubleshooting	27		
Pump Troubleshooting	28		
Air Motor Troubleshooting	29		

Symbols

Warning Symbol



This symbol alerts you to the possibility of serious injury or death if you do not follow the instructions.

Caution Symbol



This symbol alerts you to the possibility of damage to or destruction of equipment if you do not follow the instructions.

WARNING




INSTRUCTIONS

EQUIPMENT MISUSE HAZARD

Equipment misuse can cause the equipment to rupture or malfunction and result in serious injury.

- This equipment is for professional use only.
- Read all instruction manuals, tags, and labels before operating the equipment.
- Use the equipment only for its intended purpose. If you are uncertain about usage, call your Graco distributor.
- Do not alter or modify this equipment. Use only genuine Graco parts and accessories.
- Check equipment daily. Repair or replace worn or damaged parts immediately.
- Do not exceed the maximum working pressure stated on the equipment or in the **Technical Data** for your equipment. Do not exceed the maximum working pressure of the lowest rated component in your system.
- Use fluids and solvents which are compatible with the equipment wetted parts. Refer to the **Technical Data** section of all equipment manuals. Read the fluid and solvent manufacturer's warnings.
- Do not kink or overbend hoses or use hoses to pull equipment.
- Route hoses away from traffic areas, sharp edges, moving parts, and hot surfaces. Do not expose Graco hoses to temperatures above 180°F (82°C) or below -40°F (-40°C).
- Wear hearing protection when operating this equipment.
- Do not lift pressurized equipment.
- Do not lift the equipment by the air motor lift ring if the total weight of the equipment exceeds 550 lb (250 kg).
- Comply with all applicable local, state, and national fire, electrical, and safety regulations.

WARNING



SKIN INJECTION HAZARD

Spray from the gun, hose leaks, or ruptured components can inject fluid into your body and cause extremely serious injury, including the need for amputation. Fluid splashed in the eyes or on the skin can also cause serious injury.



- Fluid injected into the skin might look like just a cut, but it is a serious injury. **Get immediate surgical treatment.**
- Do not point the gun at anyone or at any part of the body.
- Do not put your hand or fingers over the spray tip.
- Do not stop or deflect leaks with your hand, body, glove or rag.
- Do not “blow back” fluid; this is not an air spray system.
- Always have the tip guard and the trigger guard on the gun when spraying.
- Check the gun diffuser operation weekly. Refer to the gun manual.
- Be sure the gun trigger safety operates before spraying.
- Lock the gun trigger safety when you stop spraying.
- Follow the **Pressure Relief Procedure** on page 24 whenever you: are instructed to relieve pressure; stop spraying; clean, check, or service the equipment; and install or clean the spray tip.
- Tighten all fluid connections before operating the equipment.
- Check the hoses, tubes, and couplings daily. Replace worn, damaged, or loose parts immediately. Permanently coupled hoses cannot be repaired; replace the entire hose.
- Use only Graco approved hoses. Do not remove any spring guard that is used to help protect the hose from rupture caused by kinks or bends near the couplings.



MOVING PARTS HAZARD

Moving parts, such as the pump rod, follower plate and ram assembly, can pinch or amputate your fingers.

- Keep clear of all moving parts when starting or operating the pump.
- Keep your hands away from the follower plate and the lip of the drum while the ram is operating.
- Keep your hands away from the ram frame while the ram is operating.
- Before servicing the equipment, follow the **Pressure Relief Procedure** on page 24 to prevent the equipment from starting unexpectedly.

WARNING



FIRE AND EXPLOSION HAZARD

Improper grounding, poor ventilation, open flames or sparks can cause a hazardous condition and result in a fire or explosion and serious injury.

- Ground the equipment and the container where the material is deposited. Refer to **Grounding the System** on page 12.
- If there is any static sparking or you feel an electric shock while using this equipment, **stop the pumps immediately**. Do not use the equipment until you identify and correct the problem.
- Provide fresh air ventilation to avoid the buildup of flammable fumes from solvents or the fluid being sprayed.
- Keep the spray area free of debris, including solvent, rags, and gasoline.
- Electrically disconnect all equipment in the spray area.
- Extinguish all open flames or pilot lights in the spray area.
- Do not smoke in the spray area.
- Do not turn on or off any light switch in the spray area while operating or if fumes are present.
- Do not operate a gasoline engine in the spray area.
- Keep a fire extinguisher in the work area.



TOXIC FLUID HAZARD

Hazardous fluid or toxic fumes can cause serious injury or death if splashed in the eyes or on the skin, inhaled, or swallowed.

- Know the specific hazards of the fluid you are using.
- Store hazardous fluid in an approved container. Dispose of hazardous fluid according to all local, state and national guidelines.
- Always wear protective eyewear, gloves, clothing and respirator as recommended by the fluid and solvent manufacturer.

Unpacking the System

The Uni-Drum supply system was carefully packaged for shipment by Graco. When the system arrives, perform the following procedure to uncrate the system.

WARNING

EQUIPMENT MOVING HAZARD

Removing the unit off the pallet without following the uncrating procedure will damage the equipment.

To unpack the system, do the following:

1. Inspect carefully for shipping damage. Contact the carrier promptly if damage is discovered.
2. Carefully unwrap and remove the plastic packaging material.
3. Inspect the contents carefully. There should not be any loose or damaged parts.
4. Compare the packing slip against all items included in the crate. Report any shortages or other inspection problems immediately.
5. Remove the band straps that hold the Uni-Drum to the pallet.

NOTE: The Uni-Drum is ready for installation. Before installing the system, read the “General Description” section to become familiar with the system components.

Overview

Installation Overview

The location of the Uni-Drum should allow for easy loading and unloading of the 300 gallon (1200 liter) magnadrum or other tote drums with a forklift.

The Uni-Drum supply system must be leveled and mounted on a horizontal floor. An unlevelled condition can keep the Uni-Drum from operating properly.

Anchor the frame's four foot pads securely to the floor. The anchor bolts should be sized with sufficient safety factor to withstand the downward force of the follower plate and other objects that can push the frame off the floor.

Operation Overview

The Uni-Drum is a supply system that evacuates fluids from a 300 gallon (1200 liter) magnadrum or other tote drums.

Each Uni-Drum includes two Graco air motors and displacement pumps, a ram assembly with a follower plate and a pneumatic layout panel that controls the air components.

In short, the operator places the magnadrum inside the frame with the follower plate placed directly on top of the material. Locally, the system can be operated using pneumatic layout panel.

Two displacement pumps evacuate material out of each magnadrum. After removing the empty drum from the system, the operator repeats the evacuation process when another drum is ready for evacuation.

General Description

System Components

A general description of the Uni-Drum supply system helps the installers and operators become familiar with the system components. Contact your Graco distributor for help in choosing accessories to suit your particular needs.

Before you install the system you should be familiar with the parts described in the following paragraphs.

Fig. 1 shows the typical Uni-Drum supply system equipped with Premier™ air motors. The following list identifies the Uni-Drum system components:

- **Uni-Drum System (A)** is usually setup to alternate the material supply operation between the left hand (LH) and right hand (RH) supply units, which is accomplished using a combination of pneumatic logic and manual operators. Drum changeovers occur after the follower plate has reached its preset low limit level in the drum. Alternating between supply units eliminates the downtime that is usually expended unloading an empty drum and reloading a full drum.

- LH pump supply unit (A) accommodates one 300 gallon (1200 liter) drum. The LH supply unit has a local pneumatic layout panel.
- RH pump supply unit (B) accommodates one 300 gallon (1200 liter) drum. The RH supply unit has a local pneumatic layout panel.

Ref.	Description
A	Left hand (LH) supply unit
B	Right hand (RH) supply unit
C	Pumps and air motor. See page 2 for a list of models.
D	Ram assembly and follower plate
E	Main air inlet valve

Ref.	Description
F	3/8 npt air filter
G	Pneumatic layout panel
H	Bleed stick
K	Vent cylinders
M	Pump inlet valves
N	Drum clamps




Fig. 1

T10418

General Description

System Components (*continued*)

NOTE: The paragraphs that follow describe the components for the LH pump supply unit only. The descriptions are the same for the RH pump supply unit.

- The pumps evacuate material from the drum. See page 2 for a complete list of pumps and technical data.
- The **follower plate** (D) is connected to the ram assembly and is designed to apply an even amount of pressure to the material in the drum. With the follower plate in its raised position, the operator moves a drum inside the frame. The follower plate is lowered directly on top of the material in the drum. When pressure is applied to the follower plate, the material is pumped out of the drum through hoses, which are attached to the pump outlet ports. When the drum is empty, the operator raises the follower plate, removes the empty drum. The process is repeated when another drum is ready to be unloaded.
- **3/8" npt air filter** (F) filters air to the pneumatic layout panel. The 5 micron filter removes particles, such as dust, moisture, foreign matter and other contaminants from the compressed air.
- **Bleed sticks** (H) are removed to allow air trapped between the top of the material and ram plate to be evacuated. Typically, they are removed and the ram plate is lowered until the material is evident in the port. They are replaced before pumping begins.
- **Vent cylinders** (K) open to allow air back under the follower plate while it is being removed from an empty drum. Care should be taken to keep these vents clean. If vents become clogged a vacuum can be created behind the follower plate and result in the explosive removal of the plate from the empty drum.
- Main Air Inlet Valve (at E) is used to open or shutoff the air supply to the entire supply unit.
- Pump No. 1 Air Regulator controls pump speed and outlet pressure for pump no. 1 by adjusting the air pressure to the pump.
- Pump No. 1 Pressure Gauge displays the amount of air pressure supplied to pump no. 1.
- Pump No. 1 Start
- Pump No. 2 Start
- Pump No. 2 Air Regulator controls pump speed and outlet pressure for pump no. 2 by adjusting the air pressure to the pump.
- Pump No. 2 Pressure Gauge displays the amount of air pressure supplied to pump no. 2.
- Follower Vent Open switch is activated to open the vent to relieve container pressure. The follower switch has two settings.
 - In the AUTO setting, when the Ram Position switch is placed in the RAISE position, the vent valves open after a short delay. This allows air back under the follower plate, preventing the creation of a vacuum under the plate. The delay ensures that the downward force on the follower plate can be overcome and prevents material from flowing past the vents.
 - In the OPEN position the vents open after a short delay and remain open to facilitate cleaning. The selector should be returned to the AUTO setting immediately after cleaning is complete. If the valve is left OPEN the vents may open when the Ram Position switch is placed in the UP position and material may flow past the vents onto the top of the follower plate.
- Ram Up pushbutton turns on air pressure to raise the follower plate.
- The Ram Position Switch performs the following three functions:
 - Place the switch in the RAISE position to enable the Ram Up Position Switch.
 - Place the switch in the HOLD position to hold the follower plate in the current position.
 - Place the switch in the LOWER position to lower the follower plate.

Pneumatic Layout Panel (G)

The pneumatic layout panel includes the following system components. For more information, refer to the **Pneumatic Diagram** on page 47.

Installation

The installation procedures in this section are intended to serve as a guide for installing the Uni-Drum system. If you need more information, contact your Graco distributor.

NOTE: When raising and lowering the follower plate, be sure that the unit is unobstructed overhead to avoid interference with other objects.

The installation procedure includes:

- Preparing the site
- Selecting a location for the Uni-Drum
- Preparing to install the Uni-Drum
- Installing the Uni-Drum
- Connecting power to the control panel
- Grounding the system
- Checking resistance between the control panel and the true earth ground
- Connecting air supply lines to Uni-Drum

Preparing the Site

Ensure that you have an adequate compressed air supply. Approximately 450 cfm at 80 psi is required to operate the pumps at the maximum rate.

Keep the site clear of any obstacles or debris that could interfere with the installer's and operator's movement.

Selecting a Location for the Uni-Drum

Refer to **Technical Data** on page 61 for ram mounting and clearance dimensions.

When selecting a location for the Uni-Drum, keep the following in mind:

1. There should be sufficient space for installing, servicing, and using the equipment.
 - Select an accessible location for the system. There must be sufficient space around the system for maintenance.
 - Select a convenient location for the equipment. Check that there is sufficient overhead clearance for the pump and ram when the ram is in the fully raised position. Make sure the air regulators for the pumps and follower plate are fully accessible.
 - Make sure the air source for the panel and shutoff valves are fully accessible.
 - Make sure there is easy and safe access to an appropriate pneumatic source. Graco recommends a minimum of 3 feet (0.91 m) of open space in front of the control panel.
2. Make sure that you will be able to level the base of the ram using metal shims.

Preparing to Install the System

Before installing the system:

- See component manuals for specific data on component requirements. Data presented here pertains to the system only.
- Have all system and subassembly documentation available during installation.
- Be sure that all non-Graco supplied hoses are adequately sized and pressure-rated to meet the system requirements.

Installation

Installing the Uni-Drum

To install the Uni-Drum, follow the procedure below. Refer to **Technical Data** on page 61 for ram mounting and clearance dimensions.

1. Using equipment such as a forklift or handtruck, move the Uni-Drum into place on the floor. Remove the shipping pallet.
2. Level the Uni-Drum, using metal shims.
3. Using the holes in the base as a guide, drill holes for 13 mm (1/2") anchors.
4. Bolt the Uni-Drum to the floor using anchors that are long enough to prevent the unit from tipping. Refer to page 61 for more information.

WARNING



EQUIPMENT MISUSE HAZARD

The Uni-Drum system is shipped with every major component already attached and weighs approx. 3950 lb (1792 kg).

The Uni-Drum system should never be moved or lifted by one person. To prevent equipment damage or personal injury, engage an adequate number of personnel and use a forklift, hand truck, and support devices, such as a hoist when moving and installing the Uni-Drum system.

CAUTION

Be sure to use as many people as needed when the frame is being lifted or moved. Exercise care to avoid jarring, dropping, or tilting the frame while it is being moved to its installed location to prevent injury or property damage.

Installation

Grounding the System


WARNING



FIRE AND EXPLOSION HAZARD

Before operating the pump, ground the system as explained below. Also read the section **FIRE AND EXPLOSION HAZARD** on page 6.

1. *Pump:* use a ground wire and clamp. See Fig. 2. Loosen the grounding lug locknut (W) and washer (X). Insert one end of a 12 ga (1.5 mm²) minimum ground wire (Y) into the slot in lug (Z) and tighten the locknut securely. Connect the other end of the wire to a true earth ground. For a ground wire and clamp, order Part No. 237569.



0720

Fig. 2

2. *Air and fluid hoses:* Use only electrically conductive hoses.
3. *Air compressor:* follow manufacturer's recommendations.
4. *Spray gun or dispensing valve:* ground through connection to a properly grounded fluid hose and pump.

5. *Object being sprayed:* follow your local code.
6. *Fluid supply drum:* follow your local code.
7. *Solvent pails used when flushing:* follow your local code. Use only metal pails, which are conductive, placed on a grounded surface. Do not place the pail on a nonconductive surface, such as paper or cardboard, which interrupts the grounding continuity.
8. *To maintain grounding continuity when flushing or relieving pressure,* hold a metal part of the spray gun firmly to the side of a grounded *metal* pail, then trigger the gun.

Checking the Resistance Between the Pumps and the True Earth Ground

Have a qualified electrician check the resistance between the each pump and the true earth ground. The resistance must be less than 29 megohms. If the total resistance to ground exceeds 29 megohms, a different ground site may be required. Do not operate the system until the problem is corrected.

NOTE: Use a meter that is capable of measuring resistance at this level.

WARNING



FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD

To reduce the risk of fire, explosion, or electric shock the resistance between the supply unit components and true earth ground must be less than 0.25 ohms.



Installation

Connecting the Air Supply Lines to the Uni-Drum

Perform the following procedure to connect the input air supply lines to the Uni-Drum system.

Connecting Air Supply Lines to the Supply Units

To connect the main air supply line to the LH and RH supply units, do the following:

⚠ WARNING

To reduce the risk of overpressurizing your system, which could result in component rupture and cause serious injury, never exceed the specified maximum incoming air pressure to the pumps (see the **Technical Data** on page 61).

NOTE: Have a qualified technician connect both supply units to an air supply source that has the following required ratings:

Description	Requirements
Inlet Port Size:	1" npt(f)
Air Volume:	450 cfm
Input Air:	80 psi (5.5 bar, 0.55 MPa)

1. Check the air supply to ensure that it is properly sized and pressure-rated for this system.
2. Connect the air supply line to the 1" npt main air inlet.




Fig. 3

Installation

Connecting Output Hose to the Pumps

This procedure describes how to connect the fluid output hoses to the two pumps. It is the customer's responsibility to have the fluid supply hose already installed and ready for connection to the pumps.

CAUTION

There must be a minimum of 10 feet (3 m) of fluid supply hose on the outlet to prevent damage to the unit.

NOTE: The fluid supply hose must move freely without kinking when the pumps move up and down.

Check the fluid supply hose to ensure it is properly sized and pressure-rated for this system to avoid excessive weight/crossloading on the carriage. Use only electrically conductive hoses. The fluid supply hose should have spring guards on both ends. Connect the fluid supply hose to the fluid manifold outlet.




Fig. 4

TI0139

Operation

The operation procedures include:

- Prepare the operator
- Overview
- Pneumatic layout panel switches and indicators
- Initial system startup procedure
- Daily system startup
- System shutdown
- Operation modes for the pumps
- Pressure relief procedure
- Air motor icing
- Preventive maintenance schedule
- System operation procedures

Prepare the Operator

All persons who operate the equipment must be trained in the safe, efficient operation of all system components as well as the proper handling of all fluids. All operators must thoroughly read all instruction manuals, tags, and labels before operating the equipment.

Overview

The Uni-Drum supply system uses two air driven reciprocating pumps on the LH supply unit and two air driven reciprocating pumps on the RH supply unit. Each supply unit pumps material from a 300 gallon (1200 liter) drum.

General Functional Description

The LH and RH supply units can operate at the same time or as independent units. Generally, the Uni-Drum system is setup to operate as redundant units. This means that the RH unit is held in reserve on standby until the drum underneath the LH unit has been emptied, and vice versa.

Operating a redundant system allows the operator to maintain a continuous supply of material without interruption. The operator is afforded sufficient time to replace an empty drum at one supply unit while the drum at the other supply unit is being emptied.

System Startup

There are a series of steps that must be followed in sequential order to startup the system.

System Operation

Depending upon the system setup, at any time during operation, the operator can:

- Stop the pumps and relieve ram pressure at the LH supply unit.
- Stop the pumps and relieve ram pressure at the RH supply unit.
- Shutdown the system.

To load the drum into the supply unit, the follower plate must be raised and the bleed stick removed at the supply unit. The follower plate is lowered by the operator directly into the drum, the bleed sticks are replaced. The follower plate is pressurized, the pumps are turned on and material is pumped from the drum through the outlet ports on the pumps via a supply hose to one or more targeted applications.

Supply Unit Operation

The Uni-Drum supply system can be setup to alternate between the LH and RH supply units. This dual supply system setup virtually eliminates material replenishment downtime.

The Uni-Drum supply system allows the operator to load the material drum into the RH supply unit while the LH supply unit drum is being emptied. When the supply unit changeover occurs, the operator unloads the empty drum at the LH supply unit while the RH supply unit drum is being emptied. The cycle is repeated as many times as needed.

System Shutdown

For system shutdown, the operator turns off the pumps and depressurizes the system. Depending upon the type of material, the operator may choose to raise the follower plate from the drum or keep the follower plate lowered in the drum to prevent the material from being contaminated. Some materials will harden or congeal when exposed to air or used past their shelf life. Material should be kept covered when it is not being used and uncovered when it is ready to use.

Operation

Pneumatic Layout Panel Switches and Indicators

Use the table and Fig. 5 when operating the switches and reading the indicators on the pneumatic layout panel.

Ref	Button/Switch/Gauge		What it Does
A	PUMP NO. 1 PRESSURE Air Gauge		Indicates the air inlet pressure setting for pump no. 1.
B	PUMP NO. 2 PRESSURE Air Gauge		Indicates the air inlet pressure setting for pump no. 2.
C	Pump Air On		Starts pumps
D	Pump Air Off		Shut off pumps
E	PUMP NO. 1 REGULATOR Control Knob		Controls pump speed and outlet pressure by adjusting the air pressure to pump no. 1.
F	FOLLOWER VENT OPEN Directional Valve		Opens and closes the vents that relieve air pressure in the follower plate assembly.
G	PUMP NO. 2 REGULATOR Control Knob		Controls pump speed and outlet pressure by adjusting the air pressure to pump no. 2.
H	RAM UP Pushbutton		Raises the follower plate.
J	RAM POSITION Switch	RAISE	Enables Ram Up push button.
		HOLD	Holds the follower plate in the current position.
		LOWER	Lowers the follower plate.
K	Air Inlet Valve		Opens air supply line to the unit.
M	DRUM EMPTY Indicator		Indicates low fluid level in drum. Signals change to other ram in tandem systems.
N	DRUM IN POSITION Indicator		Indicates presence of Magnadrum under follower plate.

Operation




Fig. 5

243559 Panel Shown

9192A

Operation

Flushing the System Before Initial Use

Flushing the system before its initial use can prevent material contamination, which may cause the material to fail or perform poorly.

CAUTION

Flush the system before performing the initial material loading procedure. The system was factory-tested using a light soluble oil, a soybean oil, or some other oil as tagged. Flush the system to avoid contaminating the material that has been designated for initial material loading.

To flush the system, perform the following procedure:

1. Select the material for the initial material load.
2. Verify whether the factory-test oil and the initial material load are compatible:
 - a. If the two substances are compatible, omit the remaining steps in this procedure and perform the **Initial System Startup Procedure** on page 19.
 - b. If the two substances are incompatible, perform the remaining steps in this procedure to flush the system.

WARNING

Use fluids and solvents that are chemically compatible with the equipment wetted parts. See the **Technical Data** sections of all the equipment manuals. Always read the material manufacturer's literature before using fluid or solvent in this pump.

3. Select a drum containing a compatible material that can dissolve, clean, and eliminate the factory-test oil from the system. If necessary, check with the material supplier for a recommended flush material.
4. Before flushing, be sure the entire system and flushing drums are properly grounded. Refer to **Ground the System**, on page 12.
5. Perform steps 7 through 12 of the **Initial System Startup Procedure** on page 19 to load the drum containing the solvent.
6. Run the flush material through the system for approximately 1 to 2 minutes.
7. Remove the drum containing the flush material.

Operation

Initial System Startup Procedure

WARNING



PRESSURIZED FLUID HAZARD

To reduce the risk of serious bodily injury, such as fluid injection or splashing fluid in the eyes or on the skin, **always** wear eye protection and protective clothing when installing, operating, or servicing this dispensing system.



MOVING PARTS HAZARD

Moving equipment parts can cause personal injury, including severing of hands or fingers. Make sure all personnel are clear of moving parts before operating the equipment.

CAUTION

The use of a non-compatible lubricant can cause material contamination or inadequate performance. Use only a lubricant compatible with the material to be pumped. Check with the material supplier for a recommended lubricant.

To help avoid damage to equipment, *do not* use a drum of material that has been dented or otherwise damaged; damage to the follower plate wiper may result.

WARNING



PRESSURIZED EQUIPMENT HAZARD

To reduce risk of injury or equipment damage:

- Make sure all material hose connections are secure.
- Do not pressurize the system until you have verified the system is ready and it is safe to do so.

Settings for Initial System Startup

The initial system startup procedure contains the checklist of settings, adjustments, and procedural steps that must be completed before the system is ready for daily operation.

NOTE: Complete the startup procedure for the LH supply unit first. Then, repeat the startup procedure for the RH supply unit.

Perform the initial system startup procedure as follows:

1. Check all material hoses and fittings to ensure tightness and to prevent any material leakage.
2. Check all system air lines. Make sure that all routing of air lines will not interfere with any moving components within the system.
3. Fill the packing nut/wet cup on both pumps 1/3 full with Graco throat seal liquid (p/n 206995). Refer to your specific pump manual for details.
4. At the pneumatic layout panel, open the main air inlet valve at the LH supply unit, making air pressure available to the unit. See Fig. 3.
5. Adjust both pump main air regulators to 0 psi.
6. Set the RAM POSITION switch to RAISE.
7. Press the RAM UP button to raise the follower plate above the height of the material drum to be used.
8. Set the RAM POSITION switch to HOLD.
9. Roll a drum into the supply unit under the elevated follower plate.

NOTE: Whenever a drum change is required, remove the cover from the drum of new material by holding it level and lifting it straight up. Tipping the cover may allow accumulated dirt to spill into the drum, which may result in damage to the material and equipment.

Operation

Initial System Startup Procedure (*continued*)

10. **IMPORTANT:** Lubricate the follower plate wiper with a lubricant that is compatible with the material to be pumped. Check with your material supplier for compatibility.

NOTE: Before lowering the follower plate assembly into the drum, make sure that nothing is between the follower plate and the drum, or between the ram tie bar and the top of the ram posts.

11. Remove bleed sticks at the base of each pump.

12. Lower the follower plate as follows:

- Set the Ram Position selector to LOWER.
- Lower the follower plate until the material is evident in the bleedstick ports.
- Set the Ram Position selector to HOLD.
- Replace the bleedsticks.
- Set the Ram Position selector to LOWER.

13. Close both pump #1 and pump #2 inlet valves (located on top of air motor).

14. Prime the pumps as follows:

- Set both pump #1 and pump #2 regulators to 30 psi.
- Push the pump Air On button to open the air supply to the pumps. Note: Pumps should not start if inlet valves were closed in step 13.
- Place a waste container under pump #1 bleed valve.
- Open pump #1 bleeder valve.
- Open pump #1 inlet valve to start pump
- dispense material until all the air is purged from the system.
- Shut off pump #1 inlet air valve and close bleed valve.
- Repeat steps c–g for pump #2.

15. Push pump air off button on control panel.

16. Open both pump inlet valves.

Adjusting the Pump Regulators

NOTE: Both pumps must operate at the same cycles per minute rate to prevent the occurrence of uneven drum evacuation.

NOTE: For the maximum air input pressure for each pump see the appropriate manual as indicated on the chart on page 2).

20 309169

17. Run the system under normal conditions. Adjust the PUMP NO. 1 REGULATOR to the desired setting as follows:

- Turn the knob clockwise to increase air pressure or counterclockwise to decrease air pressure (see Fig. 7).
- Check the air gauge to verify the air pressure setting.

18. Repeat step 17 to adjust the air regulator for the PUMP NO. 2 REGULATOR.

Adjusting the Ram-Up and Ram-Down Regulators

19. At the pneumatic layout panel (see page 21), open the hinged cover.

20. Set the RAM POSITION switch to RAISE and push the RAM UP pushbutton. Verify that the follower plate (5) elevates at the desired speed. If not, do the following:

- Adjust the RAM-UP REGULATOR. Turn the knob clockwise to increase the amount of air pressure. Check the air gauge to verify that air pressure was increased. (See Fig. 7).
- Verify that regulator R3 is set to 5 to 10 psi (.035 to .07 MPa, 0.35 to 0.7 bar).

CAUTION

Improper setting of the Regulator R3 while the selector is in the HOLD position, can cause the plate to drop and operator injury.

- Repeat step 20.a until the ram raises at the desired speed.

21. Set the RAM POSITION switch to DOWN while observing the air gauge inside the panel.

22. Adjust the RAM-DOWN REGULATOR to 50 psi (0.34 MPa, 3.4 bar) as follows (see Fig. 7):

- Turn the knob clockwise to increase air pressure or counterclockwise to decrease air pressure.
- Check the air gauge to verify the air pressure setting.

23. Close and secure the hinged cover.

Operation




Fig. 7

Operation

Initial System Startup Procedure (*continued*)

Preventing Pump Cavitation

NOTE: Cavitation occurs when the pump cylinder did not fully load with material on the upstroke, and a cavity forms in the material after the pump changes to the downstroke. Perform step 24 when there is pump cavitation. If cavitation is not occurring, omit step 24 and proceed to step 25.

24. To prevent cavitation from occurring, perform the following steps:

- a. Lower the air motor air pressure until cavitation stops.
- b. Increase the ram down pressure.

Adjusting the Low Limit Switch

NOTE: When the low limit switch is activated, the pumps are normally turned off automatically by the pneumatic control, and a second set of pumps begin pumping.

25. Adjust the low limit switch as follows:

- a. At the control panel (see page 47), set the RAM POSITION switch to LOWER, allowing the follower plate to activate the lower limit switch.
- b. Verify that the follower plate lowers to the limit set point: a level between 1 to 4 inches (25.4 to 101.6 mm) from the bottom of the drum.
- c. Adjust the actuator to activate the switch at the level defined in step 25.b.




Fig. 6

Operation

Emergency Stop

When an emergency stop is required, do the following:

Stopping the System

1. To stop the system, close the main air inlet supply (see Fig. 8) to the supply unit.

Restarting the System

2. To restart the system, do the following:
 - a. Open the main air valve to the supply unit (see Fig. 8).




Fig. 8

Operation

Pressure Relief Procedure

This procedure describes how to relieve pressure from the system. Use this procedure whenever you shutoff the pumps and before checking or adjusting any part of the system, to reduce the risk of serious injury.

WARNING




MOVING PARTS HAZARD

Follow the **Pressure Relief Procedure** below before checking or repairing the follower plate or any other part of the system and when shutting down the system. Keep hands and fingers away from the follower plate, pump inlets, and the drum when raising or lowering the follower plate to reduce the risk of pinching or amputating hands or fingers.

During operation, also keep hands and fingers away from limit switches to reduce the risk of pinching or amputating hands or fingers.

WARNING



INJECTION HAZARD

The system pressure must be manually relieved to prevent the system from starting or spraying accidentally. Material under high pressure can be injected through the skin and cause serious injury. To reduce the risk of an injury from injection, splashing fluid, moving parts, follow the **Pressure Relief Procedure** whenever you:


- are instructed to relieve the pressure
- stop dispensing material
- check or service any of the system equipment
- install or clean the follower plate wipers.

To relieve pressure on the follower plate and in the pumps, perform the following procedure:

At the pneumatic layout panel, do the following:

1. Close the main air inlet valve (see Fig. 8).
2. Open any downstream fluid valves.

Note: Depressurization kit not included for models 246983 and 246984.



TI0195

Fig. 9

Preventive Maintenance Schedule

The operating conditions of your particular system determine how often maintenance is required. Establish a preventive maintenance schedule by recording when and what kind of maintenance is needed, and then determine a regular schedule for checking your system.

Operation

Changing Empty Drums

NOTE: After the automatic pump crossover has taken place, immediately replace the empty drum with a new, full drum. If both Uni-Drums become empty at the same time:

- Material will stop being delivered to the dispenser
- Air may enter the supply hose or pipe header
- Pump runaway could occur, resulting in damage to the pumps.

Drum Changing Procedure

To remove an empty drum and load a new, full drum:

1. Verify that the two front and rear drum clamps are engaged on the Uni-Drum ram base.
2. Check that the pump air is turned off.
3. Check that the RAM UP air regulator is set to 60 psi (maximum).
4. Close the two ball valves at the outlet manifold at the rear of the Uni-Drums.
5. To raise the follower plate:
 - a. Set the RAM POSITION control to RAISE.
 - b. Push and hold the RAM UP button as the follower plate slowly rises.

Note: If the Ram Up button is not pushed within 5 seconds, the vent valves may open before the pressure in the follower plate is relieved causing the material to bleed past the vents.

6. With the ram raised and the RAM POSITION control set to RAISE, pull the drum clamps back and remove the empty drum, using a suitable lifting device.

WARNING



MOVING PARTS HAZARD

Use a long-handled flat-bladed ice scraper if it is necessary to scrape the bottom of the follower plate. Do not put your hands between the plate and the drum.

7. **IMPORTANT:** Being careful not to damage the follower plate wipers, wipe or scrape any material buildup from the follower plate and wipers, and properly dispose of the waste material.

NOTE: When you open a new drum, take care to remove the cover by holding it level. Tipping the cover may allow accumulated dirt to spill into the material, which can damage the equipment. Also check that the drum is not damaged or dented.

8. Remove the cover from the new drum and remove any other packing from the drum, exposing the material. Make sure there are no foreign objects on the surface of the material.
9. Position the new drum, using a suitable lifting device, under the raised follower plate. Check that the DRUM IN PLACE indicator is lighted.
10. **IMPORTANT:** Lubricate the follower plate wipers with a lubricant approved by the material manufacturer.
11. Push the two front and rear drum clamps forward until engaged.

Operation

WARNING



PRESSURIZED FLUID HAZARD

To reduce the risk of serious bodily injury, such as fluid injection or splashing fluid in the eyes or on the skin, **always** wear eye protection and protective clothing when installing, operating, or servicing this dispensing system.



MOVING PARTS HAZARD

Moving equipment parts can cause personal injury, including severing of hands or fingers. Make sure all personnel are clear of moving parts before operating the equipment.

CAUTION

The use of a non-compatible lubricant can cause material contamination or inadequate performance. Use only a lubricant compatible with the material to be pumped. Check with the material supplier for a recommended lubricant.

To help avoid damage to equipment, *do not* use a drum of material that has been dented or otherwise damaged; damage to the follower plate wiper may result.

WARNING



PRESSURIZED EQUIPMENT HAZARD

To reduce risk of injury or equipment damage:

- Make sure all material hose connections are secure.
- Do not pressurize the system until you have verified the system is ready and it is safe to do so.

NOTE: Complete the entire procedure described below for the LH supply unit first. Then, repeat the procedure for the RH supply unit.

NOTE: Before lowering the follower plate assembly into the drum, make sure that nothing is between the follower plate and the drum, or between the ram tie bar and the top of the ram posts.

12. Remove bleed sticks at the base of each pump.

13. Lower the follower plate as follows:

- a. Set the Ram Position selector to LOWER.
- b. Lower the follower plate until the material is evident in the bleedstick ports.
- c. Set the Ram Position selector to HOLD.
- d. Replace the bleedsticks.
- e. Set the Ram Position selector to LOWER.

14. Close both pump #1 and pump #2 inlet valves (located on top of the air motor).

15. Prime the pumps as follows:

- a. Set both pump #1 and pump #2 regulators to 30 psi.
- b. Push the pump Air On button to open the air supply to the pumps. Note: Pumps should not start if inlet valves were closed in step 13.
- c. Place a waste container under pump #1 bleed valve.
- d. Open pump #1 bleeder valve.
- e. Open pump #1 inlet valve to start pump
- f. dispense material until all the air is purged from the system.
- g. Shut off pump #1 inlet air valve and close bleed valve.
- h. Repeat steps c–g for pump #2.

16. Push pump air off button on control panel.

17. Open both pump inlet valves.

NOTE:


- If the pump does not prime properly, which may occur with heavier, high viscosity fluids, increase the Ram Down air pressure.
- If fluid is forced out around the top wiper, ram pressure is too high; decrease the air pressure to the ram.
- Ram pressure adjustments may be carried out using the dual regulator **inside** the pneumatic panel, where the upper regulator knob controls the downward pressure of the ram, and the lower regulator knob controls the upward pressure of the ram.

Ram Assembly Troubleshooting

Problem	Cause(s)	Solution(s)
Ram won't raise or lower	Closed main air valve or clogged air line	Open air valve, clear air line
	Not enough air pressure	Increase ram pressure
	Worn or damaged piston	Replace piston. See procedure on page 33.
Ram raises or lowers too fast	Ram air pressure too high	Decrease ram air pressure
Ram drops when in "Raise" or "Hold" position	Regulator R3 pressure set too high	Reset R3 pressure to between 5–7 psi.
Fluid squeezes past follower plate wipers	Ram air pressure too high	Decrease ram air pressure
	Worn or damaged wipers	Replace wipers. See procedure on page 36.
Pump won't prime properly, or pumps air	Not enough ram air pressure	Increase ram down pressure
	Worn or damaged ram piston	Replace ram piston. See procedure on page 33.
	Bent drum has stopped follower plate	Replace drum

Pump Troubleshooting

For additional information about the displacement pump, refer to the applicable instruction manual.

Problem	Cause(s)	Solution(s)
Rapid downstroke or upstroke (pump cavitation)	Air is trapped in pump.	Bleed air from the pumps and prime using the procedure described in steps 15a–15h on page 26.
	Downstroke: Lower check in pump is worn. Upstroke: Upper check in pump is worn.	Rebuild and replace pump, as necessary.
Material leaks around pump outlet	Outlet fitting is loose.	Tighten outlet fitting.
Material leaks around bleed port	Bleed port fitting is loose.	Tighten bleed port fitting.
Pump won't move up or down	Problem with air motor.	See Air Motor Troubleshooting chart on page 29.
	Foreign object lodged in pump.	Remove object and rebuild pump assembly.
<div>  WARNING </div> <p>To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the Pressure Relief Procedure (page 24).</p> <p>Before attempting to dislodge a foreign object:</p> <ol style="list-style-type: none"> 1. Relieve system pressure. 2. Remove the pump from the air motor. 		
Wet-cup leaks	Worn throat packings.	Tighten wet-cup. Replace throat packings.

Air Motor Troubleshooting

For additional information about the air motor, refer to the applicable instruction manual.

Problem	Cause(s)	Solution(s)
Air motor will not shift directions, stalled in DOWN position	Main air valve spool is dirty or damaged	Clean/rebuild main air valve.
Air motor will not shift directions, stalled in UP position		
Air motor stalled halfway between the top and bottom		
Air continually exhausting around air motor shaft.	Air motor shaft seal is damaged	Replace air motor shaft seal.
Air continually exhausting around the air valve/slide valve	Air valve/slide valve gasket is damaged	Replace the valve gasket.
Air continually exhausting from muffler while the motor is idle	Internal seal damage	Rebuild air motor.
Oil leaking from exhaust port	Too much lubricant mixed in with the air supply	Reduce lubricant supply.
Frost build-up on muffler	Air motor operating at high pressure, or high cycle rate	Reduce pressure, cycle rate, or duty cycle of the air motor.

Routine Maintenance

Flushing the System

Flush the pump:

- Before the first use
- When changing material or fluid part number or brand
- Before fluid can dry or settle out in a dormant pump (check the shelf life or pot life of catalyzed fluids)
- Before storing the pump.

Flush with a fluid that is compatible with the fluid you are pumping and with the wetted parts in your system. Check with your fluid manufacturer or supplier for recommended flushing fluids and flushing frequency.

WARNING



FIRE AND EXPLOSION HAZARD

Before flushing, read the section **FIRE AND EXPLOSION HAZARD** on page 6. Be sure the entire system and flushing pails are properly grounded. Refer to **Grounding** on page 12.

To flush the system, perform the following procedure:

1. Place a drum of compatible flush material under the follower plate.
2. Run the pumps and circulate the flush material through the system for approximately 1 to 2 minutes or until the solution is clean.
3. Remove the drum containing the flush material from under the follower plate.
4. Return the system to current readiness condition.

Cleaning the System

CAUTION

Cleaning the system after using it can prevent material contamination, which may cause the material to fail or perform poorly. Do not load new material into a contaminated system.

Clean the system to avoid untimely equipment malfunctions and to ensure that system components operate efficiently.

To clean the system, perform the following procedure:

WARNING



MOVING PARTS HAZARD

Use a long-handled flat-bladed ice scraper if it is necessary to scrape the bottom of the follower plate. Do not put your hands between the plate and the drum.

1. **IMPORTANT:** Being careful not to damage the follower plate wipers, wipe or scrape any material buildup from the follower plate and wipers, and properly dispose of the waste material.
2. Apply a generous amount of lubricant to the follower plate wipers.
3. Return the system to current readiness condition.

Wiper Lubrication

It is extremely important that the follower plate wipers be thoroughly lubricated between drum changes. The follower plate may stick without lubrication.

Pneumatic Layout Panel Service

The pneumatic layout panel service procedures include:

- Filter/element replacement

Filter/Element Replacement

The air filter is located between the air supply source and the pneumatic layout panel. See Fig. 11.

To replace an air filter/element, do the following:

1. At the pneumatic layout panel, do the following:
 - a. Press the PUMP AIR OFF to shutoff the air supply at both pumps.
 - b. Close the main air inlet valve.
 - c. Turn the shutoff valve under the panel to the off position.




Fig. 10

TI0198

WARNING

To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** on page 24.


2. Relieve the pressure.

Filter Removal

3. Turn the air filter counterclockwise to unscrew the filter from its mounting.

Filter/Element Replacement

4. Replace the old air filter element with a new filter element.
5. Clean the sight glass, if necessary. Reinstall the sight glass back on its threaded mounting. Tighten the sight glass.
6. Check for air leakage around the filter.
7. Return the system to current readiness condition.



TI0201

Fig. 11

Ram Assembly Service

Piston Rod Seal Service (Fig. 12)

WARNING


To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** on page 24.

1. **Relieve the air pressure.**
2. Remove the four nuts and lockwashers holding the tie bar to the rods. Remove the tie bar.
3. Remove the guide sleeve retaining ring by gripping the ring tab with a pair of pliers and rotating the ring out of its groove.
4. Remove the guide sleeve by sliding it off of the rod. Four 1/4"-20 holes are provided to ease removal of the guide sleeve.

WARNING

Do not use pressurized air to remove the guide sleeve or piston. Failure to follow this instruction may result in personal injury.

5. Inspect the parts for wear or damage. Replace as necessary.
6. Install new O-rings and seal guard. Lubricate the packings with O-ring lubricant.
7. Slide the guide sleeve onto the rod and push it into the cylinder. Replace the retaining ring by feeding it around the guide sleeve groove.
8. Reinstall the tie bar using the nuts and lockwashers. Torque to 40 ft-lb (54 N•m).



7056A

Fig. 12

Ram Assembly Service

Ram Piston Service (Fig. 13)

WARNING

To reduce the risk of serious injury, whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** on page 24.

1. **Relieve the air pressure.**
2. Remove the tie bar as explained under **Piston Rod Seal Service.**
3. Remove the guide sleeve and slide it off of the piston rod.

WARNING

Do not use pressurized air to remove the guide sleeve or piston. Failure to follow this instruction may result in personal injury.

4. Carefully pull the piston rod **straight** up out of the cylinder. If the rod is cocked to one side, the piston or inside surfaces of the cylinder could be damaged.
5. Carefully lay the piston and rod down so the rod will not be damaged or bent. Remove the lower piston retaining ring. Slide the piston off the piston rod.

6. Install new O-ring seals on the piston rod and the piston. Lubricate the piston and seals. Reinstall the piston and retaining ring.
7. Carefully insert the piston into the cylinder and push the rod **straight** down into the cylinder. Add 3 ounces of lubricant to each cylinder after inserting the piston.
8. Slide the guide sleeve onto the piston rod. Reinstall the retaining ring and tie bar, as explained under **Piston Rod Seal Service.**




Fig. 13

7056A

Ram Assembly Service

The ram assembly service procedures include:

- Low/Empty limit switch replacement
- Ball seat applicator repair procedure
- Servicing the pumps

Low/Empty Limit Switch Replacement

To replace the lower limit switch, do the following:

1. Perform the **System Shutdown** procedure provided by the integrator at the applicable supply unit (LH or RH).

WARNING



ELECTROCUTION HAZARD

Installing and servicing this equipment requires access to parts which could cause an electric shock or other serious injury. Have only qualified electricians access the control assembly.

2. Shut off main air control panel.

NOTE: When raising and lowering the follower plate, be sure that the unit is unobstructed overhead to avoid interference with other objects.

Switch Removal

3. Disconnect the air tubing from the switch. Note the tube and fitting relationship to insure they are reconnected correctly.
4. Mark the surface on the ram limit bracket using a felt-tipped pen to ensure that the new lower limit switch is installed in the same spot.
5. Measure the distance from the mounting bracket (306) to the outer diameter of the limit switch roller to ensure that the new roller is installed in the same position.
6. Remove the fasteners holding the switch to the limit bracket (306).




Fig. 14

Ram Assembly Service

Low/Empty Limit Switch Replacement (continued)

Switch Replacement

7. Install the new limit switch (305) on the limit bracket (306) using the fasteners.
8. Reconnect the tubing for the limit switch.
9. Make sure that the limit switch roller is positioned in the same location per the measurement in step 5. See Fig. 14.
10. Reinstall the cover on the control panel.
11. Resupply air to the control panel.
12. Perform the **Daily System Startup** procedure provided by the integrator at the applicable supply unit (LH or RH).
13. Verify that the limit switch operates correctly.
14. Return the system to current readiness condition.

Servicing the Pumps

When the pumps and air motors require service, refer to the applicable instruction manual. See page 2 for detailed information.

Ram Assembly Service

Replacing Wipers (Fig. 15)

1. Perform the **System Shutdown** procedure provided by the integrator.
2. To replace worn or damaged wipers (412), raise the follower plate up out of the drum. Remove the drum from the base. Wipe the fluid off the follower plate. Refer to the **Drum Changing** procedure on page 25.
3. Separate the wiper joint (A) and bend back the strapping (413) covering the clamp setscrew (415). See Detail A of Fig. 15. Loosen the setscrew, pull the end of the strapping through the clamp (414) and remove the wiper.
4. Slide the strapping (413) through the new wiper (412). Slide the clamp (414) onto the new strapping and bend the strapping back approximately 3 in. (76 mm). Insert the strapping through the clamp a second time. See Detail B of Fig. 15.
5. Install the wipers on the follower plate. Position the wipers so that their joints (A) are 180° apart.

NOTE: You will need the special banding tool (C) shown in Detail C of Fig. 15 to tighten the strapping. Order Part No. 168092 Banding Tool.

6. Grip the strapping (413) with the tool (C) as shown. With your thumb on the gripper lever (E), turn the tool handle (F) clockwise to apply tension.

NOTE: Be careful not to pull the cutting handle (D) until you are ready to cut the strapping in step 8.

7. Continue turning the tool handle until you see the strapping stop moving through the clamp (414). Stop turning the handle.
8. Tighten the setscrew (B) with a wrench (G). Pull the cutting handle (D) to cut. Remove the tool (C). Bend the strapping back over the clamp (414).
9. Pound the wiper all the way around with a rubber mallet until the joints (A) are butted tightly together. Check the overall circumference of both wipers. They should measure less than 135 in. (343 cm). Adjust as necessary.
10. Return the system to current readiness condition. Refer to the **Drum Changing** procedure on page 25.




Fig. 15

Pump Assembly Service

Pump Removal

(Refer to System Parts Diagram; page 38.)

WARNING

To reduce the risk of serious injury, whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** on page 24.

1. Relieve the air pressure from the air motors and ram assembly to be serviced.
2. Move the RAM POSITION switch to HOLD.
3. Close the pump outlet ball valves and relieve the fluid pressure from the pumps at the pump bleed valve on the ram assembly to be serviced.
4. Using an overhead lifting device, attach and secure a chain capable of lifting the weight of the pump assembly to the eye at the top of the air motor.

NOTE: For effective pump removal, the lifting point must be directly above the pump and capable of moving sideways. The lifting action should be the “chain fall” type that allows a slow upward and downward movement.

NOTE: Check the Technical Data page in the separate pump manual to find the weight of the pump being serviced. For example, Graco Premier 45:1 SST Pump (222939) weighs 240 lb (109 kg) per Form 308148.

5. Detach the air hose from the air motor.
6. Detach the fluid supply hose at the pump outlet.

NOTE: When loosening the pump and the air motor fasteners in steps 7 and 8 below, ensure the chain slack is taken up to prevent the pump assembly from falling.

7. On the follower plate adapter, loosen and rotate or remove four lugs and hex bolts holding the flange of the pump lower .
8. On the underside of the air motor, remove the bolts securing the air motor to the motor support brackets. It may be necessary to move or remove some brackets for effective pump removal.
9. Detach any other connections to the pump assembly to ensure the pump is free of attachments before removal. Possible connections include:

- Air motor exhaust kit
- Pump proximity switch kit
- Pump grounding wire

NOTE: When lifting the pump in step 10 below, ensure the lifting chain does not damage the air controls mounted at the top of the ram cross-members.

10. Using a “chain fall” style lifting device, slowly pull the pump upward a few inches until the base of the pump clears the pump mounting adapter and the air motor clears the support brackets.
11. Pull the pump assembly out of the ram assembly and guide the pump assembly downward to the floor, placing the base of the pump on a wood surface and taking care not to damage the seal area of the pump inlet housing.
12. Remove the gasket and o-ring (items 32 and 33) from the pump adapter. They should be discarded and replaced when the pump is reinstalled.
13. Clean excess and hardened material from the pump adapter on the follower plate.
14. Ensure that material is not rising through the pump adapter in the follower plate. If material is flowing upward, move the RAM POSITION switch to RAISE until the flow stops, then move the switch back to HOLD.
15. Move the pump assembly to a suitable work area and repair the pump using the appropriate Graco Instruction Manual.

Pump Installation

(Refer to System Parts Diagram; page 38.)

1. When the pump is serviced and tested and ready to be replaced in the Uni-Drum Ram, perform the steps of the Pump Removal procedure in reverse order.
2. It is recommended that the pump be tagged with the type and date of repair and the name of the technician who performed the repair.
3. Before returning the reassembled pump to production use, it must be primed with material and air removed from the material. Follow the Pump Instruction Form and the pump material bleeding procedure from the Drum Changing Procedure on page 25 .

System Parts

See page 2 for a complete list of Uni-Drum supply units and specific pump information.





Fig. 16

System Parts

Models 246983, 246984, 249154, 249155: See page 2 for a complete list of Uni-Drum supply units and specific pump information.



System Parts

C59784, C59785 20:1 Left and Right Hand Supply Unit with King carbon steel pump

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
1	233050	ELEVATOR, RAM 300 gal RH	1	26	C38324	FITTING, elbow, street	2
	233066	ELEVATOR, RAM 300 gal LH	1	27	233058	HOSE, coupled	2
3	617205	BRACKET, Pump mounting	2	28	521975	FITTING, union, pipe	2
5	C20450	U-BOLT	4	29	118854	VALVE, ball, high pressure	2
8	C19126	SCREW, cap hex head	8	30	070408	SEALANT, pipe, stainless steel	
9	C19200	WASHER	8	33	113332	VALVE, ball, vented	2
10	C19213	WASHER, lock medium	16	40	C20489	FITTING, nipple	1
11	100307	NUT, hex	8	41	106464	TEE, Pipe	1
12	111803	SCREW, cap, hex head	8	42	C20463	FITTING, nipple, reducing	1
13	222833	PUMP, KING 20:1 quiet	2	43	C57799	VALVE, check, 1/2"	1
15	196073	CLAMP	8	44	C19019	FITTING, union, swivel	2
17	100133	WASHER	8	45	214656	HOSE, coupled	1
18	109495	PACKING, O-RING	2	48	C20490	FITTING, nipple, hex	4
19	237569	WIRE, assy, 25 feet	2	51	C12039	HOSE, air	1
22	C38457	FITTING, coupling reducing	2	52	C19032	SWIVEL, Swivel union	1
23	521850	VALVE, check	2	67	175013	NIPPLE, pipe	2

C58461, C58462 33:1 Left and Right Hand Supply Unit with Premier carbon steel pump

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
1	233050	ELEVATOR, RAM 300 gal RH	1	26	C38324	FITTING, elbow, street	2
	233066	ELEVATOR, RAM 300 gal LH	1	27	233058	HOSE, coupled	2
3	C58360	PLATE, adjuster, Uni-Drum	2	28	521975	FITTING, union, pipe	2
4	C58361	BRACKET, pump support	2	29	118854	VALVE, ball, high pressure	2
5	C20450	U-BOLT	4	30	070408	SEALANT, pipe, stainless steel	
6	C19192	NUT, hex, 3/8-16 regular	16	40	C20489	FITTING, nipple	1
7	C19220	PIN, 1/16 x 1/2 cotter	20	41	106464	TEE, Pipe	1
8	C19126	SCREW, cap hex head	4	42	C20463	FITTING, nipple, reducing	1
10	C19213	WASHER, lock medium	16	43	C57799	VALVE, check, 1/2"	1
12	111803	SCREW, cap, hex head	8	44	C19019	FITTING, union, swivel	2
13	222942	PUMP, 800 cm, 33:1	2	45	214656	HOSE, coupled	1
15	196073	CLAMP	8	48	C20490	FITTING, nipple, hex	2
17	100133	WASHER	8	50	C19672	BUSHING, reducing	2
18	109495	PACKING, O-RING	2	51	C12039	HOSE, air	1
19	237569	WIRE, assy, 25 feet	2	52	C19032	SWIVEL, Swivel union	1
22	C38457	FITTING, coupling reducing	2	53	243559	PNEUMATIC	1
23	521850	VALVE, check	2				

System Parts

C59807, C59808 34:1 Left and Right Hand Supply Unit with Premier carbon steel with carbide balls

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
1	233050	ELEVATOR, RAM 300 gal RH	1	26	C38324	FITTING, elbow, street	2
	233066	ELEVATOR, RAM 300 gal LH	1	27	233058	HOSE, coupled	2
3	C58360	PLATE, adjuster, Uni-Drum	2	28	521975	FITTING, union, pipe	2
4	C58361	BRACKET, pump support	2	29	118854	VALVE, ball, high pressure	2
5	C20450	U-BOLT	4	30	070408	SEALANT, pipe, stainless steel	
6	C19192	NUT, hex, 3/8-16 regular	16	40	C20489	FITTING, nipple	1
7	C19220	PIN, 1/16 x 1/2 cotter	20	41	106464	TEE, Pipe	1
8	C19126	SCREW, cap hex head	4	42	C20463	FITTING, nipple, reducing	1
10	C19213	WASHER, lock medium	16	43	C57799	VALVE, check, 1/2"	1
12	111803	SCREW, cap, hex head	8	44	C19019	FITTING, union, swivel	2
13	C59806	PUMP, Premier, 34:1	2	45	214656	HOSE, coupled	1
15	196073	CLAMP	15	48	C20490	FITTING, nipple, hex	2
17	100133	WASHER	8	50	C19672	BUSHING, reducing	2
18	109495	PACKING, O-RING	2	51	C12039	HOSE, air	1
19	237569	WIRE, assy, 25 feet	2	52	C19032	SWIVEL, Swivel union	1
22	C38457	FITTING, coupling reducing	2	53	243559	PNEUMATIC	1
23	521850	VALVE, check	2				

C59778, C59779 45:1 Left and Right Hand Supply Unite with Premier carbon steel pump

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
1	233050	ELEVATOR, RAM 300 gal RH	1	26	C38324	FITTING, elbow, street	2
	233066	ELEVATOR, RAM 300 gal LH	1	27	233058	HOSE, coupled	2
3	C58360	PLATE, adjuster, Uni-Drum	2	28	521975	FITTING, union, pipe	2
4	C58361	BRACKET, pump support	2	29	118854	VALVE, ball, high pressure	2
5	C20450	U-BOLT	4	30	070408	SEALANT, pipe, stainless steel	
6	C19192	NUT, hex, 3/8-16 regular	22	40	C20489	FITTING, nipple	1
7	C19220	PIN, 1/16 x 1/2 cotter	26	41	106464	TEE, Pipe	1
8	C19126	SCREW, cap hex head	4	42	C20463	FITTING, nipple, reducing	1
10	C19213	WASHER, lock medium	22	43	C57799	VALVE, check, 1/2"	1
12	111803	SCREW, cap, hex head	8	44	C19019	FITTING, union, swivel	2
13	237555	PUMP, 45:1, carbon steel	2	45	214656	HOSE, coupled	1
15	196073	CLAMP	15	48	C20490	FITTING, nipple, hex	2
17	100133	WASHER	8	50	C19672	BUSHING, reducing	2
18	109495	PACKING, O-RING	2	51	C12039	HOSE, air	1
19	237569	WIRE, assy, 25 feet	2	52	C19032	SWIVEL, Swivel union	1
22	C38457	FITTING, coupling reducing	2	53	243559	PNEUMATIC	1
23	521850	VALVE, check	2				

System Parts

246983, 246984 45:1 Left and Right Hand Supply Unit with Premier stainless steel pump with silicone nitride balls (depressurization kit not included with these models)

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
1	109495	O-RING	2	20	C38324	FITTING, elbow	2
2	196073	CLAMP	8	21	521975	FITTING, union	2
3	111803	SCREW, cap	8	22	C20490	FITTING, nipple	6
4	100133	WASHER, lock	8	23	158555	NIPPLE, reducing	2
5	C19200	WASHER, plain	14	24	113332	VALVE, ball	2
6	C19213	WASHER, lock	18	25	C19019	FITTING, union	2
7	100307	NUT, hex	10	26	214656	HOSE, coupled, 10 ft.	1
8	C20450	BOLT, u	4	28	C57799	VALVE, check, 1/2 in.	1
9	15D133	CLAMP, support	4	29	C20463	FITTING, nipple	1
10	C58361	BRACKET, support	2	30	C12039	HOSE, air	1
11	C58360	PLATE, adjuster	2	31	C19032	SWIVEL, union	1
12	C19126	SCREW, cap	2	32	106464	TEE, pipe	1
13	246989	PUMP, 800 cm, 45:1 (left)	1	33	C20489	FITTING, nipple	1
14	237569	WIRE, assy. 25 ft.	2	36	248126	RAM, elevator 300 gallon, (left)	1
15	246990	PUMP, 800 cm, 45:1 (right)	1		248127	RAM, elevator 300 gallon, (right)	1
16	118854	VALVE, ball	4	37	15D140	MANIFOLD	1
17	C38457	FITTING, coupling	2	38	234428	HOSE, coupled, 1-1/4 in. x 15 ft.	2
18	246994	VALVE, bleed	2				
19	246929	VALVE, check	2				

249154, 249155 34:1 Left and Right Hand Supply Unit with Premier stainless steel pump with silicone nitride balls (depressurization kit not included with these models)

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
1	109495	O-RING	2	20	C38324	FITTING, elbow	2
2	196073	CLAMP	8	21	521975	FITTING, union	2
3	111803	SCREW, cap	8	22	C20490	FITTING, nipple	6
4	100133	WASHER, lock	8	23	158555	NIPPLE, reducing	2
5	C19200	WASHER, plain	14	24	113332	VALVE, ball	2
6	C19213	WASHER, lock	18	25	C19019	FITTING, union	2
7	100307	NUT, hex	10	26	214656	HOSE, coupled, 10 ft.	1
8	C20450	BOLT, u	4	28	C57799	VALVE, check, 1/2 in.	1
9	15D133	CLAMP, support	4	29	C20463	FITTING, nipple	1
10	C58361	BRACKET, support	2	30	C12039	HOSE, air	1
11	C58360	PLATE, adjuster	2	31	C19032	SWIVEL, union	1
12	C19126	SCREW, cap	2	32	106464	TEE, pipe	1
13	249157	PUMP, 800 cm, 34:1 (left)	1	33	C20489	FITTING, nipple	1
14	237569	WIRE, assy. 25 ft.	2	36	248126	RAM, elevator 300 gallon, (left)	1
15	249158	PUMP, 800 cm, 34:1 (right)	1		248127	RAM, elevator 300 gallon, (right)	1
16	118854	VALVE, ball	4	37	15D140	MANIFOLD	1
17	C38457	FITTING, coupling	2	38	234420	HOSE, coupled	2
18	246994	VALVE, bleed	2				
19	246929	VALVE, check	2				

System Parts

C58607, C58608 56:1 Left and Right Hand Supply Unit with King carbon steel pump

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
1	233050	ELEVATOR, RAM 300 gal RH	1	40	C20489	FITTING, nipple	3
	233066	ELEVATOR, RAM 300 gal LH	1	41	106464	TEE, Pipe	1
4	617205	BRACKET, Pump mounting	2	42	C20463	FITTING, nipple, reducing	1
5	C20450	U-BOLT	4	43	C57799	VALVE, check, 1/2"	1
8	C19126	SCREW, cap hex head	8	44	C19019	FITTING, union, swivel	2
9	C19200	WASHER	8	45	214656	HOSE, coupled	1
10	C19213	WASHER, lock medium	16	48	C20490	FITTING, nipple, hex	2
13	245713	PUMP, King 56:1	2	51	C12039	HOSE, air	1
11	100307	NUT, hex	8	52	C19032	SWIVEL, Swivel union	1
17	100133	WASHER	8	56	165702	HOUSING, valve	2
18	109495	PACKING, O-RING	2	57	190128	PLUG, valve	2
19	237569	WIRE, assy, 25 feet	2	58	276025	LUG	8
22	C38457	FITTING, coupling reducing	2	59	102637	SCREW, cap	8
23	521850	VALVE, check	2	60	190166	CYLINDER, intake	2
26	C38324	FITTING, elbow, street	2	61	109495	PACKING, O-RING	1
27	233058	HOSE, coupled	2	64	517038	SCREW, hex head	32
28	521975	FITTING, union, pipe	2	65	C19662	BUSHING,, 1-1/4" X 1	2
29	118854	VALVE, ball, high pressure	2	66	108124	VALVE, safety	2
30	070408	SEALANT, pipe, stainless steel		67	175013	NIPPLE, pipe	2
33	113332	VALVE, ball, vented	2				

249311, 249312 56:1 Left and Right Hand Supply Unit with King carbon steel pump

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
1	249310	ELEVATOR, RAM 300 gal RH	1	41	106464	TEE, Pipe	1
	249309	ELEVATOR, RAM 300 gal LH	1	42	C20463	FITTING, nipple, reducing	1
4	617205	BRACKET, Pump mounting	2	43	C57799	VALVE, check, 1/2"	1
5	C20450	U-BOLT	4	44	C19019	FITTING, union, swivel	2
8	C19126	SCREW, cap hex head	8	45	214656	HOSE, coupled	1
9	C19200	WASHER	8	48	C20490	FITTING, nipple, hex	2
10	C19213	WASHER, lock medium	16	52	C19032	SWIVEL, Swivel union	1
11	100307	NUT, hex	8	56	165702	HOUSING, valve	2
13	245713	PUMP, King 56:1	2	57	190128	PLUG, valve	2
17	100133	WASHER	8	58	276025	LUG	8
18	109495	PACKING, O-RING	2	59	102637	SCREW, cap	8
19	237569	WIRE, assy, 25 feet	2	60	190166	CYLINDER, intake	2
26	C38324	FITTING, elbow, street	2	61	109495	PACKING, O-RING	1
29	118854	VALVE, ball, high pressure	2	64	517038	SCREW, hex head	32
30	070408	SEALANT, pipe, stainless steel		66	108124	VALVE, safety	2
33	113332	VALVE, ball, vented	2	67	175013	NIPPLE, pipe	2
40	C20489	FITTING, nipple	3				

System Parts

C59793, C59794 45:1 Left and Right Hand Supply Unit with Premier carbon steel pump


Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
1	233050	ELEVATOR, RAM 300 gal RH	1	23	521850	VALVE, check	2
	233066	ELEVATOR, RAM 300 gal LH		26	C38324	FITTING, elbow, street	2
3	C58360	PLATE, adjuster, Uni-Drum	2	27	233058	HOSE, coupled	2
4	C58361	BRACKET, pump support	2	28	521975	FITTING, union, pipe	2
5	C20450	U-BOLT	4	29	521629	VALVE, ball, high pressure	2
8	C19126	SCREW, cap hex head	4	30	070408	SEALANT, pipe, stainless steel	
9	C19200	WASHER	14	33	113332	VALVE, ball, vented	2
10	C19213	WASHER, lock medium	18	40	C20489	FITTING, nipple	1
11	100307	NUT, hex	10	41	106464	TEE, Pipe	1
12	111803	SCREW, cap, hex head	8	42	C20463	FITTING, nipple, reducing	2
13	233069	PUMP, 800 cm, 45:1	1	43	C57799	VALVE, check, 1/2"	1
	233070	PUMP, 800 cm, 45:1	1	44	C19019	FITTING, union, swivel	2
15	196073	CLAMP	8	45	214656	HOSE, coupled	1
16	158555	NIPPLE, reducing	2	48	C20490	FITTING, nipple, hex	4
17	100133	WASHER	8	50	C19672	BUSHING, reducing	2
18	109495	PACKING, O-RING	2	51	C12039	HOSE, air	1
19	237569	WIRE, assy, 25 feet	2	52	C19032	SWIVEL, Swivel union	1
22	C38457	FITTING, coupling reducing	2				

C58601, C58338 67:1 Left and Right Hand Supply Unit with Premier carbon steel pump

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
1	233050	ELEVATOR, RAM 300 gal RH	1	41	106464	TEE, Pipe	1
	233066	ELEVATOR, RAM 300 gal LH		42	C20463	FITTING, nipple, reducing	2
3	C58360	PLATE, adjuster, Uni-Drum	2	43	C57799	VALVE, check, 1/2"	1
4	C58361	BRACKET, pump support	2	44	C19019	FITTING, union, swivel	2
5	C20450	U-BOLT	4	45	214656	HOSE, coupled	1
6	C19192	NUT, hex, 3/8-16 regular	16	48	C20490	FITTING, nipple, hex	4
7	C19220	PIN, 1/16 X 1/2 cotter	20	51	C12039	HOSE, air	1
8	C19126	SCREW, cap hex head	4	52	C19032	SWIVEL, Swivel union	1
10	C19213	WASHER, lock medium	16	54	C06304	VALVE, Relief	2
13	239828	PUMP, 800 cm, 67:1	2	55	C58449	LABEL	2
17	100133	WASHER	8	56	165702	HOUSING, valve	4
26	C38324	FITTING, elbow, street	2	57	190128	PLUG, valve	4
27	233058	HOSE, coupled	2	58	276025	LUG	8
28	521975	FITTING, union, pipe	2	59	102637	SCREW, cap	8
29	118854	VALVE, ball, high pressure	2	60	190166	CYLINDER, intake	2
30	070408	SEALANT, pipe, stainless steel		61	109495	PACKING, O-RING	2
33	113332	VALVE, ball, vented	2	62	617201	VALVE, check	2
40	C20489	FITTING, nipple	1	63	C20465	FITTING, reducing, nipple	1

System Parts

243559 Pneumatic Panel Layout



TI0419B

Fig. 17

System Parts

243559, Pneumatic Layout Panel

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
101	115837	Control Enclosure Box		137	C20353	FITTING, tube	2
102	C20357	TEE, push, branch	1	138	517309	FITTING, tube	2
103	517302	PANEL, Uni-Drum	1	139	517355	VENT, breather	
104	517315	VALVE, 3-way, button, palm		140	517307	FITTING, tube reducer 5t x .25T	1
105	C06149	VALVE, pilot, dual air, 4-way		141	C20344	UNION, tee	1
106	517324	VALVE	1	142	517305	TUBING, nylon, 5/32 OD	90
107	517323	VALVE, ball, vented .500		143	590332	TUBING, polyflo, 1/4" OD X 5/32" ID	
108	517322	VALVE, pneumatic impulse 1/8 nptf		144	C12194	TUBING, 1/2 OD	6
109	517321	VALVE, shuttle		145	C20496	PLUG, tube	
110	C06206	AIR REGULATOR	2	146	C19019	FITTING, union swivel	1
111	517320	INDICATOR, pneumatic, red		147	C19086	SCREW, hex, 1/4-20 x 4	2
112	517412	VALVE, 4-way	1	148	105510	WASHER, lock, spring	4
113	517318	INDICATOR, pneumatic, green		149	C19812	SCREW, capscrew	2
114	517317	AIR REGULATOR, miniature	1	150	C19048	SCREW, round head machine	2
115	517316	GAUGE	2	151	100020	WASHER, lock	2
116	517314	VALVE, 3-way, button, palm		152	C19158	SCREW	6
117	517313	VALVE	2	155	C19404	FITTING, Tube 1/8" npt 5/32" OD	2
118	C20740	SWIVEL, connector/adapter	1	156	196058	PLUG, restrictor	1
119		SWIVEL, 1/2 in. elbow	1	157	168491	EMBLEM, Graco	1
121	C19466	FITTING, elbow		158	C19405	FITTING, connector, male	1
122	517304	BRACKET, mounting	1	159	C19159	SCREW	6
123	598140	ELBOW, tube, 5/32	14	160	C19215	WASHER, lock, med #8 bolt	6
124	C19387	TUBE	7	161	517360	VALVE, air, 3-way	3
125	C20355	BRANCH TEE, 1/8P	3	162	113911	GAUGE, pressure air	1
126	C19381	FITTING; 1/2 tube x 1/2 npt	4	163	513594	SWITCH, selector, 2 position	1
127	C20360	FITTING, tube	1	164	551659	CONTACT, block	1
128	C19391	ELBOW, swivel, 1/4 npt	1	165	551663	BASE, mounting switch	1
129	C20498	BULKHEAD, tube; 1/4 in.	6	166	100284	NUT, hex, mscr	1
130	517312	FITTING, adapter, 1/4 x 5/32	4	167	100079	WASHER, lock, spring	1
131	517311	FITTING, tube	4	168	102795	SCREW, cap, sch	1
132	C19254	PLUG, pipe	2	169	115826	VALVE, control, timer	1
133	517310	FITTING, tube	3	170	115828	VALVE, check	1
134	C20499	FITTING, tube	1	171		SWIVEL, 1/2 in. straight	1
135	597151	ELBOW, swivel, 1/8 npt	2	172		NIPPLE, 1/2 in.	1
136	513226	FITTING, tee	1	173		NIPPLE, 1/2 in. short	1

System Parts

243559, PLC Pneumatic Layout Panel Left Side




Fig. 18

System Parts

243559, PLC Pneumatic Layout Panel Right Side




Fig. 19

System Parts






Fig. 20

TI0422

System Parts




Fig. 21

System Parts

Part No. 233041 Follower Plate

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
401	233040	PLATE, ram	1	413	068104	STRAPPING; steel	288 in.
402*	115782	CYLINDER, air	2	414	101817	CLAMP, banding	2
403*	196052	SPACER	8	415	115785	SCREW, set	2
404*	196053	PLATE	2	416	617230	GASKET	2
405*	517286	PLUNGER	2	417	196072	RING, adapter	2
406*	115783	BOLT, hex hd	2	418	233044	PLUG, vent	2
407*	196051	SPACER	2	419	C19843	CAPSCREW	4
408*	100333	SCREW, cap, hex hd	8	420	C19280	LOCKWASHER	4
409*	100016	WASHER, lock 1/4 in.	8	421	102726	PLUG, pipe	2
410*	112245	O-RING	2	422	196122	SHIELD	2
411*	115784	SCREW, cap, socket hd	8	423	114269	GROMMET	2
412	617195	WIPER	2	* Items 402–411 sold separately or as 234958 Vent Valve Kit.			

System Parts





Fig. 22


System Parts

Part No. 248126 and 248127 Elevator Assembly



System Parts

Part No. 248126 and 248127 Elevator Assembly



ti4548a


System Parts

Part No. 248126 and 248127 Elevator Assembly

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
1	617206	ELEVATOR, weldmont 300 gallon	1				
2	617204	CARRIAGE, weldmont 300 gallon	1	51	C20485	NIPPLE, hex	1
3	233041	PLATE, ram, Neoprene	1	52	100549	ELBOW, street 90°	2
4	517269	VALVE, drain	4	53	C20461	NIPPLE, reducing	2
5	C12194	TUBE, nylon	19.8 ft	54	515147	REGULATOR, air, 1/2 p	2
6	C19291	NUT, hex	2	55	C19391	ELBOW, fitting	2
7	100361	PLUG, pipe	2	56	106464	TEE, pipe	1
8	114129	CONNECTOR, fitting (m)	8	57	158555	NIPPLE, reducing	2
9	C31001	WIPER, rod	4	58	214849	LUBRICATOR, air line	2
10	C03043	RING, snap	4	59	517290	HOSE	2
11	C20808	SCREW, sockethead	16	60	224040	VALVE, runaway	2
12	617179	PAD, rest	4	61	C19438	ELBOW, 90°	2
13	C19725	WASHER	4	62	C19630	NIPPLE, 1 npt	1
14	C20811	SCREW, sockethead	12	63	113532	ELBOW, fitting (f)	4
15a	115441	ARM, limit switch	1	64	113093	CONNECTOR, pipe	2
15b	C06019	VALVE, limit	1	65	157191	ADAPTER, fitting, 1/2 npt x 3/4 npt	2
16	104472	SCREW, cap	2	66	100469	SCREW, cap, hex	2
17	100020	WASHER, lock	2	68	617202	MANIFOLD, air	1
18	C03042	RING	4	69	114112	CONNECTOR (f)	2
19	116325	O-RING, packing	4	70	160022	UNION	1
20	156593	O-RING, packing	4	71	C20489	NIPPLE	1
21	C31000	SLEEVE	4	72	112859	FILTER, air, 1 npt	1
22	617176	ROD, lift	4	73	C20378	FITTING, branch y	2
23	C20417	RING, retaining	8	74	C12509	TUBE, nylon	54.8 ft
24	C03046	PISTON, elevator	4	75	517272	CLAMP	2
25	C20280	O-RING	4	76	617149	ACTUATOR	1
26	C03047	GUIDE, band	4	77	C19810	SCREW, cap	2
27	158776	O-RING, packing	4	78	160327	UNION, 90°	2
28	C19130	SCREW, cap, hex	6	79	C19965	SCREW, cap	2
29	100018	WASHER, lock, spring	8	80	C19212	WASHER, lock	2
30	194968	CLAMP	2	81	617265	BRACKET, mounting	1
31	517281	PIN, spring	2	82	517288	TUBE, coiled	2
34	101535	NUT, full hex	8	83	243559	BOX, pneumatic control	1
35	101533	WASHER, spring lock	8	84	114110	ELBOW, swivel (m)	1
37	100681	NUT, jam, hex	2	85	617200	SUPPORT, bracket	1
38	517411	KNOB	2	86	114111	CONNECTOR (m)	1
41	100321	NUT	6	87	597151	ELBOW, swivel, 1/8 npt	2
42	196084	COVER, right	1	88	C06182	VALVE, air limit	1
43	196085	COVER, left	1	89	100049	SCREW, cap, hex	2
45	516102	CLAMP, pipe	2	90	112698	ELBOW, swivel, (m)	6
46	114508	NIPPLE, fitting	1	91	C19124	SCREW, cap, hex	4
47	104765	PLUG, pipe	1	92	C19213	WASHER, lock	6
48	617180	ROD, connecting	4	93	517254	CLIP, tube	2
49	C19200	WASHER, plain	4	94	110299	RIVET, blind	2
50	C19019	UNION, swivel	1	95	106149	FILTER, air, 1/2 npt	1



System Parts

Part No. 233050, 233066, 249311, and 249312 Elevator Assembly




System Parts

Part No. 233050, 233066, 249311, and 249312 Elevator Assembly



TI6632A



ti4548a

System Parts

Part No. 233050, 233066, 249311, and 249312 Elevator Assembly

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
1	617206	ELEVATOR, weldmont 300 gallon	1	54	515147	REGULATOR, air, 1/2 p	2
2	617204	CARRIAGE, weldmont 300 gallon	1	55	C19391	ELBOW, fitting	2
3	233041	PLATE, ram, Neoprene	1	56	106464	TEE, pipe	1
4	517269	VALVE, drain	4	57	158555	NIPPLE, reducing	2
5	054139	TUBE, nylon	17.8 ft	58	214849	LUBRICATOR, air line	2
6	C19291	NUT, hex	2	59	517290	HOSE	2
7	100361	PLUG, pipe	2	60	224040	VALVE, runaway	2
8	114129	CONNECTOR, fitting (m)	8	61	C19438	ELBOW, 90°	2
9	C31001	WIPER, rod	4	62	C19630	NIPPLE, 1 npt	1
10	C03043	RING, snap	4	63	113532	ELBOW, fitting (f)	4
11	C20808	SCREW, sockethead	16	64	113093	CONNECTOR, pipe	2
12	617179	PAD, rest	4	65	157191	ADAPTER, fitting, 1/2 npt x 3/4 npt	2
13	C19725	WASHER	4	66	100469	SCREW, cap, hex	2
14	C20811	SCREW, sockethead	12	68	617202	MANIFOLD, air	1
15a	115441	ARM, limit switch	1	69	114112	CONNECTOR (f)	2
15b	C06019	VALVE, limit	1	70	C19032	UNION	1
16	104472	SCREW, cap	2	71	C20489	NIPPLE	1
17	100020	WASHER, lock	2	72	112859	FILTER, air, 1 npt	1
18	C03042	RING	4	73	C20378	FITTING, branch y	2
19	116325	O-RING, packing	4	74	C12509	TUBE, nylon	54.8 ft
20	156593	O-RING, packing	4	75	517272	CLAMP	2
21	C31000	SLEEVE	4	76	617149	ACTUATOR	1
22	617176	ROD, lift	4	77	C19810	SCREW, cap	2
23	C20417	RING, retaining	8	78	160327	UNION, 90°	2
24	C03046	PISTON, elevator	4	79	C19965	SCREW, cap	2
25	C20280	O-RING	4	80	C19212	WASHER, lock	2
26	C03047	GUIDE, band	4	81	617265	BRACKET, mounting	1
27	158776	O-RING, packing	4	82	517288	TUBE, coiled	2
28	C19130	SCREW, cap, hex	6	83	243559	BOX, pneumatic control	1
29	100018	WASHER, lock, spring	8	84	114110	ELBOW, swivel (m)	1
30	194968	CLAMP	2	85	617200	SUPPORT, bracket	1
31	517281	PIN, spring	2	86	114111	CONNECTOR (m)	1
34	101535	NUT, full hex	8	87	597151	ELBOW, swivel, 1/8 npt	2
35	101533	WASHER, spring lock	8	88	C06182	VALVE, air limit	1
37	100681	NUT, jam, hex	2	89	100049	SCREW, cap, hex	2
38	517411	KNOB	2	90	112698	ELBOW, swivel, (m)	6
41	100321	NUT	6	91	C19124	SCREW, cap, hex	4
42	196084	COVER, right	1	92	C19213	WASHER, lock	6
43	196085	COVER, left	1	93	517254	CLIP, tube	2
45	516102	CLAMP, pipe	2	94	110299	RIVET, blind	2
46	114508	NIPPLE, fitting	1	95	106149	FILTER, air, 1/2 npt	1
47	104765	PLUG, pipe	1	96	617203	SUPPORT, bar	1
48	617180	ROD, connecting	4	97	C20450	U-BOLT	2
49	C19200	WASHER, plain	4	98*	C20449	U-BOLT, w/nuts	2
50	C19019	UNION, swivel	1	99*	517284	MANIFOLD, discharge	1
51	C20485	NIPPLE, hex	1				
52	100549	ELBOW, street 90°	2				
53	C20461	NIPPLE, reducing	2				

* 233050 and 233066 only.

Recommended Spare Parts

Spare Parts for Pump and Air Motor

See appropriate manual listed on page 2.

Spare Parts for Ram Plate Assembly

The customer should maintain an inventory of the spare parts (per unit) listed below.

Part No.	Description	Qty.	Part No.	Description	Qty.
918241	WIPER KIT	1	112245*	O-RING	2
517286*	PLUNGER	2	115782*	AIR CYLINDER	2
196053*	PLATE	2	196051*	SPACER	2
115783*	BOLT	2	115784*	SCREW	8
196052*	SPACER	8	617230	GASKET	2
			109195	O-RING	4

*Can be preassembled for a quick replacement of vent assembly.

Spare Parts for Ram Plate Assembly

Part No.	Description
918110	REPAIR KIT
108035	FILTER KIT

Optional Long Bleeder Valve


Part No.	Description
190126	BODY, bleeder
190128	PLUG, valve

Pneumatic Diagram

Pneumatic Layout Panel

LEGEND

DV - DIRECTIONAL VALVE
 IV - IMPULSE VALVE
 SV - SHUTTLE VALVE
 R - REGULATOR
 I - INDICATOR
 GA - GAUGE



TI0423

Technical Data

Unit	Description	Specification
Uni-Drum System	Overall dimensions:	Width: 69 in. (1753 mm)
		Depth: 51 in. (1295 mm)
		Height (lowered): 85.2 in. (2164 mm)
		Height (raised): 141 in. (3581 mm)
Supply Units (LH and RH)	Compressed air requirement	80 psi maximum (5.5 bar, 0.55 MPa)
		450 cfm
	Main air inlet size	1 in. npt(f)
	Overall Weight	Approximately 3950 lb (1792 kg)

Technical Data (King Pumps)

Unit	Description	Specification
Pumps (LH-C59784) (RH-C59785)	Ratio	20:1 fluid to air power ratio
	Maximum fluid working pressure	1800 psi (124.0 bar, 12.0 MPa)
	Maximum air input pressure	90 psi (6.2 bar, 620 kPa)
	Pump cycles	6.5 per 1 gal. (3.8 liters)
	Recommended pump speed for continuous operation	50 cycles per min
	Maximum flow rate	12.0 gpm (46.0 liters/min) at 50 cycles/min
	Air motor piston effective area	78.5 in. ² (506 cm ²)
	Stroke length	4.75 in. (120 mm)
	Displacement pump effective area	3.72 in. ² (24 cm ²)
	Pump operating temperature	180.0° F (82.0° C) maximum temperature
	Air inlet size	3/4 in. npsm(f)
	Fluid inlet size	2.0 in. npt(f)
	Fluid outlet size	1-1/2 in. npt(m)
	Wetted components	Carbon Steel; Chrome, Zinc, and Electroless Nickel Plating; 304, 440, and 17-4 PH Grades of Stainless Steel; Ductile Iron; Tungsten Carbide; Delrin®; PTFE; Leather
	Weight	Approx. 162 lbs. (69 kg) per pump
Pumps (LH-C58607) (RH-C58608) (LH-249311) (RH-249312)	Ratio	56:1 fluid to air power ratio
	Maximum fluid working pressure	5000 psi (345.0 bar, 34.0 MPa)
	Maximum air input pressure	90 psi (6.0 bar, 0.6 MPa)
	Pump cycles	18.0 per 1 gal. (3.8 liters)
	Recommended pump speed for continuous operation	60 cycles per min
	Maximum flow rate	3.4 gpm (12.9 liters/min) at 60 cycles/min
	Air motor piston effective area	78.5 in. ² (506 cm ²)
	Stroke length	4.75 in. (120 mm)
	Displacement pump effective area	1.40 in. ² (9 cm ²)
	Pump operating temperature	180.0° F (82.0° C) maximum temperature
	Air inlet size	3/4 in. npsm(f)
	Fluid inlet size	2.0 in. npt(f)
	Fluid outlet size	1.0 in. npt(m)
	Wetted components	Carbon Steel; Chrome Steel; Alloy Steel; Chrome, Zinc, and Nickel Plating; 440 and 17-4 PH Grades of Stainless Steel; Ductile Iron; Tungsten Carbide; PTFE; Glass-Filled PTFE
	Weight	Approx. 130 lbs. (59 kg) per pump

Technical Data (Premier Pumps)

Unit	Description	Specification
Pumps (LH-C58338) (RH-C58601)	Ratio	67:1 fluid to air power ratio
	Maximum fluid working pressure	5000 psi (345.0 bar, 34.5 MPa)
	Maximum air input pressure	75 psi 5.2 bar, 0.5 MPa)
	Pump cycles	12.5 per 1 gal. (3.8 liters)
	Recommended pump speed for continuous operation	40 cycles per min
	Maximum flow rate	4.8 gpm (18.2 liters/min) at 60 cycles/min
	Air motor piston effective area	12.6 in. ² (321 cm ²)
	Stroke length	4.75 in. (120 mm)
	Displacement pump effective area	1.86 in. ² (12 cm ²)
	Pump operating temperature	160.0° F (71.0° C) maximum temperature
	Air inlet size	3/4 in. npsm(f)
	Fluid inlet size	2.0 in. npt(f)
	Fluid outlet size	1-1/2 in. npt(m)
	Wetted components	Carbon Steel; Chrome, Zinc, and Electroless Nickel Plating; 304, 440, and 17-4 PH Grades of Stainless Steel; Ductile Iron; Tungsten Carbide; Delrin®; PTFE; Leather
	Weight	Approx.240 lbs. (109 kg) per pump

Technical Data (Premier Pumps)

Unit	Description	Specification
Pumps (LH-C58461) (RH-C58462)	Ratio	34:1 fluid to air power ratio
Pumps (LH-C59807) (RH-C59808)		
Pumps (LASD) (LH-249154) (RH-249155)		
	Maximum fluid working pressure	3400 psi (235.0 bar, 24.0 MPa)
	Maximum air input pressure	100 psi (7.0 bar, 0.7 MPa)
	Pump cycles	6.5 per 1 gal. (3.8 liters)
	Recommended pump speed for continuous operation	60 cycles per min
	Maximum flow rate	9.2 gpm (34.6 liters/min) at 60 cycles/min
	Air motor piston effective area	38.5 in. ² (800 cm ²)
	Stroke length	4.75 in. (120 mm)
	Displacement pump effective area	3.72 in. ² (24 cm ²)
	Pump operating temperature	180.0° F (82.0° C) maximum temperature
	Air inlet size	3/4 in. npsm(f)
	Fluid inlet size	2.0 in. npt(f)
	Fluid outlet size	1-1/2 in. npt(m)
	Wetted components	Carbon Steel; Chrome, Zinc, and Electroless Nickel Plating; 304, 440, and 17-4 PH Grades of Stainless Steel; Ductile Iron; Tungsten Carbide; Delrin®; PTFE; Leather <i>LASD Pumps Only:</i> 304, 329, and 17-4 Stainless Steel, Silicone Nitride, Delrin, PTFE, Ultra High Molecular Weight Polyethylene, Leather
	Weight	Approx. 240 lbs. (109 kg) per pump

Technical Data (Premier Pumps)

Unit	Description	Specification
Pumps (LH-C59778) (RH-C59779) (LH-246983) (RH-246984) (LH-C59793) (RH-C59794)	Ratio	45:1 fluid to air power ratio
	Maximum fluid working pressure	4500 psi (310.0 bar, 31.0 MPa)
	Maximum air input pressure	100 psi (7.0 bar, 0.7 MPa)
	Pump cycles	8.7 per 1 gal. (3.8 liters)
	Recommended pump speed for continuous operation	60 cycles per min
	Maximum flow rate	6.9 gpm (26.1 liters/min) at 60 cycles/min
	Air motor piston effective area	38.5 in. ² (800 cm ²)
	Stroke length	4.75 in. (120 mm)
	Displacement pump effective area	2.79 in. ² (18 cm ²)
	Pump operating temperature	150.0° F (65.5° C) maximum temperature
	Air inlet size	3/4 in. npsm(f)
	Fluid inlet size	2.0 in. npt(f)
	Fluid outlet size	1-1/2 in. npt(m)
	Wetted components	Carbon Steel; Chrome, Zinc, and Electroless Nickel Plating; 304, 440, and 17-4 PH Grades of Stainless Steel; Ductile Iron; Tungsten Carbide; Delrin®; PTFE; Leather; Silicon Nitride (models 246983 and 246984 only); UHMW Polyethylene
	Weight	Approx. 240 lbs. (109 kg) per pump

Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Information

TO PLACE AN ORDER, contact your Graco distributor, or call one of the following numbers to identify the distributor closest to you:

1-800-328-0211 Toll Free

612-623-6921

612-378-3505 Fax

All information, illustrations and specifications in this document are based on the latest product information available at the time of publication. The right is reserved to make changes at any time without notice.

MM 309169

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441

www.graco.com

PRINTED IN U.S.A. 309169 07/2000, Revised 1/2006