

Desiccant Air Drying System

309921 rev.G

Model 234401

Maximum Operating Pressure 160 psi (1.1 MPa, 11 bar)

Maximum Temperature 150° F (65° C)



Important Safety Instructions

Read all warnings and instructions in this manual.
Save these instructions.




Includes:

Part No.	Description	Air Inlet npt(f)	Air Outlet npt(f)	Air Flow Capacity	Maximum Operating Pressure
234402	Stage 1 - Air Filter with auto drain Removes water and contaminants down to 5 microns.	1/2 in.	1/2 in.	108 CFM	175 psi (1.2 MPa, 12 bar)
234403	Stage 2 - Coalescer with auto drain Removes oil and sub-micronic particles down to .01 microns.	1/2 in.	1/2 in.	35 CFM	175 psi (1.2 MPa, 12 bar)
234404	Stage 3 - Desiccant Housing Removes uncondensed moisture.	3/4 in. reduced to 1/2 in.	3/4 in. reduced to 3/8 in.	30 CFM	175 psi (1.2 MPa, 12 bar)
288787	Self Relieving Air Regulator	3/8 in.	1/4 in.	100 CFM	160 psi (1.1 MPa, 11 bar)
288810	Silica Gel Desiccant (5 lb. can)				
288798	Shut-off Valve				
288808	Mounting Bracket				

PROVEN QUALITY. LEADING TECHNOLOGY.

How Desiccant Air Drying System Works



When air is compressed, the temperature of the air increases, as does its capacity to hold moisture. As the hot, moist air travels down through the lines, it cools, allowing the moisture to condense. Filters, drain traps, and driplegs only remove liquid condensation. The Dryaire Desiccant Air Drying System removes liquid condensation, residual water vapor and aerosols.

As the wet compressed air flows through the inlet port and down the bed of desiccant, the desiccant beads absorb the water vapor and aerosols and can reduce the air humidity down to a -40°F (-40°C) pressure dew point.


After the moisture has been removed, the dry air passes through an element, up the center tube, and out the outlet port. As long as the desiccant is replaced at saturation point and your compressed air is not exposed to a temperature below the dew point, your equipment will receive dry, moisture-free air.

As the desiccant becomes saturated with moisture, the dew point begins to rise. This is evident when the blue silica gel desiccant beads in the sight glass change to pink, indicating the need for desiccant replacement. Refer to **Desiccant Changeout**, page 7.

Installation

1. Before installing air line components, blow out the pipe line to remove debris. Be sure air to the regulator is clean. Erratic operation or loss of regulation is usually caused by dirt in the regulator.
2. Install the Air Drying System as close as possible to the equipment it serves. Use template 289185, provided, to position system.
3. Install air shut-off valve 288798 upstream from the air system to isolate it for service.
4. Install system so air flows through filters in the direction noted on top of filter.
5. A minimum 1/2 in. npt piping is recommended. Avoid using too many fittings, couplings, etc., which will restrict air flow.

Shop Air Piping Layout



- Main Air Line stand pipe should not be smaller than compressor outlet size.
- A minimum of 25 ft. (7.62 m) from compressor to first filter outlet is required to cool air [50 ft. (15.24 m) optimum]

Minimum Pipe Size Recommendations			
Compressor		Main Air Line	
Size	Capacity	Length	Size
1-1/2 - 2 HP	6 - 9 CFM	any	3/4 in. (19 mm)
3 - 5 HP	12 - 20 CFM	Up to 200 ft (61 m)	3/4 in. (19 mm)
		Over 200 ft (61 m)	1 in. (25.4 mm))
5 - 10 HP	20 - 40 CFM	Up to 100 ft (30.5)	3/4 in. (19 mm)
		Over 100-200ft(30.5-61 m)	1 in. (25.4 mm)
		Over 200 ft (61 m)	1-1/4 in. (31.8 mm)
10 - 15 HP	40 - 60 CFM	Up to 100 ft (30.5)	3/4 in. (19 mm)
		Over 100-200ft(30.5-61 m)	1-1/4 in. (31.8)
		Over 200 ft (61 m)	1-1/2 in. (38.1)

Air Pressure Drop Through Hose, by hose length and ID psi (Kpa, bar)						
Air Hose Inside Diameter	4 ft. (1.22 m)	10 ft. (3.05 m)	15 ft. (4.6 m)	20 ft. (6.1 m)	25 ft. (7.62 m)	50 ft. (15.24 m)
1/4 in. (6.4 mm)						
40 psi (276 kPa, 2.8 bar)	6 (41, .4)	8 (55, .6)	9.5 (66, .7)	11 (76, .8)	12.75 (88, 0.9)	24 (165, 1.7)
50 psi (345 kPa, 3.4 bar)	7.5 (52, .5)	10 (69, .7)	12 (83, .8)	14 (97, 1)	16 (110, 1.1)	28 (193, 1.9)
60 psi (414 kPa, 4.1 bar)	9 (62, .6)	12.5 (86, .9)	14.5 (100, .1)	16.75(115, 1.2)	19 (131, 1.3)	31 (214, 2.1)
70 psi (483 kPa, 4.8 bar)	10.75 (74, .7)	14.5 (100, 1)	17 (117, 1.2)	19.5 (134, 1.3)	22.5 (155, 1.6)	34 (234, 2.3)
80 psi (552 kPa, 5.5 bar)	12.25 (84, .8)	16.5(114, 1.1)	19.5 (134, 1.3)	22.5 (155, 1.6)	25.5 (176, 1.8)	37 (255, 2.6)
90 psi (621 kPa, 6.2 bar)	14 (97, 1)	18.75 (129, 1.3)	22 (152, 1.5)	25.25 (172, 1.7)	29 (200, 2)	39.5 (169, 2.7)
5/16 in. (7.9 mm)						
40 psi (276 kPa, 2.8 bar)	2.25 (16, .2)	2.75 (19, .2)	3.25 (22, .2)	3.5 (24, .2)	4 (28, .3)	8.5 (59, .6)
50 psi (345 kPa, 3.4 bar)	3 (21, .2)	3.5 (24, .2)	4 (28, .3)	4.5 (31, .3)	5 (34, .3)	10 (69, .7)
60 psi (414 kPa, 4.1 bar)	3.75 (26, .3)	4.5 (31, .3)	5 (34, .3)	5.5 (38, .4)	6 (41, .4)	11.5 (79, .8)
70 psi (483 kPa, 4.8 bar)	4.5(31, .3)	5.25 (36, .4)	6 (41, .4)	6.75 (47, .5)	7.25 (50, .5)	13 (90, .9)
80 psi (552 kPa, 5.5 bar)	5.5 (38, .4)	6.25 (43, .4)	7 (48, .5)	8 (55, .6)	8.75 (60, .6)	14.5 (100, 1)
90 psi (621 kPa, 6.2 bar)	6.5 (45, .4)	7.5 (52, .5)	8.5 (59, .6)	9.5 (66, .7)	10.5 (72, .7)	16 (110, 1.1)

Operation



WARNING

Do not exceed the Maximum Incoming Air Pressure of the equipment. Over pressurizing can cause component rupture and serious injury.


1. Attach air hose(s) to air regulator outlet valve 289165.
2. Open main shut-off valve 288798.
3. Turn the T-hand adjusting screw in or out to adjust regulator to desired setting.
4. Open outlet valve 289165 to supply air to spray guns or tool.
5. With air flowing, readjust air pressure regulator if necessary.
6. Turn off unit when not in use. Follow **Pressure Relief Procedure**, page 6.

Auto Drain

Both Air Filter 234402 and Coalescer 234403 have an auto drain. When the bowl is pressurized, the piston travels down against the spring and closes the drain opening. When the bowl is depressurized (i.e., overnight when system is shut down), the spring lifts the piston from the seal, allowing the bowl to drain.



You can also push the piston stem on the bottom of the filter to manually drain the bowl.





Part No.	Description
234402	Air Filter with auto drain; see Manual 309919 for parts information
234403	Coalescer with auto drain; see Manual 309919 for parts information
234404	Desiccant Housing
288787	Air Regulator, self relieving
289185	Template/Spacer
288789	Nipple with screen
288798	Shut-off Valve
289165	Regulator Outlet Valve

Coalescer Pressure Drop Indicator

The differential pressure drop indicator provides early detection of a clogged coalescing filter element. As the filter element becomes clogged, the red indicator starts to rise while air is flowing through the unit. When the pressure drop across the element reaches 10-12 psi (69-83 kPa, 0.7-0.8 bar), the red indicator will be in full view, and the element should be replaced. Failure to replace the element when the pressure drop exceeds 10 psi (69 kPa, 0.7 bar) will affect your air quality and tool efficiency.

Pressure Relief Procedure

**WARNING**




To avoid injury, relieve air and fluid pressure before checking, cleaning, or repairing the equipment.

The following is a basic pressure relief procedure. Be sure to follow the specific pressure relief procedure in your spray gun and/or fluid supply equipment manuals.

1. Close the main air shut-off valve.
2. Trigger the gun or dispense valve and open any drain valves to relieve pressure.


Maintenance

-  • Relieve the pressure before cleaning, checking or repairing. Follow **Pressure Relief Procedure**, above.
- Check system at least once per shift to ensure proper drainage.
- A supply of low flow/low humidity air will provide longer desiccant life.

Air Filter 234402

To maintain maximum filtering efficiency and avoid excessive pressure drop, the filter must be kept clean. See Manual 309919 for cleaning and parts information.


Coalescer 234403

-  It is recommended that Air Filter 234402 be installed upstream of the coalescing filter to remove 5 micron and larger size particles and separate large droplets of moisture from the air line.


CAUTION
Never let the liquid level in the bowl reach the base of the coalescing element.

See Manual 309919 for operation, cleaning, and parts information.

Desiccant Housing 234404

 Always install a moisture filter, to remove bulk fluids, and a coalescing filter, to remove oil, upstream of the desiccant housing. Desiccant coated with oil will not absorb moisture.

Desiccant Changeout

 Desiccant beads are non-toxic and non-flammable.


The desiccant beads (blue gel) gradually turn pink, indicating it has absorbed moisture to the saturation point and needs to be regenerated or replaced.

- To regenerate Silica Gel desiccant, heat desiccant for 4 hours at 275°F.
- To replace desiccant, order part no. 288810.

Desiccant Housing Disassembly

1. Follow the **Pressure Relief Procedure**, page 6.
2. Unscrew the metal collar holding the desiccant bowl to cover. Remove bowl and collar.
3. Dump old desiccant out of bowl.
4. If the pressure drop across the dryer has become unacceptable, the bronze element in the bottom of the bowl may be clogged. To remove clog:
 - a. Place a blow gun at the top of the tube and blow air through the flow tube.
 - b. If element replacement is needed: disassemble flow tube from the bowl by removing the end cap and nut from the bottom of the bowl.
 - c. Turn the flow tube (hand tight) counter clockwise to remove it, then replace elements.
 - d. Reassemble in reverse order.
5. Refill bowl with new or regenerated desiccant. See **Desiccant Changeout**. Desiccant Housing 234404 holds 5 lb. of desiccant.

6. Reassemble bowl to cover, making sure that o-ring 289186 is in place in cover.



Part No.	Description
288793	Flow Tube Assy., includes flow tube, nut, o-ring, filter elements and retainers
289186	O-Ring
288794	Gasket
289189	O-Ring
289187	Filter Element
289188	O-Ring
288795	Sight Glass
288810	Desiccant



Self-Relieving Air Regulator 288787

Be sure air to the regulator is clean. Erratic operation or loss of regulation is usually caused by dirt in the regulator.

Cleaning

1. Follow the **Pressure Relief Procedure**, page 6.
2. Remove bottom plug, spring, and valve.
3. Remove six screws, and separate regulator body.
4. Clean all parts with denatured alcohol. Wipe off seat and blow out body.
5. Inspect parts for damage and replace as needed. To replace the valve and diaphragm, order Repair Kit 288796.
6. Reassemble parts and screw them into the regulator before tightening the bottom plug. Make sure the valve, diaphragm and spring are center aligned.

Air Regulator Assembly for Desiccant Air Drying System



Part No.	Description
100960	Air Pressure Gauge
289149	Plug
288796	Diaphragm/Valve Repair Kit
289190	T-handle Adjusting Screw
289191	Spring
288797	Nipple, 3/8 in. x 3/8 in.
289165	Shut-off Valve

[illegible]

Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Phone Numbers

TO PLACE AN ORDER, contact your Graco distributor or call to identify the nearest distributor.

Phone: 612-623-6921 **or Toll Free:** 1-800-328-0211, **Fax:** 612-378-3505

*All written and visual data contained in this document reflects the latest product information available at the time of publication.
Graco reserves the right to make changes at any time without notice.*

This manual contains English. MM 309921

Graco Headquarters: Minneapolis
International Offices: Belgium, China, Japan, Korea

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441

www.graco.com

309921 6/2003 Revised 05/2007