

# Instructions – Parts List



WALL MOUNT OR FLOOR STAND, HIGH-FLO®


## Viscount II® 300 and 400, Circulation Packages

310570 Rev.B



**Read warnings and instructions.**

See page 2 for table of contents and list of models.



TI1045

### Related Manuals:

307107 Back Pressure Valve

307628 Low-Pressure Ball Valves

307707 Surge Tanks

308048 Quiet Viscount II Hydraulic Motor

308115 Back Pressure Regulators

309136 High-Flo Plus Pumps

PROVEN QUALITY. LEADING TECHNOLOGY.

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441  
Copyright 2001, Graco Inc. is registered to I.S. EN ISO 9001



# Table of Contents

List of Models .....	2	Troubleshooting .....	14
Warnings .....	3	Parts .....	16
Component Identification .....	5	Technical Data .....	22
Setup .....	6	Dimensions .....	24
Operation .....	10	Mounting Hole Layouts .....	25
Maintenance .....	13	Graco Warranty .....	26

## List of Models

Model	Pump	Description – Pump Model	Maximum Fluid Working Pressure	Maximum Hydraulic Supply Pressure	Parts Page
96A390	Viscount II	Right Hand Pump Mount High Flo Plus™ 300	300 psi (2.1 MPa, 21 bar)	1500 psi (10.3 MPa, 103 bar)	16
96A897	Viscount II	Right Hand Pump Mount High Flo Plus™ 300, Low Shear	300 psi (2.1 MPa, 21 bar)	1500 psi (10.3 MPa, 103 bar)	16
96A788	Viscount II	Right Hand Pump Mount High Flo Plus™ 400	400 psi (2.8 MPa, 28 bar)	1500 psi (10.3 MPa, 103 bar)	16
96A901	Viscount II	Right Hand Pump Mount High Flo Plus™ 400, Low Shear	400 psi (2.8 MPa, 28 bar)	1500 psi (10.3 MPa, 103 bar)	16
96A645	Viscount II	Left Hand Pump Mount High Flo Plus™ 300	300 psi (2.1 MPa, 21 bar)	1500 psi (10.3 MPa, 103 bar)	18
96A898	Viscount II	Left Hand Pump Mount High Flo Plus™ 300, Low Shear	300 psi (2.1 MPa, 21 bar)	1500 psi (10.3 MPa, 103 bar)	18
96A789	Viscount II	Left Hand Pump Mount High Flo Plus™ 400	400 psi (2.8 MPa, 28 bar)	1500 psi (10.3 MPa, 103 bar)	18
96A902	Viscount II	Left Hand Pump Mount High Flo Plus™ 400, Low Shear	400 psi (2.8 MPa, 28 bar)	1500 psi (10.3 MPa, 103 bar)	18

# Symbols

## Warning Symbol



This symbol alerts you to the possibility of serious injury or death if you do not follow the instructions.

## Caution Symbol



This symbol alerts you to the possibility of damage to or destruction of equipment if you do not follow the instructions.

## WARNING



INSTRUCTIONS

### EQUIPMENT MISUSE HAZARD

Equipment misuse can cause the equipment to rupture or malfunction and result in serious injury.

- This equipment is for professional use only.
- Read all instruction manuals, tags, and labels before operating the equipment.
- Use the equipment only for its intended purpose. If you are uncertain about usage, call your Graco distributor.
- Do not alter or modify this equipment. Use only genuine Graco parts and accessories.
- Check equipment daily. Repair or replace worn or damaged parts immediately.
- Do not exceed the maximum working pressure stated on the equipment or in the **Technical Data** for your equipment. Do not exceed the maximum working pressure of the lowest rated component in your system.
- Use fluids and solvents which are compatible with the equipment wetted parts. Refer to the **Technical Data** section of all equipment manuals. Read the fluid and solvent manufacturer's warnings.
- Route hoses away from traffic areas, sharp edges, moving parts, and hot surfaces. Do not expose Graco hoses to temperatures above 180°F (82°C) or below -40°F (-40°C).
- Wear hearing protection when operating this equipment.
- Do not lift pressurized equipment.
- Comply with all applicable local, state, and national fire, electrical, and safety regulations.



### PRESSURIZED EQUIPMENT HAZARD

Spray from the gun, hose leaks, or ruptured components can splash fluid in the eyes or on the skin and cause serious injury.

- Do not point the gun at anyone or at any part of the body.
- Do not stop or deflect leaks with your hand, body, glove or rag.
- Follow the **Pressure Relief Procedure** on page 10 whenever you: are instructed to relieve pressure; stop spraying; clean, check, or service the equipment; and install or clean the spray tip.
- Tighten all fluid connections before operating the equipment.
- Check the hoses, tubes, and couplings daily. Replace worn, damaged, or loose parts immediately. Permanently coupled hoses cannot be repaired; replace the entire hose.

# WARNING



## MOVING PARTS HAZARD

Moving parts, such as the air motor piston, can pinch or amputate your fingers.

- Keep clear of all moving parts when starting or operating the pump.
- Before servicing the equipment, follow the **Pressure Relief Procedure** on page 10 to prevent the equipment from starting unexpectedly.



## FIRE AND EXPLOSION HAZARD

Improper grounding, poor ventilation, open flames or sparks can cause a hazardous condition and result in a fire or explosion and serious injury.

- Ground the equipment and the object being sprayed. Refer to **Grounding** on page 9.
- If there is any static sparking or you feel an electric shock while using this equipment, **stop spraying immediately**. Do not use the equipment until you identify and correct the problem.
- Provide fresh air ventilation to avoid the buildup of flammable fumes from solvents or the fluid being sprayed.
- Keep the spray area free of debris, including solvent, rags, and gasoline.
- Electrically disconnect all equipment in the spray area.
- Extinguish all open flames or pilot lights in the spray area.
- Do not smoke in the spray area.
- Do not turn on or off any light switch in the spray area while operating or if fumes are present.
- Do not operate a gasoline engine in the spray area.




## TOXIC FLUID HAZARD

Hazardous fluid or toxic fumes can cause serious injury or death if splashed in the eyes or on the skin, inhaled, or swallowed.

- Know the specific hazards of the fluid you are using.
- Store hazardous fluid in an approved container. Dispose of hazardous fluid according to all local, state and national guidelines.
- Always wear protective eyewear, gloves, clothing and respirator as recommended by the fluid and solvent manufacturer.

# Component Identification

- 1 Ensure that there is 5 ft (1.5 m) overhead clearance for a wall mounted system and at least 7 ft (2.1 m) for a floor mounted system.
- 2 Mount the circulation package so the top of the bracket is 4 to 5 ft (1.2 to 1.5 m) above the floor.



## KEY

A	Fluid Outlet	J	Fluid Surge Tank	V	Fluid Regulator and Gauge
B	Fluid Gauge and Dampener	N	Pump	W	Hydraulic Inlet Line Shutoff Valve
C	Fluid Gauge Ball Valve	P	Ground Wire	Z	Hydraulic Inlet
D	Fluid Filter	R	Wall Mount Frame	AA	Hydraulic Outlet
E	Filter Ball Valve	T	Fluid Return		
F	Fluid Drain Valve	U	Fluid Return Ball Valve		

Fig. 1

# Setup

## WARNING

To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** on page 10.

## Site Preparation

Fig. 1. **Relieve system pressure.** For installing any one of the packages listed in this manual, select a site with at least 5 ft (1.5 m) overhead clearance for the wall mounted systems and at least 7 ft (2.1 m) for the floor mounted systems.

Ensure that the wall is strong enough to support the weight of the circulation package and accessories, fluid, hoses, and stress caused during pump operation.

Bring a hydraulic supply line from the facility hydraulic supply (Z) to the circulation package location. Be sure all lines are properly sized and pressure-rated for the system. Use only electrically conductive hoses.

Install a hydraulic supply line shutoff valve (W) in the hydraulic line to isolate the line components for servicing.

Keep the site clear of any obstacles or debris that could interfere with the operator's movement.

Have a grounded, metal pail available for use when flushing the system.

## Supplied Components

Refer to Fig. 1.

## WARNING

A master hydraulic valve (W) and a fluid drain valve (F) are supplied. These components help reduce the risk of serious injury, including splashing of fluid in the eyes or on the skin, and injury from moving parts if you are adjusting or repairing the pump.

The master hydraulic valve shuts off the hydraulic supply from the facility.

The fluid drain valve assists in relieving fluid pressure in the displacement pump, fluid filter, hose, and gun. Triggering the gun to relieve pressure may not be sufficient.

- **The hydraulic supply line shutoff valve (W)** is required in your system to isolate the line components for servicing. (See the preceding **WARNING**.)
- **The fluid drain valve (F)**, is mounted on the bottom of the fluid filter bowl. The fluid drain valve is required in your system to relieve fluid pressure in the displacement pump, fluid filter, and surge tank. (See the preceding **WARNING**.)
- **The pump (N)**, run by a hydraulic motor, circulates fluid throughout the system. See pump manual 309136 and hydraulic motor manual 308048 for further details.
- **The fluid filter (D)** includes a 60 mesh (250 micron) stainless steel element to filter particles from the fluid as it leaves the pump.
- **The fluid surge tank (J)** protects against surges in the fluid lines during gun use and system operation.
- **The fluid regulator and gauge (V)** controls fluid back pressure. The gauge provides a readout of the circulation system fluid pressure. See manual 307107 for further details.
- Fluid is returned to the circulation package from the system through the **fluid return ball valve (U)**. See valve manual 307628 for further details.

# Setup

## WARNING

To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** on page 10.

### Wall Mount installation of the Circulation Package

Fig. 1. The circulation package consists of the pump mounted on the wall mount frame. Also on the wall mount frame are hydraulic valves and controls, surge tank, fluid filter, and plumbing.

**NOTE:** Ensure that there is 5 ft (1.5 m) overhead clearance for a wall mounted system.

**NOTE:** Refer to Fig. 1, and to the Dimension drawing on page 24 and the Mounting Hole Layout on page 25.

1. **Relieve system pressure** prior to installation of circulation package. Follow **Pressure Relief Procedure** on page 10.
2. Ensure that wall is strong enough to support weight of circulation package, accessories, fluid plumbing, and stress caused during pump operation.
3. Using capable hoist, position wall mount frame (R) so that the top edge is 4 to 5 ft (1.2 to 1.5 m) above floor. Check that wall mount frame is level. Mark four holes on wall for each of four wall mount feet.
4. Drill holes where marked on wall.

## WARNING

The wall mount frame (R) must be bolted to the wall. Do not simply hang the wall mount frame. Failure to do so may cause circulation package to fall causing equipment damage or personal injury.

5. Using capable hoist, lift circulation package back into position. Bolt wall mount frame (R) to wall. Use 1/2 in. bolts and washers to mount circulation package to wall. Use bolts that are long enough to keep wall mount frame from vibrating during operation.

### Single or Dual Floor Mount installation of the Circulation Package

Fig. 1. The circulation package consists of the pump mounted on the wall mount frame. Also on the wall mount frame are hydraulic valves and controls, surge tank, fluid filter, and plumbing.

**NOTE:** Ensure that there is 7 ft (2.1 m) overhead clearance for a floor mounted system.

**NOTE:** Refer to Fig. 1, and to the Single Mount Floor Stand drawing on page 20 or the Dual Mount drawing on page 21. Also refer to the Mounting Hole Layouts on page 25.

1. **Relieve system pressure** prior to installation of circulation package. Follow **Pressure Relief Procedure** on page 10.
2. Anchor either single or dual floor stand to floor using 1/2 in. bolts.

## WARNING

Do not attempt to mount two circulation packages on a single mount floor stand. Use dual mount stand for dual or back-to-back installations. Failure to do so can result in mount failure causing equipment damage or personal injury

3. Using capable hoist, position wall mount frame (R) so that the top edge is level with the top edge of the floor stand. For dual, use second hoist and align with dual floor stand and first circulation package.
4. Bolt single unit or dual units to floor stand using 3/8 in. hardware.

# Setup

## Connect the Fluid Lines

Fig. 1. Connect system fluid supply line to the circulation package at fluid outlet (A). Close filter ball valves (E) to isolate the circulation package from the main fluid supply line.


Connect circulation package to the system fluid return line at fluid return (T). Close fluid return valve (U) to isolate the circulation package from the main fluid return line.

Bring a hydraulic supply line from the facility hydraulic supply (Z) to the circulation package location. Be sure lines are properly sized and pressure-rated for the system. Use only electrically conductive hoses.

Install a bleed-type shutoff valve (W) in the hydraulic line to isolate the components for servicing.

## Using the Quick Connectors

Fig. 2. To open a quick connector (A), loosen the captive screw (B) and open the connector. Slide the desired component into or out of the connector, close, and tighten the screw.




06278


**Fig. 2**




# Setup


## Grounding

**WARNING**

**FIRE AND EXPLOSION HAZARD**  
Before operating the circulation package, ground the system as explained below. Also read the section **FIRE AND EXPLOSION HAZARD** on page 4.



1. *Pump:* use the ground wire and clamp (A, supplied). See Fig. 3. Loosen the grounding lug locknut (W) and washer (X). Insert one end of the ground wire (A) into the slot in lug (Z) and tighten the locknut securely. Connect the ground clamp to a true earth ground.
2. *Fluid hoses:* use only electrically conductive hoses.
3. *Spray gun:* ground through connection to a properly grounded fluid hose and pump.
4. *Fluid supply container:* follow your local code.
5. *Object being sprayed:* follow your local code.
6. *Solvent pails used when flushing:* follow your local code. Use only metal pails, which are conductive, placed on a grounded surface. Do not place the pail on a nonconductive surface, such as paper or cardboard, which interrupts the grounding continuity.
7. *To maintain grounding continuity when flushing or relieving pressure,* hold a metal part of the spray gun firmly to the side of a grounded *metal* pail, then trigger the gun.



0720

**Fig. 3**

# Operation

## Pressure Relief Procedure

### **WARNING**

#### **PRESSURIZED EQUIPMENT HAZARD**

The system pressure must be manually relieved to prevent the system from starting or spraying accidentally. To reduce the risk of an injury from accidental spray from the gun, splashing fluid, or moving parts, follow the **Pressure Relief Procedure** whenever you:

- are instructed to relieve the pressure,
- stop spraying,
- check or service any of the system equipment,
- or install or clean the spray nozzle.

1. Fig. 4. Relieve the pressure of the entire system following applicable system pressure relief procedures. Ensure that system pressure is relieved before proceeding with step 2.
2. Close hydraulic supply line shutoff valve (W).
3. Trigger the gun at the last gun station to relieve fluid pressure. Maintain firm metal-to-metal contact between the gun and a grounded waste pail. Repeat for all gun stations.
4. Open the fluid drain valve (2) to relieve fluid pressure which may be trapped in the pump, plumbing, or hose.

If you suspect that pressure is not fully relieved after following the steps above, wrap a fitting near the pump outlet with a rag, and slowly and carefully loosen the fitting to relieve pressure. Be careful to protect your eyes from splashing.

## Packing Nut

Fig. 4. Before starting, fill the packing nut (AA) 1/3 full with Graco Throat Seal Liquid (TSL) or compatible solvent.

### **WARNING**


To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** at left.


The packing nut is torqued at the factory and is ready for operation. If it becomes loose and there is leaking from the throat packings, relieve pressure, then torque the nut to 34–40 N•m (25–30 ft-lb). Do this whenever necessary. Do not overtighten the packing nut.

## Flush the Circulation Package Before First Use

The circulation package is tested with lightweight oil, which is left in to protect the circulation package parts. If the fluid you are using may be contaminated by the oil, flush it out with a compatible solvent. See **Flushing** on page 13.

# Operation



 Torque packing nut (H) to 34–40 N•m (25–30 ft-lb).  
Packing nut is partially hidden.

**Fig. 4**

# Operation

## Starting and Adjusting the Pump

1. Fig. 4. Open all fluid shutoff valves (4–two) (36).
2. Open the spray gun at the last gun station and keep it open while starting the pump.
3. Open the hydraulic supply line shutoff valve (W).
4. Run the pump until all air is purged from the fluid lines.
5. Count the cycle rate of the pump.
6. Close the flow control valve until the cycle rate and fluid pressure start to drop.
7. Open the flow control valve slightly until the cycle rate and fluid pressure return to the desired level. This method of setting the hydraulic controls ensures proper pump operation and will prevent pump runaway and damage if the fluid supply runs out.
8. Adjust the fluid pressure to the lowest setting necessary to get the desired results. Higher pressures may not improve the spray pattern and will cause premature component wear.
9. To adjust the spray pattern, follow the complete instructions in your gun manual.
10. One at a time, open any other guns in the system to purge air from the lines.

**NOTE:** In a circulating system, the pump will continue to cycle as long as hydraulic fluid is supplied. In a direct supply system, the pump starts when the gun is opened, and stops when the gun is closed.

## WARNING



### COMPONENT RUPTURE HAZARD

To reduce the risk of serious injury, including splashing in the eyes or on the skin, and property damage, never exceed the maximum air/hydraulic and fluid working pressure of the lowest rated component in your system. See **EQUIPMENT MISUSE HAZARD, System Pressure**, on page 3 and **Technical Data** on page 22.

## CAUTION

Do not allow the pump to run dry. It will quickly accelerate to a high speed, causing damage. If your pump is running too fast, stop it immediately and check the fluid supply. If the container is empty and air has been pumped into the lines, refill the container and prime the pump and the lines, or flush and leave it filled with a compatible solvent. Eliminate all air from the fluid system.

## Shutdown

## WARNING

To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** on page 10.

For overnight shutdown, stop the pump at the bottom of its stroke to prevent fluid from drying on the exposed displacement rod and damaging the throat packings. **Relieve the pressure.**


Always flush the pump before the fluid dries on the displacement rod. See **Flushing** on page 13.

# Maintenance

## Preventive Maintenance Schedule

The operating conditions of your particular system determine how often maintenance is required. Establish a preventive maintenance schedule by recording when and what kind of maintenance is needed, and then determine a regular schedule for checking your system.

## Flushing

**WARNING**


**FIRE AND EXPLOSION HAZARD**  
Before flushing, read the section **FIRE AND EXPLOSION HAZARD** on page 4. Be sure the entire system and flushing pails are properly grounded. Refer to **Grounding** on page 9.

Fig. 4. Flush the pump:

- Before the first use
- When changing colors or fluids
- Before fluid can dry or settle out in a dormant pump (check the pot life of catalyzed fluids)
- Before storing the pump.

Flush with a fluid that is compatible with the fluid you are pumping and with the wetted parts in your system. Check with your fluid manufacturer or supplier for recommended flushing fluids and flushing frequency.

**WARNING**

To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** on page 10.

1. Fig. 4. Relieve the pressure.

2. Remove the air cap and spray tip from the gun. See the gun manual.
3. Fig. 4. Remove the filter element from the fluid filter (8). Reinstall the filter bowl.
4. Hold a metal part of the gun firmly to the side of a grounded *metal* pail.
5. Start the pump. Always use the lowest possible fluid pressure when flushing.
6. Trigger the gun. Flush the system until clear solvent flows from the gun.
7. Release the gun trigger and lock the trigger safety. The pump will continue to cycle as long as air is supplied.
8. Direct drain hose into a waste container. Continue flushing until clear fluid comes from the hose.
9. Relieve the pressure.
10. Clean the air cap, spray tip, and fluid filter element separately, then reinstall them.

## Fluid Filter Service

**WARNING**

To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** on page 10.

1. Fig. 4. Relieve the pressure.
2. Replace the fluid filter as required to maximize filtering efficiency and to avoid excessive pressure drop.
3. Close two filter ball valves (4). Open filter drain valve (2) and partially loosen filter top to allow fluid in filter to drain into waste container.
4. Install new filter, close filter drain valve (2) and open filter ball valves (4).

# Troubleshooting

## **WARNING**



To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** (page 10).


For pump service see manual 309136. For hydraulic motor service see manual 308048.

Problem	Cause(s)	Solution(s)
Pump output low on both strokes	Restricted hydraulic lines	Clear any obstructions; be sure all valves are open; increase pressure.
	Empty fluid supply	Refill and reprime pump. In an air-powered system, use pump runaway valve.
	Clogged fluid outlet line, valves, etc.	Clear.
	Worn packings	Tighten packing nut; replace all packings. See 309136.
Pump output low on only one stroke	Held open or worn check valve	Check and repair. See 309136.
	Worn piston packings	Replace. See 309136.
No output	Improperly installed ball check valves	Check and correct. See 309136.
Pump operates erratically	Exhausted fluid supply	Refill and reprime pump. In an air-powered system, use pump runaway valve.
	Held open or worn check valves	Check and repair. See 309136.
	Worn piston packings	Replace. See 309136.
Pump does not operate	Restricted hydraulic power supply lines	Clear any obstructions; be sure all shut-off valves are open; increase pressure.
	Exhausted fluid supply	Refill and reprime pump.
	Clogged fluid outlet line, valves, etc.	Clear.
	Damaged hydraulic motor	See 308048.
	Fluid dried on piston rod	Disassemble and clean pump. Stop pump at bottom of stroke. See 309136.

## This image shows a full page of blank, lined paper. It features approximately 20 evenly spaced horizontal grey lines across the entire width of the page, providing a guide for writing. The background is a clean, solid white color. There are no margins, text, or other markings present.

# Parts

**Right Hand Mount Models: 96A390, 96A897, 96A788, 96A901  
300 and 400, Viscount II Pumps**



**Model 96A390 Shown**




# Parts

## Right Hand Mount Models: 96A390, 96A897, 96A788, 96A901 300 and 400, Viscount II Pumps

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
1	515571	GAUGE and DAMPENER, sst	2	36	515551	VALVE, double union, sst, 1" npt	1
2	237528	BALL VALVE, sst, 1/4" npt	2	37	516772	NIPPLE, sst, 1" x 4"	1
		See 307628 for parts		38	208997	REGULATOR, standard, sst	1
3	516036	ELBOW, street, 90°, sst, 1/4" npt	1			(used on 96A390 and 96A788)	
4	515564	BALL VALVE, sst, 1-1/2" npt	2			See 307107 for parts	
5	51A297	CLAMP, sanitary, sst, 1-1/2"	9		224486	REGULATOR, low shear, sst	1
6	51A306	GASKET, sanitary, Teflon, 1-1/2"	9			(used on 96A897 and 96A901)	
7	618095	BRACKET, pipe support, 1"	1			See 307107 for parts	
8	916367	FILTER, model 12, sst, 1-1/2"	1	39	515992	BUSHING, reducer, sst, 1-1/4x1" npt	2
9	618096	HEADER, filter discharge, 1-1/2"	1			(used on 96A390 and 96A788)	
10	618098	HEADER, discharge, 1-1/2 x 1-1/4"	1		516306	BUSHING, reducer, sst, 1-1/2x1" npt	2
11	917069	KIT, installation	1			(used on 96A897 and 96A901)	
13	238985	TANK, surge, 1-1/2"	1	40	516037	ELBOW, street, 90°, sst, 1-1/4" npt	2
		See 307707 for parts		41	515983	BUSHING, reducer, sst, 2x1-1/4" npt	2
14	180783	BRACKET, angle	3	42	51B289	ADAPTER, 1-1/4 npt x 1.5"	1
15	51A796	ELBOW, 90°, sst, 1-1/2"	1	43	516582	SCREW, hex hd, 5/8 x 1"	3
16	51B381	HOSE, material, 1-1/2 x 4"	1	44	100128	WASHER, lock, 5/8"	3
17	100057	SCREW, hex hd, 5/16 x 18-3/4"	2	45	100127	NUT, hex, 5/8"	3
18	100214	WASHER, lock, 5/16"	2	52	100469	SCREW, cap, hex hd	3
30	618097	HEADER, surge tank discharge, 1-1/2"	1	53	C19199	WASHER, plain	3
31	618094	FRAME, wall mount	1	54	51B312	ADAPTER, tube, 1-1/2 x 1"	1
32	243755	PUMP, 300 Viscount II, sst	1	64	220011	GROUND WIRE ASSY, 25 ft	1
		(used on 96A390 and 96A897)		65	101896	TERMINAL, ring	4
		See 309136 for parts		66	112278	WRAP, tie, electrical	4
	243753	PUMP, 400 Viscount II, sst	1	67	236297	CLAMP ASSY, grounding	1
		(used on 96A788 and 96A901)		68	115248	SCREW, cap, hex hd	1
		See 309136 for parts		69	100166	NUT, full, hex	2
33	C19126	SCREW, hex hd, 3/8 x 1-3/4"	4	70	100718	WASHER	2
34	C19213	WASHER, lock, 3/8"	4	71	220089	CONDUCTOR, ground	1
35	100307	NUT, hex, 3/8"	4	72	065136	WIRE, copper, electrical	1

# Parts

**Left Hand Mount Models: 96A645, 96A898, 96A789, 96A902  
300 and 400, Viscount II Pumps**



**Model 96A645 Shown**



# Parts

## Left Hand Mount Models: 96A645, 96A898, 96A789, 96A902 300 and 400, Viscount II Pumps

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
1	515571	GAUGE and DAMPENER, sst	2	36	515551	VALVE, double union, sst, 1" npt	1
2	237528	BALL VALVE, sst, 1/4" npt	2	37	516772	NIPPLE, sst, 1" x 4"	1
		See 307628 for parts		38	208997	REGULATOR, standard, sst	1
3	516036	ELBOW, street, 90°, sst, 1/4" npt	1			(used on 96A645 and 96A789)	
4	515564	BALL VALVE, sst, 1-1/2" npt	2			See 307107 for parts	
5	51A297	CLAMP, sanitary, sst, 1-1/2"	9		224486	REGULATOR, low shear, sst	1
6	51A306	GASKET, sanitary, Teflon, 1-1/2"	9			(used on 96A898 and 96A902)	
7	618095	BRACKET, pipe support, 1"	1			See 307107 for parts	
8	916367	FILTER, model 12, sst, 1-1/2"	1	39	515992	BUSHING, reducer, sst, 1-1/4x1" npt	2
9	618096	HEADER, filter discharge, 1-1/2"	1			(used on 96A645 and 96A789)	
10	618098	HEADER, discharge, 1-1/2 x 1-1/4"	1		516306	BUSHING, reducer, sst, 1-1/2x1" npt	2
11	917074	KIT, installation	1			(used on 96A898 and 96A902)	
13	238985	TANK, surge, 1-1/2"	1	40	516037	ELBOW, street, 90°, sst, 1-1/4" npt	2
		See 307707 for parts		41	515983	BUSHING, reducer, sst, 2x1-1/4" npt	2
14	180783	BRACKET, angle	3	42	51B289	ADAPTER, 1-1/4 npt x 1.5"	1
15	51A796	ELBOW, 90°, sst, 1-1/2"	1	43	516582	SCREW, hex hd, 5/8 x 1"	3
16	51B381	HOSE, material, 1-1/2 x 4"	1	44	100128	WASHER, lock, 5/8"	3
17	100057	SCREW, hex hd, 5/16 x 18-3/4"	2	45	100127	NUT, hex, 5/8"	3
18	100214	WASHER, lock, 5/16"	2	52	100469	SCREW, cap, hex hd	3
30	618097	HEADER, surge tank discharge, 1-1/2"	1	53	C19199	WASHER, plain	3
31	618237	FRAME, wall mount	1	54	51B312	ADAPTER, tube, 1-1/2 x 1"	1
32	243755	PUMP, 300 Viscount II, sst	1	64	220011	GROUND WIRE ASSY, 25 ft	1
		(used on 96A645 and 96A898)		65	101896	TERMINAL, ring	4
		See 309136 for parts		66	112278	WRAP, tie, electrical	4
	243753	PUMP, 400 Viscount II, sst	1	67	236297	CLAMP ASSY, grounding	1
		(used on 96A789 and 96A902)		68	115248	SCREW, cap, hex hd	1
		See 309136 for parts		69	100166	NUT, full, hex	2
33	C19126	SCREW, hex hd, 3/8 x 1-3/4"	4	70	100718	WASHER	2
34	C19213	WASHER, lock, 3/8"	4	71	220089	CONDUCTOR, ground	1
35	100307	NUT, hex, 3/8"	4	72	065136	WIRE, copper, electrical	1

# Parts




## Single Mount Floor Stand, Model 618122



**Model 618122**

# Parts

## Dual Mount Floor Stand, Model 618123



Model 618123

# Technical Data

## Viscount II 300 Pumps, Models 96A390, 96A645, 96A897, and 96A898

Category	Data
Maximum Fluid Working Pressure	2.1 MPa, 21 bar (300 psi)
Maximum Hydraulic Fluid Pressure	10.3 MPa, 103 bar (1500 psi)
Fluid Flow at 60 Cycles per Minute	237 liter/min (63 gpm)
Cycles Per Liter (gallon)	0.24 (0.93)
Maximum Recommended Pump Speed	60 cycles per minute
Maximum Hydraulic Motor Fluid Temperature	54°C (134°F)
Wetted parts	Stainless Steel, Teflon®, Ultra High Molecular Weight Polyethylene

Teflon® and Viton® are registered trademarks of the Du Pont Co.

### Performance Charts



**To find Fluid Outlet Pressure** (psi/MPa/bar) at a specific fluid flow (lpm/gpm) and operating hydraulic pressure (psi/MPa/bar):

1. Locate desired flow along bottom of chart.
2. Follow vertical line up to intersection with selected fluid outlet pressure curve (black). Follow left to scale to read fluid outlet pressure.

**To find Motor Hydraulic Oil Consumption** (l/min or gpm) at a specific fluid flow (l/min or gpm):

1. Locate desired flow along bottom of chart.
2. Read vertical line up to intersection with hydraulic oil consumption curve (dashes). Follow left to scale to read hydraulic oil consumption.

- A** 10.3 MPa, 103 bar (1500 psi) hydraulic pressure  
**B** 7.2 MPa, 72.4 bar (1050 psi) hydraulic pressure  
**C** 4.1 MPa, 41 bar (600 psi) hydraulic pressure



# Technical Data

## Viscount II 400 Pumps, Models Models 96A788, 96A789, 96A901, and 96A902

Category	Data
Maximum Fluid Working Pressure	2.8 MPa, 28 bar (400 psi)
Maximum Hydraulic Fluid Pressure	10.3 MPa, 103 bar (1500 psi)
Fluid Flow at 60 Cycles per Minute	178 liter/min (47 gpm)
Cycles Per Liter (gallon)	0.34 (1.3)
Maximum Recommended Pump Speed	60 cycles per minute
Maximum Hydraulic Motor Fluid Temperature	54°C (134°F)
Wetted parts	Stainless Steel, Teflon®, Ultra High Molecular Weight Polyethylene

Teflon® and Vitor® are registered trademarks of the Du Pont Co.

### Performance Charts



**To find Fluid Outlet Pressure** (psi/MPa/bar) at a specific fluid flow (lpm/gpm) and operating hydraulic pressure (psi/MPa/bar):

1. Locate desired flow along bottom of chart.
2. Follow vertical line up to intersection with selected fluid outlet pressure curve (black). Follow left to scale to read fluid outlet pressure.

**To find Motor Hydraulic Oil Consumption** (l/min or gpm) at a specific fluid flow (l/min or gpm):

1. Locate desired flow along bottom of chart.
2. Read vertical line up to intersection with hydraulic oil consumption curve (dashes). Follow left to scale to read hydraulic oil consumption.


- A 10.3 MPa, 103 bar (1500 psi) hydraulic pressure  
 B 7.2 MPa, 72.4 bar (1050 psi) hydraulic pressure  
 C 4.1 MPa, 41 bar (600 psi) hydraulic pressure



# Dimensions



1 Ensure that there is 5 ft (1.5 m) overhead clearance for wall mounted systems and at least 7 ft (2.1 m) for floor mounted systems.


2 Mount the circulation package so the top of the bracket is 4 to 5 ft (1.2 to 1.5 m) above the floor.





# Mounting Hole Layout

-  Check that the wall frame is level before bolting it to the wall.
-  Mount the wall frame so the top edge is 4 to 5 ft (1.2 to 1.5 m) above the floor.



**Wall Frame 618094 (right hand mount )  
or 618237 (left hand mount)**

# Graco Standard Warranty

Graco warrants all equipment manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale by an authorized Graco distributor to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

**THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.**

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

Graco makes no warranty, and disclaims all implied warranties of merchantability and fitness for a particular purpose in connection with accessories, equipment, materials or components sold but not manufactured by Graco. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

## **FOR GRACO CANADA CUSTOMERS**

The parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

# Graco Information

**TO PLACE AN ORDER**, contact your Graco distributor, or call one of the following numbers to identify the distributor closest to you:

**1-800-367-4023 Toll Free**

**612-623-6921**

**612-378-3505 Fax**

*All written and visual data contained in this document reflects the latest product information available at the time of publication.  
Graco reserves the right to make changes at any time without notice.*

**Sales Offices:** Minneapolis, Detroit  
**International Offices:** Belgium, Korea, Hong Kong, Japan

**GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441**

**[www.graco.com](http://www.graco.com)**

PRINTED IN USA 310570 10/2001 Revised 05/2003