

# **X**TREME™ **Mix 185**

310666 rev.G

## Plural Component Proportioner




### Important Safety Instructions

Read all warnings and instructions in this manual.  
Save these instructions.


See page 3 for model information, including maximum working pressure and approvals.

### Non-heated Units



TI4912b

### Heated Units



TI5112a

PROVEN QUALITY. LEADING TECHNOLOGY.

# Contents

|  |           |  |           |
|--|-----------|--|-----------|
| <b>Manual Conventions</b> .....            | <b>2</b>  | <b>Electrical Schematic</b> .....                  | <b>22</b> |
| <b>Xtreme Mix 185 Models</b> .....         | <b>3</b>  | <b>Main Control Board Schematic</b> .....          | <b>23</b> |
| <b>Related Manuals</b> .....               | <b>4</b>  | <b>Parts</b> .....                                 | <b>25</b> |
| <b>Warnings</b> .....                      | <b>5</b>  | Part No. 234616, 3, Non-heated, Intrinsically Safe |           |
| <b>Warning</b> .....                       | <b>5</b>  | 25   |           |
| <b>Pressure Relief Procedure</b> .....     | <b>7</b>  | Part No. 234617, Xtreme Mix 185, Non-heated,       |           |
| Fluid Manifold to Gun .....                | 7         | Non-intrinsically Safe .....                       | 25        |
| Pump to Fluid Manifold .....               | 8         | Part No. 234614, Xtreme Mix 185, Non-heated, Wall  |           |
| <b>Maintenance</b> .....                   | <b>9</b>  | Mount, Intrinsically Safe .....                    | 30        |
| Preventive Maintenance Schedule .....      | 9         | Part No. 234615, Xtreme Mix 185, Non-heated, Wall  |           |
| Mix Manifold .....                         | 9         | Mount, Non-intrinsically Safe .....                | 30        |
| Dispense Valve .....                       | 9         | Part No. 234838, Xtreme Mix 185, 240V Heaters,     |           |
| Pump .....                                 | 9         | Intrinsically Safe .....                           | 33        |
| Turbine Alternator .....                   | 9         | Part No. 234839, Xtreme Mix 185, 240V Heaters,     |           |
| Air Filters .....                          | 9         | Non-intrinsically Safe .....                       | 33        |
| Pump Test/Meter Calibration .....          | 9         | Part No. 234840, Xtreme Mix 185, 480V Heaters,     |           |
| Wet Cup .....                              | 9         | Intrinsically Safe .....                           | 33        |
| Storage .....                              | 9         | Part No. 234841, Xtreme Mix 185, 480V Heaters,     |           |
| Icing .....                                | 9         | Non-intrinsically Safe .....                       | 33        |
| <b>Troubleshooting</b> .....               | <b>10</b> | Tube Connections, Non-heated Units .....           | 39        |
| <b>Alarms</b> .....                        | <b>13</b> | Tube Connections, Heated Units .....               | 40        |
| <b>Repair</b> .....                        | <b>15</b> | Pneumatic Schematic .....                          | 41        |
| Replacing Air Filter Element .....         | 15        | 248270 Pneumatic Control .....                     | 42        |
| User Interface .....                       | 16        | 234621 User Interface .....                        | 44        |
| Pneumatic Control .....                    | 19        | 287230 Pump Air Control .....                      | 45        |
| Dispense Valve/Mix Manifold Assembly ..... | 21        | <b>Technical Data</b> .....                        | <b>47</b> |
| Pump Assembly .....                        | 21        | <b>Graco Standard Warranty</b> .....               | <b>48</b> |
|  |           | <b>Graco Information</b> .....                     | <b>48</b> |

## Manual Conventions

**WARNING**

**WARNING** indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

Warnings included in instructions generally have a symbol indicating the hazard. Follow the instructions and read the hazard section on warning pages 5 to 6 for additional information.

**CAUTION**

**CAUTION** indicates a potentially hazardous situation which, if not avoided, may result in property damage or destruction of equipment.

**Note**


A note indicates additional helpful information.

# Xtreme Mix 185 Models

## WARNING



Do not install equipment approved only for non-hazardous location in a hazardous area. Substitution of components may impair intrinsic safety and cause personal injury. Read page 5.

| Approved for Hazardous Location<br>Class I, Div 1, Group D (North America); Class I, Zones 1 and 2 (Europe) |        |  |   |  |
|---|--------|--|---|--|
| Non-heated Units  |        |  |   |  |
| Xtreme Mix 185 Part No.   | Series | Description  | Maximum Working Pressure psi (MPa, bar) | Approvals  |
| 234614  | A      | Wall mount, HydraMix 700 carbon steel Pumps, with hose and gun   | 4700 (32, 324)                          | <br>APPROVED<br>Conforms to FM std 3600 & 3610 for use in Class I Div 1 Group D T3 Hazardous Locations<br><br><br><br><br>ISSeP 04 ATEX 020X<br>EEx ia p IIA T3<br><br><br>CAN/CSA<br>22.2 No. 157-92 & No. 1010.1-92    |
| 234616  | A      | Cart mount, HydraMix 700 carbon steel Pumps, with hose and gun   | 4700 (32, 324)                          |  |
| Heated Units  |        |  |   |  |
| 234838  | A      | Cart mount, HydraMix 700 carbon steel Pumps, 240V Heaters (16.2 A each, 32.4 A total), with hose and gun | 4700 (32, 324)                          | <br>APPROVED<br>Conforms to FM std 3600 & 3610 for use in Class I Div 1 Group D T2 Hazardous Locations<br><br><br><br><br>ISSeP04ATEX098X<br>EEx ia p d IIA T2<br><br><br>CAN/CSA<br>22.2 No. 157-92 & No. 1010.1-92 |
| 234840  | A      | Cart mount, HydraMix 700 carbon steel Pumps, 480V Heaters (8.3 A each, 16.6 A total), with hose and gun  | 4700 (32, 324)                          |  |

Continued on page 4.

| Approved for Non-hazardous Location |   |  |                |  |
|-------------------------------------|---|--|----------------|--|
| 234615                              | A | Wall mount, HydraMix 700 carbon steel Pumps, Non-heated, with hose and gun                               | 4700 (32, 324) |  <p>Conforms to UL std 61010A-1<br/>CSA std C22.2 No. 1010.1-92</p> |
| 234617                              | A | Cart mount, HydraMix 700 carbon steel Pumps, Non-heated, with hose and gun                               | 4700 (32, 324) |  |
| 234839                              | A | Cart mount, HydraMix 700 carbon steel Pumps, 240V Heaters (16.2 A each, 32.4 A total), with hose and gun | 4700 (32, 324) |  |
| 234841                              | A | Cart mount, HydraMix 700 carbon steel Pumps, 480V Heaters (8.3 A each, 16.6 A total), with hose and gun  | 4700 (32, 324) |  |

## Related Manuals

### Component Manuals in English

| Manual | Description                   |
|--------|-------------------------------|
| 310665 | Xtreme Mix 185 Operation      |
| 310666 | Xtreme Mix 185 Repair-Parts   |
| 310654 | Fluid Mix Manifold            |
| 310655 | Dispense Valve                |
| 310662 | Displacement Pumps            |
| 310672 | HydraMix Pumps                |
| 310673 | Circulation Kits              |
| 310675 | AC Power Supply               |
| 310676 | Remote Manifold Kit           |
| 310677 | Heater Installation Kit       |
| 310678 | TSL Pump Kits                 |
| 309192 | ISO Supply Kit                |
| 310743 | XTR™ Airless Spray Gun        |
| 309524 | VISCON HP Heater              |
| 309623 | Data Download Kits            |
| 308034 | Turbine Alternator Repair Kit |

### This manual available in the following languages:

| Manual | Language |
|--------|----------|
| 310666 | English  |
| 310702 | French   |
| 310704 | Spanish  |
| 310706 | German   |
| 310708 | Korean   |
| 310710 | Chinese  |
| 310712 | Japanese |

# Warnings

The following general warnings are related to the safe setup, use, grounding, maintenance, and repair of this equipment. Additional more specific warnings may be found throughout the text of this manuals where applicable.

|  <b>WARNING</b> |  |
|--|--|
|                 | <p><b>FIRE AND EXPLOSION HAZARD</b></p> <p>Flammable fumes, such as solvent and paint fumes, in work area can ignite or explode. To help prevent fire and explosion:</p> <ul style="list-style-type: none"> <li>• Use equipment only in well ventilated area.</li> <li>• Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static arc).</li> <li>• Keep work area free of debris, including solvent, rags and gasoline.</li> <li>• Do not plug or unplug power cords or turn lights on or off when flammable fumes are present.</li> <li>• Ground equipment and conductive objects in work area.</li> <li>• Use only grounded hoses.</li> <li>• Hold gun firmly to side of grounded pail when triggering into pail.</li> <li>• If there is static sparking or you feel a shock, <b>stop operation immediately</b>. Do not use equipment until you identify and correct the problem.</li> </ul> |
|                | <p><b>SKIN INJECTION HAZARD</b></p> <p>High-pressure fluid from gun, hose leaks, or ruptured components will pierce skin. This may look like just a cut, but it is a serious injury that can result in amputation. <b>Get immediate surgical treatment.</b></p> <ul style="list-style-type: none"> <li>• Do not point gun at anyone or at any part of the body.</li> <li>• Do not put your hand over the spray tip.</li> <li>• Do not stop or deflect leaks with your hand, body, glove, or rag.</li> <li>• Do not spray without tip guard and trigger guard installed.</li> <li>• Engage trigger lock when not spraying.</li> <li>• Follow <b>Pressure Relief Procedure</b> in this manual, when you stop spraying and before cleaning, checking, or servicing equipment.</li> </ul>  |
|               | <p><b>MOVING PARTS HAZARD</b></p> <p>Moving parts can pinch or amputate fingers and other body parts.</p> <ul style="list-style-type: none"> <li>• Keep clear of moving parts.</li> <li>• Do not operate equipment with protective guards or covers removed.</li> <li>• Pressurized equipment can start without warning. Before checking, moving, or servicing equipment, follow the <b>Pressure Relief Procedure</b> in this manual. Disconnect power or air supply.</li> </ul>   |

|  <b>WARNING</b> |   |
|--|---|
|                 | <p><b>EQUIPMENT MISUSE HAZARD</b></p> <p>Misuse can cause death or serious injury.</p> <ul style="list-style-type: none"> <li>• Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See <b>Technical Data</b> in all equipment manuals.</li> <li>• Use fluids and solvents that are compatible with equipment wetted parts. See <b>Technical Data</b> in all equipment manuals. Read fluid and solvent manufacturer’s warnings.</li> <li>• Check equipment daily. Repair or replace worn or damaged parts immediately.</li> <li>• Do not alter or modify equipment.</li> <li>• For professional use only.</li> <li>• Use equipment only for its intended purpose. Call your Graco distributor for information.</li> <li>• Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces.</li> <li>• Do not use hoses to pull equipment.</li> <li>• Comply with all applicable safety regulations.</li> </ul> |
|                 | <p><b>TOXIC FLUID OR FUMES HAZARD</b></p> <p>Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed.</p> <ul style="list-style-type: none"> <li>• Read MSDS’s to know the specific hazards of the fluids you are using.</li> <li>• Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.</li> </ul>  |
|                 | <p><b>BURN HAZARD</b></p> <p>Equipment surfaces and fluid that’s heated can become very hot during operation. To avoid severe burns, do not touch hot fluid or equipment. Wait until equipment/fluid has cooled completely.</p>   |
|               | <p><b>PERSONAL PROTECTIVE EQUIPMENT</b></p> <p>You must wear appropriate protective equipment when operating, servicing, or when in the operating area of the equipment to help protect you from serious injury, including eye injury, inhalation of toxic fumes, burns, and hearing loss. This equipment includes but is not limited to:</p> <ul style="list-style-type: none"> <li>• Protective eyewear</li> <li>• Clothing and respirator as recommended by the fluid and solvent manufacturer</li> <li>• Gloves</li> <li>• Hearing protection</li> </ul>  |

# Pressure Relief Procedure

**⚠ WARNING**



Relieve pressure from fluid manifold to gun whenever you stop spraying and before servicing gun or removing spray tip.

In addition, relieve pressure from pump to fluid manifold at end of day and before cleaning, checking, or servicing pump, manifold, or fluid line accessories or transporting equipment.

Read warnings, page 5.

## Fluid Manifold to Gun

1. Engage trigger lock.



TI5049a

2. Press .

3. Disengage trigger lock.



TI5048a

4. Hold a metal part of the gun firmly to a grounded metal pail. Trigger gun to relieve pressure.



TI5046a


5. Engage trigger lock.




TI5049a

## Pump to Fluid Manifold

1. Close shutoff valves G<sup>A</sup> and G<sup>B</sup>.
2. Place waste container under sampling valves H<sup>A</sup> and H<sup>B</sup>.



3. Turn function knob to pressure relief/park .



4. Press . Indicator A comes on, and Pump A pressurizes.

5. Open sampling valve A slowly to bleed off pressure. Indicator A will stay on for 5 sec after Pump A reaches Park position, then go off.

 Pump air supply pressure must be sufficient to cause pumps to stroke to bottom-most position when function knob is set to pressure relief/park



6. Indicator B comes on and Pump B pressurizes.
7. Open sampling valve B slowly to bleed off pressure. Indicator B will stay on for 5 sec after Pump B reaches Park position, then go off.



 If both pumps are not parked after 1 min, Alarm 26 will sound.

8. Close sampling valves A and B before restarting system.

# Maintenance

## Preventive Maintenance Schedule

Establish a preventive maintenance schedule, based on the pump's repair history.

## Mix Manifold

See mix manifold manual 310654.

## Dispense Valve

See dispense valve manual 310655.

## Pump

See applicable pump manual 310671, 310672, or 310662.

## Turbine Alternator

Replace bearings every 2000 hours. See page 19.

## Air Filters

Check daily. Drain and clean as necessary. See page 15.

## Pump Test/Meter Calibration

See Xtreme Mix 185 Operation manual. If pumps/meters fail test, see **Troubleshooting**, page 10.

## Wet Cup

Check pump and dispense valve wet-cups daily. Keep filled with Graco Throat Seal Liquid (TSL), Part No. 206995.

## Storage


Before storing the pump, always flush it, see Xtreme Mix 185 Operation manual. Relieve the pressure, page 7.

## Icing

If you experience icing at the pump air manifold:

- Reduce pump input air pressure below 80 psi (0.56 MPa, 5.6 bar), if required spray pressure allows.
- Reduce moisture in compressed air supply, or use heated air.

If icing persists, see table below.

| Problem                                | Solution   |  <p style="text-align: right; font-size: small;">T15294a</p> |
|--|--|---|
| Pump slows on both up and down stroke. | Turn D port bleed screw 60° (1/6 turn) counter-clockwise, to bleed 1 cfm air to melt ice.  |   |
| Pump slows on down stroke.             | Turn D port bleed screw 60° (1/6 turn) counter-clockwise, to bleed 1 cfm air to melt ice. If icing continues, turn screw to 90° (1/4 turn) to increase air flow to 2 cfm. If necessary, increase air flow to 3 cfm by turning screw to 270° (3/4 turn). Do not exceed 3 cfm (3/4 turn maximum).  |   |
| Pump slows on up stroke.               | Turn U port bleed screw 90° (1/4 turn) counter-clockwise, to bleed 1 cfm air to melt ice. If icing continues, turn screw to 120° (1/3 turn) to increase air flow to 2 cfm. If necessary, increase air flow to 3 cfm by turning screw to 180° (1/2 turn). Do not exceed 3 cfm (1/2 turn maximum). |   |

# Troubleshooting

 **WARNING**

Read warnings, page 5-6.

 If an alarm code displays, see page 13.

| Problem                                | Cause                                      | Solution  |
|--|--|---|
| Display not lit.<br>No electric power. | Air valve not turned on.                   | Turn on main air valve to system.   |
|  | Air supply pressure too low.               | Increase pressure to 60 psi (0.42 MPa, 4.2 bar) or greater.   |
|  | Air supply filters plugged.                | Clean filter bowls; replace filter elements. Page 15.   |
|  | Turbine air regulator set too low.         | Adjust to proper setting.   |
|  | Turbine alternator failure.                | Repair or replace turbine. Page 19.   |
|  | Power supply not connected to main board.  | Check power connections to main board. See <b>Electrical Schematic</b> , page 22.   |
|  | Main board not connected to display board. | Check electrical connections between display and main board. See <b>Electrical Schematic</b> , page 22, and <b>Main Control Board Schematic</b> , page 23.  |
| Pumps do not run.                      | Display board failure.                     | Replace display board. Page 18.   |
|  | Air pressure to pumps too low.             | Increase pressure to 50 psi (0.35 MPa, 3.5 bar).  |
|  | Solenoid valve stuck.                      | Actuate solenoid manually, if it does not operate, replace solenoid. Page 20.   |
| Pump test volume is not correct.       | Dispense valve(s) not opening.             | Service or replace valve(s). See 310655.  |
|  | Air pressure to pumps too low              | Increase pressure to 50 psi (0.35 MPa, 3.5 bar).  |
|  | Sensors not functioning properly.          | Check position of sensors. See Xtreme Mix 185 Operation manual, and applicable pump manual.<br>Check board calibration and recalibrate if necessary. See Xtreme Mix 185 Operation manual.<br>Replace sensors. See pump manual 310671 or 310672. |
|  | Pump cavitating excessively.               | Check for air in lines caused by loose fitting or use of agitator.<br>Material too viscous. Use heater.   |

| Problem   | Cause  | Solution  |
|---|--|---|
| Paint does not cure consistently.                           | Ratio not set correctly.   | Check that correct ratio is set and set by volume. See Xtreme Mix 185 Operation manual.   |
|   | Material not mixing correctly.   | Test pump. Page 9.<br>Make sure mixer is clean; flush as needed. See Xtreme Mix 185 Operation manual.                               |
|   | Pump not operating correctly.  | Observe whether pumps are loading and checking correctly, if not, clean and repair pump. See displacement pump manual 310662.       |
| Poor spray pattern.   | Fluid pressure too low.  | Increase pump pressure.   |
|   | Spray tip dirty or worn.   | Relieve pressure. Clean or replace tip. Follow gun manual instructions.   |
|   | Fluid A or B filters plugged.  | Clean filters.  |
|   | Mixer or hoses partially plugged or too restrictive.                             | Inspect parts for cured material. Clean or replace, or use larger hoses and mixer.  |
| System runs erratically.                                    | Air filter(s) clogged. Replace elements.   | Clean. Replace element(s). See page 15.   |
|   | Air supply hoses undersized.   | Replace hoses with appropriate size.  |
|   | Air compressor undersized.   | Use larger air compressor.  |
|   | Air supply pressure tank undersized.   | Use larger pressure tank.   |
| Air supply relief valve opens.                              | Turbine air regulator set too high.  | Lower setting to 23-25 psi (172-241 kPa, 1.7-2.4 bar).  |
| Turbine alternator makes high-pitched whining noise.        | Turbine bearings worn. (Setting turbine air regulator too high, wears bearings.) | Replace bearings. Page 19.  |
| Display shows 88888 or unit reboots unexpectedly.           | Turbine is not supplying enough power to board.                                  | Increase turbine regulator setting to 23-25 psi (172-241 kPa, 1.7-2.4 bar).   |
|   |  | Check turbine and electrical control exhaust air for restrictions.  |
|   |  | Replace turbine bearings. Page 19.  |
| Xtreme Mix 185 does not start when start button is pressed. | Faulty start switch or wire harness.   | Check start switch and wiring harness continuity; switch is normally open circuit. See <b>Electrical Schematic</b> , page 22.       |
|   | Faulty stop switch or wiring harness.  | Check stop switch and wiring harness continuity; stop switch is normally closed circuit. See <b>Electrical Schematic</b> , page 22. |
|   | Bad I/O port on display board.   | Replace board. Page 18.   |
|   | Bad I/O port on main board.  | Replace board. Page 17.   |
| Dispense valves leaking.                                    | Loose or worn packings.  | Tighten packing nut. If leak continues, replace packings. See 310655.   |

| Problem                                     | Cause   | Solution   |
|---|---|--|
| Flow rate too low.                          | Inadequate air supply.  | Use larger CFM compressor.   |
|   | Air pressure to pumps too low.  | Increase pressure.   |
|   | Fluid A or B filters plugged.   | Clean filters.   |
|   | Spray tip too small.  | Relieve pressure. Install larger tip. Follow gun manual instructions.  |
|   | Mixer or hoses partially plugged or too restrictive.  | Inspect parts for cured material. Clean or replace, or use larger hoses and mixer.   |
|   | Insufficient dispense valve travel.   | Increase travel. See 310655.   |
|   | Shutoff valves are not fully open.  | Ensure that shutoff valves are fully open and sampling valves are closed.  |
| Pump stops after 12 cycles.                 | Knob is set to Run pump A  or B  independently. | Turn knob to spray  if spraying material. |
| Pump cycle rate slows and eventually stops. | Icing at pump air manifold.   | See <b>Icing</b> , page 9.   |

# Alarms

\* Indicates error where audible alarm sounds once briefly.

\*\* Indicates error where audible alarm sound pulses.

| Code                    | Alarm                  | Active                         | Problem   | Cause   |
|-------------------------|------------------------|--------------------------------|---|---|
| <b>Startup Errors</b>   |                        |                                |   |   |
| 01                      | Sensor Error A*        | Always                         | No signal from pump A sensor                                  | Loose cable, failed sensor or cable, failed magnet assembly                   |
| 02                      | Sensor Error B*        | Always                         | No signal from pump B sensor                                  | Loose cable, failed sensor or cable, failed magnet assembly                   |
| 03                      | Communication Error*   | Always                         | Loss of communication between main and display boards         | Loose cable, failed board   |
| <b>Operating Errors</b> |                        |                                |   |   |
| 04                      | not used               |                                |   |   |
| 05                      | not used               |                                |   |   |
| 06                      | Pump Error A**         | Spray<br>Test<br>Batch         | Pump does not stall after top change over                     | Intake valve leak   |
| 07                      | Pump Error B**         |                                | Pump cavitating excessively                                   | Air in lines caused by loose fitting or use of agitator<br>Empty fluid supply |
| 08                      | Sensor Code Error      | Always                         | Sensor values reverted to default                             | Sensor value data corrupt; board needs replacement and /or recalibration      |
| 09                      | Metering Error A**     | Spray                          | A dose too great  | Dispense valve A leak<br>Empty B fluid supply<br>Clogged flow meter           |
| 10                      | Metering Error B**     | Spray                          | B dose too great  | Dispense valve B leak<br>Empty A fluid supply<br>Clogged flow meter           |
| 11                      | Sensor Reading Low A*  | Spray<br>Test<br>Batch         | Pump stroke travels beyond sensor range at top change over    | Sensor or bracket loose   |
| 12                      | Sensor Reading Low B*  |                                |   | Sensor magnet dirty   |
| 13                      | Sensor Reading High A* | Spray<br>Test<br>Batch         | Pump stroke travels beyond sensor range at bottom change over | Sensor or bracket loose   |
| 14                      | Sensor Reading High B* |                                |   | Sensor magnet dirty   |
| 21                      | Pot Life Error         | Spray<br>first, then<br>Always | Pot life timer timed out                                      | Not enough material sprayed after last reset                                  |

| Code                                | Alarm                                     | Active | Problem  | Cause   |
|-------------------------------------|---|--------|--|---|
| <b>Operating Errors (continued)</b> |   |        |  |   |
| 22                                  | High Ratio (units with meter[s] only)     | Spray  | Mix ratio higher than Target + Tolerance                                       | Flow rate too high<br>Slow actuation of dispense valve A or B   |
| 23                                  | Low Ratio (units with meter[s] only)      | Spray  | Mix ratio lower than Target - Tolerance  | Clogged flow meter  |
| 24                                  | Dose Timeout A (units with meter[s] only) | Spray  | Air flow switch indicates more than 40 sec of air flow without dose completing | Air flow switch stuck open.   |
| 25                                  | Dose Timeout B (units with meter[s] only) |        |  | Atomizing air leak downstream of air flow switch.<br>Clogged flow meter.<br>Gun triggered without fluid (dusting parts) |
| 26                                  | Park Timeout (pump-based units only)      | Park   | Pumps not at bottom of stroke  | Sampling valves closed, or gun not triggered.   |
| <b>Testing Error</b>                |   |        |  |   |
| 15                                  | Piston packing/ball A*                    | Test   | Pump does not completely stall in up stroke                                    | Piston packing or ball check failure  |
| 16                                  | Piston packing/ball B*                    |        |  |   |
| 17                                  | Inlet Ball A*                             | Test   | Pump does not completely stall in downstroke                                   | Intake valve ball check failure   |
| 18                                  | Inlet Ball B*                             |        |  |   |
| 19                                  | Dispense Valve A*                         | Test   | Pump does not completely stall in both up and down strokes                     | Throat packing or dispense valve failure  |
| 20                                  | Dispense Valve B*                         |        |  |   |
| 27                                  | Pump Calibration Timeout A                | Run A  | Pump doesn't run through calibration.  | Sampling valves closed.   |
| 28                                  | Pump Calibration Timeout B                | Run B  |  |   |

# Repair

Flush before repairing equipment, if possible. See Xtreme Mix 185 Operation manual.

## ⚠ WARNING



Read warnings, page 5.

Follow **Pressure Relief Procedure**, page 7, if service time may exceed pot life time, before servicing fluid components, and before transporting equipment to a service area.

## Replacing Air Filter Element

There are 2 air filters on the unit: the 5 micron air manifold filter (7) and 40 micron pump air filter (9). Check filters daily and replace element as needed. Order 15D909 5 micron filter and 15D890 40 micron filter.

## ⚠ WARNING



Removing the bowl of a pressurized air filter could cause serious injury. Do not service air filter until air line is depressurized.

1. Close main air shutoff valve on air supply line and on unit.
2. Remove left side plate (21).
3. Unlock filter bowl guard and remove.
4. Unscrew filter bowl.



5. Remove and replace element.
6. Screw filter bowl on securely.
7. Reassemble.

## User Interface

### Removal

1. Close main air shutoff valve on air supply line and on unit.
2. Remove side panels (21).
3. Remove fasteners. Gently pull user interface (11) away from pneumatic control (10).




FIG. 1

4. To completely remove user interface (11), disconnect ground wire (315), and wires (416 and 406) from main control board (301). See **Electrical Schematic**, page 22.

### Software Upgrades

#### CAUTION

To avoid damaging circuit board, wear a grounding strap.

1. Remove User Interface cover. See above.
2. Use a chip remover (D) to remove software chip (C). FIG. 2.





FIG. 2

3. Install new chip (beveled corner down).
4. Reassemble.
5. Recalibrate main circuit board. See Xtreme Mix 185 Operation Manual.

## Replacing Main Circuit Board

| CAUTION  |
|--|
| To avoid damaging circuit board, wear a grounding strap. |

1. Remove User Interface cover. See page 16.
2. Disconnect all wire connectors from board (301). FIG. 3.
3. Remove four screws (302) and replace board (301).
4. Reassemble. Refer to **Electrical Schematic**, page 22.
5. Recalibrate system. See Xtreme Mix 185 Operation Manual.



TI5166a

 Third solenoid is present on heated units only.

**FIG. 3**

## Replacing Display Circuit Board

### CAUTION

To avoid damaging circuit board, wear a grounding strap.

1. Remove User Interface cover. See page 16.
2. Disconnect wires from display board (410). FIG. 4.

3. Remove two screws (411).
4. Loosen setscrew (419) from knob (405) and remove knob assembly. Remove jam nut (N).
5. Remove and replace display board (410).
6. Reassemble. Refer to **Electrical Schematic**, page 22.






FIG. 4

# Pneumatic Control

## Alternator Repair

Turbine Alternator Repair Kit 223688 is available to replace turbine bearings.

1. Remove User Interface cover. See page 16.



T15166a

 Third solenoid is present on heated units only.


**FIG. 5**

2. Disconnect power supply wires (P). FIG. 5.
3. Disconnect two air lines (310) from alternator (304). FIG. 6.
4. Remove top nut (305) and loosen bottom nut. Slide alternator up and off bottom nut.
5. Remove four screws (304d) to separate alternator housings. FIG. 7.
6. Disconnect turbine (304e) from board (A). Follow instructions in turbine kit manual 308034 to remove and repair turbine.


7. Replace gasket (304a) if damaged. Place between housings before securing with screws (304d).
8. Reassemble. Refer to **Electrical Schematic**, page 22.



- Lightly lubricate turbine o-ring before installing turbine in housing.
- Connect alternator red wire to + side and black wire to – side of main circuit board.
- Connect turbine to 3-pin connector on main circuit board.



**FIG. 6**



 Torque to 20 in-lbs (2 N•m)

**FIG. 7**

## Replacing Solenoids

Follow this procedure to replace a single solenoid.

1. Remove User Interface cover. See page 16.
2. Disconnect two solenoid wires (V) from main board. FIG. 8.
3. Disconnect pneumatic tubes from solenoid. FIG. 8.
4. Remove two screws (S).
5. Remove and replace solenoid (306b or 132).

 From left to right, solenoid functions are as follows:

- Component A
- Component B
- Circulation valves (heated units only)

6. Reassemble. Solenoid wires are polarized (red +, black -). Refer to **Electrical Schematic**, page 22.

## Replacing Alternator Regulator

1. Remove User Interface cover. See page 16.
2. Remove two screws (309) from the back of the control box.

3. Disconnect supply and exhaust air lines (310). FIG. 5, page 19.
4. Disconnect solenoid wires 12 position Phoenix connector (306r) from main board.
5. Remove solenoid module (306) with regulator (306e). FIG. 8.
6. Unscrew and replace regulator (306e).
7. Reassemble. Refer to **Electrical Schematic**, page 22.

 Make sure gaskets (306j, 306k) are in place when reinstalling solenoid module.

8. Set regulator to 24 psi (160 kPa, 1.6 bar).

## Replacing Alarm

1. Remove User Interface cover. See page 16.
2. Disconnect alarm wires from main board.
3. Unscrew alarm (313) and replace. FIG. 5, page 19.
4. Reassemble. Refer to **Electrical Schematic**, page 22.

### Dispense Valve Pilot Lines

- A1 (off), clear tube, see below  
 A2 (on), black tube, see below  
 B1 (off), green tube, see below  
 B2 (on), red tube, see below  
 R1 (circulation valves off), black tube, see page 40  
 R2 (circulation valves on), clear tube, see page 40





FIG. 8

## Dispense Valve/Mix Manifold Assembly



See the **Parts** drawing for your model.

1. Follow **Pressure Relief Procedure**, page 7.
2. Label all air and fluid lines and disconnect from fittings on manifold assembly.
3. Remove fasteners.
4. Remove mix manifold (2).
5. To repair mix manifold, see manual 310654. To repair dispense valves, see manual 310655.
6. Reassemble.


## Pump Assembly




See the **Parts** drawing for your model.

1. Follow **Pressure Relief Procedure**, page 7.
2. Remove side plates (21).
3. Remove wire harnesses from sensor and solenoids. Refer to **Electrical Schematic**, page 22.
4. Disconnect fluid inlet and outlet lines from pump lower. Disconnect air supply from pump.
5. Label all tubing and disconnect from fittings on pump assembly.
6. Remove mounting hardware and slide pump out of frame.
7. Repair as instructed in pump manuals 310671, 310672, or 310662.
8. Reassemble.

# Electrical Schematic



# Main Control Board Schematic






# Parts

Part No. 234616, 3, Non-heated, Intrinsically Safe

Part No. 234617, Xtreme Mix 185, Non-heated, Non-intrinsically Safe



T14913b

T14954c





**Part No. 234616, Xtreme Mix 185, Non-heated, Intrinsically Safe, continued**  
**Part No. 234617, Xtreme Mix 185, Non-heated, Non-intrinsically Safe, continued**


| Ref. No. | Part No. | Description  | Qty. | Ref. No. | Part No. | Description   | Qty.   |
|----------|----------|--|------|----------|----------|---|--------|
| 1        | 15D988   | FRAME, wall mount  | 1    | 38       | 113279   | PLUG, tube fitting;<br>5/32 in. (4 mm) OD tube                            | 2      |
| 2        | 234450   | MIX MANIFOLD; see 310654   | 1    | 39       | 113505   | NUT, keps, hex hd; 10-24  | 2      |
| 3        | 287230   | CONTROL, air; see page 45  | 1    | 40       | 551787   | SCREW, cap, button hd;<br>10-32 x 3/8 in. (10 mm)                         | 4      |
| 4        | 109544   | ELBOW, pipe; 3/8 npt (mbe)   | 1    | 42       | 15D998   | TUBE, fluid, A component; see<br>pages 39 and 41                          | 1      |
| 5        | 116756   | ELBOW, street, 45°;<br>3/8 npt (m x f)   | 1    | 43       | 15D999   | TUBE, fluid, B component; see<br>pages 39 and 41                          | 1      |
| 6        | 155665   | UNION, adapter; 3/8 npsm(f) x<br>3/8 npt(m)  | 1    | 44       | 114104   | SCREW, machine; 1/4-20 x<br>1-1/2 in. (38 mm)                             | 1      |
| 7        | 117629   | FILTER, air; 5 micron  | 1    | 45       | 115942   | NUT, hex, flange hd; 1/4-20   | 7      |
| 8        | 114316   | ELBOW; 3/8 npt(m) x<br>3/8 in. (10 mm) OD tube fitting   | 1    | 50       | 102656   | MUFFLER   | 2      |
| 9        | 15D795   | FILTER, air; 40 micron   | 1    | 53       | 101754   | PLUG; 3/8 npt   | 2      |
| 10       | 248270   | PNEUMATIC CONTROL;<br>see page 47  | 1    | 54       | 100721   | PLUG; 1/4 npt   | 6      |
| 11       | 234621   | USER INTERFACE; see page 44  | 1    | 56       | 598095   | TUBE; nylon; 5/32 in. (4 mm) OD;<br>clear; see pages 39 and 41            | 2 ft   |
| 12       | 273011   | PUMP; see 310672   | 1    | 57       | 054753   | TUBE; nylon; 5/32 in. (4 mm) OD;<br>black; see pages 39 and 41            | 2 ft   |
| 13       | 100361   | PLUG, pipe; 1/2 npt  | 3    | 58       | 054754   | TUBE; nylon; 5/32 in. (4 mm) OD;<br>red; see pages 39 and 41              | 2 ft   |
| 14       | 15D873   | BRACKET, support, fluid manifold   | 1    | 59       | 054757   | TUBE; nylon; 5/32 in. (4 mm) OD;<br>green; see pages 39 and 41            | 2 ft   |
| 15       | 114110   | ELBOW; 1/2 npt(m) x<br>1/2 in. (13 mm) OD tube fitting   | 3    | 61       | 061134   | TUBE; nylon; 1/2 in. (13 mm) OD;<br>see pages 39 and 41                   | 5.8 ft |
| 16       | C19038   | WASHER, lock; 1/4  | 5    | 68       | 114129   | FITTING; 3/8 npt(m) x<br>1/2 in. (13 mm) OD tube fitting                  | 1      |
| 17       | 112925   | SCREW, cap, button hd;<br>1/4-20 x 3/8 in. (10 mm)   | 5    | 69       | 100081   | BUSHING, pipe; 1/2 npt(m) x<br>3/8 npt(f)                                 | 1      |
| 18       | 155494   | ELBOW, swivel; 3/8 npt(m) x<br>3/8 npsm(f)   | 2    | 70       | 054123   | TUBE; nylon; 1/4 in. (6 mm) OD;<br>see pages 39 and 41                    | 3.5 ft |
| 19       | 156849   | NIPPLE; 3/8 npt  | 3    | 71       | 112958   | NUT, hex, flange hd; 3/8-16   | 16     |
| 20       | 103196   | SCREW, machine, phillips;<br>8-32 x 7/16 in. (11 mm)   | 4    | 72       | 116935   | SCREW, cap; 3/8-16 x<br>3 in. (76 mm)                                     | 6      |
| 21       | 15D987   | PLATE, side  | 2    | 80       | XTR704   | GUN, spray, airless; see 310743   | 1      |
| 22       | 119291   | SCREW, self-tapping  | 20   | 81       | 113436   | RING, retaining   | 3      |
| 23       | 113802   | SCREW, hex hd, flanged;<br>3/8-16 x 5/8 in. (16 mm)  | 8    | 86       | H53850   | HOSE, fluid; nylon; 3/8 in. (10<br>mm) ID; 3/8 npsm(fbe); 50 ft<br>(15 m) | 1      |
| 24       | 220598   | HOSE, air; nitrile; 1/2 in. (13 mm)<br>ID; 1/2 npt (mbe); 18 in. (457<br>mm); see also pages 39 and 41 | 1    | 87       | 15D775   | CART  | 1      |
| 25       | C19024   | ELBOW, swivel; 1/2 npt(m) x<br>1/2 npsm(f)   | 1    | 88       | 15D974   | PLATE, rear   | 1      |
| 26       | 15D607   | CABLE, sensor; see <b>Electrical<br/>Schematic</b> , page 22   | 2    | 89       | 101242   | RING, retaining   | 2      |
| 27       | 15D794   | HARNESS, connector; see <b>Elec-<br/>trical Schematic</b> , page 22                                    | 2    | 90       | 106123   | SCREW, cap, hex hd;<br>1/2-13 x 4 in. (102 mm)                            | 4      |
| 28▲      | 290331   | LABEL, warning   | 1    | 92       | 113796   | SCREW, hex hd, flange;<br>1/4-20 x 3/4 in. (19 mm)                        | 4      |
| 31       | 101765   | GROMMET  | 2    | 93       | 15C567   | BRACKET, hopper   | 2      |
| 32       | 100451   | COUPLING; 1/8 npt (fbe)  | 2    | 94       | 15D875   | BRACKET, hopper, mount  | 2      |
| 33       | 115671   | CONNECTOR; 1/8 npt(m) x<br>1/4 in. (6 mm) OD tube  | 2    | 95       | 119363   | ELBOW, swivel; 1 in. npt(m) x<br>1 in. npsm(f)                            | 2      |
| 34       | 15D966   | BRACKET, muffler   | 2    | 96       | 150287   | ADAPTER; 1/4 npt(m) x 3/8 npt(f)  | 1      |
| 35       | 15E020   | FITTING, compression; cst;<br>1/4 npt(m) x 1/2 in. (13 mm) tube  | 2    | 97       | 117366   | VALVE, ball, 3 way; 1-1/4 npt (f)   | 2      |
| 36       | 15E018   | ELBOW, compression; cst;<br>3/8 npt(m) x 1/2 in. (13 mm) tube  | 2    | 98       | 154628   | WASHER  | 3      |
| 37       | 244524   | GROUND WIRE  | 1    |          |          |   |        |

| Ref. No. | Part No. | Description   | Qty. | Ref. No. | Part No. | Description                                       | Qty. |
|----------|----------|---|------|----------|----------|---|------|
| 100      | 15A892   | BEARING, bronze   | 2    | 117      | 15B755   | SPACER  | 2    |
| 101      | 234097   | HOPPER, A component; green  | 1    | 118      | 238782   | FILTER, fluid; stainless steel;<br>30 mesh screen | 2    |
| 102      | 113807   | WHEEL   | 2    | 119      | 15A912   | AXLE  | 1    |
| 103      | 101044   | WASHER; 1/2   | 10   | 120      | 15A913   | AXLE  | 1    |
| 104      | 15E143   | SUPPORT, wheel  | 1    | 121      | 15E187   | LIFT RING   | 2    |
| 105      | 191824   | WASHER  | 4    | 122      | 100338   | NUT, jam; 1/2-13                                  | 2    |
| 106▲     | 193185   | LABEL, warning  | 2    | 123      | 113956   | BOLT, carriage; 3/8-16 x<br>1 in. (25 mm)         | 4    |
| 107      | 500054   | BUSHING, hex hd; 1 in. npt(f) x<br>1-1/4 in. npt(m)                   | 2    | 124      | 114606   | PLUG  | 4    |
| 108      | 246127   | HANDLE, cart  | 1    | 125      | 114552   | CAP, square                                       | 1    |
| 109      | H72506   | HOSE, fluid; nylon; 1/4 in. (6 mm)<br>ID; 1/4 npsm(fbe); 6 ft (1.8 m) | 1    | 126      | 15B729   | COUPLING; 3/8 npsm(m) x<br>3/8 npt(f)             | 1    |
| 110      | 511352   | MIXER, static   | 1    | 127      | 195889   | BUSHING, strain relief                            | 2    |
| 111      | 801020   | NUT, lock, hex  | 4    | 129      | 15A818   | COVER, sensor                                     | 2    |
| 112      | C19660   | BUSHING; 1-1/4 in. npt(m) x<br>1/2 npt(f)                             | 2    | 130      | C20272   | O-RING  | 2    |
| 113      | 234017   | HOPPER, B component; blue   | 1    | 131      | 15E383   | BUSHING, strain relief                            | 2    |
| 114      | 111194   | SCREW, cap, flange hd;<br>3/8-16 x 2 in. (51 mm)                      | 6    |          |          |   |      |
| 115      | 111218   | CAP, tube   | 2    |          |          |   |      |
| 116      | 113362   | WHEEL   | 2    |          |          |   |      |

▲ Replacement Danger and Warning labels, tags, and cards are available at no cost.



**Part No. 234614, Xtreme Mix 185, Non-heated, Wall Mount, Intrinsically Safe, continued**  
**Part No. 234615, Xtreme Mix 185, Non-heated, Wall Mount, Non-intrinsically Safe, continued**




**Part No. 234614, Xtreme Mix 185, Non-heated, Wall Mount, Intrinsically Safe, continued**  
**Part No. 234615, Xtreme Mix 185, Non-heated, Wall Mount, Non-intrinsically Safe, continued**


| Ref. No. | Part No. | Description  | Qty. | Ref. No. | Part No. | Description  | Qty.   |
|----------|----------|--|------|----------|----------|--|--------|
| 1        | 15D988   | FRAME, wall mount  | 1    | 39       | 113505   | NUT, keps, hex hd; 10-24   | 2      |
| 2        | 234450   | MIX MANIFOLD; see 310654   | 1    | 40       | 551787   | SCREW, cap, button hd;<br>10-32 x 3/8 in. (10 mm)                        | 4      |
| 3        | 287230   | CONTROL, air; see page 45  | 1    | 42       | 15D998   | TUBE, fluid, A component; see<br>pages 39 and 41                         | 1      |
| 4        | 109544   | ELBOW, pipe; 3/8 npt (mbe)   | 1    | 43       | 15D999   | TUBE, fluid, B component; see<br>pages 39 and 41                         | 1      |
| 5        | 116756   | ELBOW, street, 45°; 3/8 npt (mxf)  | 1    | 44       | 114104   | SCREW, machine; 1/4-20 x<br>1-1/2 in. (38 mm)                            | 1      |
| 6        | 155665   | UNION, adapter; 3/8 npsm(f) x<br>3/8 npt(m)  | 1    | 45       | 115942   | NUT, hex, flange hd; 1/4-20  | 7      |
| 7        | 117629   | FILTER, air; 5 micron  | 1    | 50       | 102656   | MUFFLER  | 2      |
| 8        | 114316   | ELBOW; 3/8 npt(m) x<br>3/8 in. (10 mm) OD tube fitting   | 1    | 53       | 101754   | PLUG; 3/8 npt  | 2      |
| 9        | 15D795   | FILTER, air; 40 micron   | 1    | 54       | 100721   | PLUG; 1/4 npt  | 6      |
| 10       | 248270   | PNEUMATIC CONTROL;<br>see page 42  | 1    | 56       | 598095   | TUBE; nylon; 5/32 in. (4 mm) OD;<br>clear; see pages 39 and 41           | 2 ft   |
| 11       | 234621   | USER INTERFACE; see page 44  | 1    | 57       | 054753   | TUBE; nylon; 5/32 in. (4 mm) OD;<br>black; see pages 39 and 41           | 2 ft   |
| 12       | 273011   | PUMP, HydraMix 700, cst;<br>see 310672   | 2    | 58       | 054754   | TUBE; nylon; 5/32 in. (4 mm) OD;<br>red; see pages 39 and 41             | 2 ft   |
| 13       | 100361   | PLUG, pipe; 1/2 npt  | 1    | 59       | 054757   | TUBE; nylon; 5/32 in. (4 mm) OD;<br>green; see pages 39 and 41           | 2 ft   |
| 14       | 15D873   | BRACKET, support, fluid manifold   | 1    | 60       | C12508   | TUBE; nylon; 3/8 in. (10 mm) OD;<br>black; see pages 39 and 41           | 0.7 ft |
| 15       | 114110   | ELBOW; 1/2 npt(m) x<br>1/2 in. (13 mm) OD tube fitting   | 3    | 61       | 061134   | TUBE; nylon; 1/2 in. (13 mm) OD;<br>see pages 39 and 41                  | 5.2 ft |
| 16       | C19038   | WASHER, lock; 1/4  | 5    | 68       | 114129   | FITTING; 3/8 npt(m) x<br>1/2 in. (13 mm) OD tube fitting                 | 1      |
| 17       | 112925   | SCREW, cap, button hd;<br>1/4-20 x 3/8 in. (10 mm)   | 5    | 69       | 100081   | BUSHING, pipe; 1/2 npt(m) x<br>3/8 npt(f)                                | 1      |
| 18       | 155494   | ELBOW, swivel; 3/8 npt(m) x<br>3/8 npsm(f)   | 2    | 70       | 054123   | TUBE; nylon; 1/4 in. (6 mm) OD;<br>see pages 39 and 41                   | 4 ft   |
| 19       | 156849   | NIPPLE; 3/8 npt  | 3    | 79       | 195889   | BUSHING, strain relief   | 2      |
| 20       | 103196   | SCREW, machine, phillips;<br>8-32 x 7/16 in. (11 mm)   | 4    | 80       | XTR704   | GUN, spray, airless; see 310743  | 1      |
| 21       | 15D987   | PLATE, side  | 2    | 86       | H53850   | HOSE, fluid; nylon; 3/8 in<br>(10 mm) ID; 3/8 npsm(fbe); 50 ft<br>(15 m) | 1      |
| 22       | 119291   | SCREW, self-tapping  | 12   | 92       | 113796   | SCREW, hex hd, flange;<br>1/4-20 x 3/4 in. (19 mm)                       | 4      |
| 23       | 113802   | SCREW, hex hd, flanged;<br>3/8-16 x 5/8 in. (16 mm)  | 8    | 96       | 165198   | NIPPLE, reducing; 1/4 npt(m) x<br>3/8 npt(m)                             | 1      |
| 24       | 220598   | HOSE, air; nitrile; 1/2 in. (13 mm)<br>ID; 1/2 npt (mbe); 18 in. (457<br>mm); see also pages 39 and 41 | 1    | 109      | H72506   | HOSE, fluid; nylon; 1/4 in. (6 mm)<br>ID; 1/4 npsm (fbe); 6 ft (1.8 m)   | 1      |
| 25       | C19024   | ELBOW, swivel; 1/2 npt(m) x<br>1/2 npsm(f)   | 1    | 110      | 511352   | MIXER, static  | 1      |
| 26       | 15D607   | CABLE, sensor; page 22   | 2    | 118      | 238782   | FILTER, fluid; sst; 30 mesh  | 2      |
| 27       | 15D794   | HARNESS, connector; page 22  | 2    | 126      | 15B729   | COUPLING; 3/8 npsm(m) x<br>3/8 npt(f)                                    | 1      |
| 28▲      | 290331   | LABEL, warning   | 1    | 129      | 15A818   | COVER, sensor  | 2      |
| 31       | 101765   | GROMMET  | 2    | 130      | C20272   | O-RING   | 2      |
| 32       | 100451   | COUPLING; 1/8 npt (fbe)  | 2    | 131      | 15E383   | BUSHING, strain relief   | 2      |
| 33       | 115671   | CONNECTOR; 1/8 npt(m) x<br>1/4 in. (6 mm) OD tube  | 2    |          |          |  |        |
| 34       | 15D966   | BRACKET, muffler   | 2    |          |          |  |        |
| 35       | 15E020   | FITTING, compression; cst;<br>1/4 npt(m) x 1/2 in. (13 mm) tube  | 2    |          |          |  |        |
| 36       | 15E018   | ELBOW, compression; cst;<br>3/8 npt(m) x 1/2 in. (13 mm) tube  | 2    |          |          |  |        |
| 37       | 244524   | GROUND WIRE  | 1    |          |          |  |        |
| 38       | 113279   | PLUG, tube fitting;<br>5/32 in. (4 mm) OD tube   | 2    |          |          |  |        |

▲ Replacement Danger and Warning labels, tags, and cards are available at no cost.

**Part No. 234838, Xtreme Mix 185, 240V Heaters, Intrinsically Safe**  
**Part No. 234839, Xtreme Mix 185, 240V Heaters, Non-intrinsically Safe**  
**Part No. 234840, Xtreme Mix 185, 480V Heaters, Intrinsically Safe**  
**Part No. 234841, Xtreme Mix 185, 480V Heaters, Non-intrinsically Safe**




T15164a




T14954c

Part No. 234838, Xtreme Mix 185, 240V Heaters, Intrinsically Safe, continued  
Part No. 234839, Xtreme Mix 185, 240V Heaters, Non-intrinsically Safe, continued  
Part No. 234840, Xtreme Mix 185, 480V Heaters, Intrinsically Safe, continued  
Part No. 234841, Xtreme Mix 185, 480V Heaters, Non-intrinsically Safe, continued




TI5297a

**Part No. 234838, Xtreme Mix 185, 240V Heaters, Intrinsically Safe, continued**  
**Part No. 234839, Xtreme Mix 185, 240V Heaters, Non-intrinsically Safe, continued**  
**Part No. 234840, Xtreme Mix 185, 480V Heaters, Intrinsically Safe, continued**  
**Part No. 234841, Xtreme Mix 185, 480V Heaters, Non-intrinsically Safe, continued**



TI4915b

Part No. 234838, Xtreme Mix 185, 240V Heaters, Intrinsically Safe, continued  
Part No. 234839, Xtreme Mix 185, 240V Heaters, Non-intrinsically Safe, continued  
Part No. 234840, Xtreme Mix 185, 480V Heaters, Intrinsically Safe, continued  
Part No. 234841, Xtreme Mix 185, 480V Heaters, Non-intrinsically Safe, continued



TI5162b

**Part No. 234838, Xtreme Mix 185, 240V Heaters, Intrinsically Safe, continued**  
**Part No. 234839, Xtreme Mix 185, 240V Heaters, Non-intrinsically Safe, continued**  
**Part No. 234840, Xtreme Mix 185, 480V Heaters, Intrinsically Safe, continued**  
**Part No. 234841, Xtreme Mix 185, 480V Heaters, Non-intrinsically Safe, continued**

| Ref. No. | Part No. | Description  | Qty. | Ref. No. | Part No. | Description   | Qty.      |
|----------|----------|--|------|----------|----------|---|-----------|
| 1        | 15D988   | FRAME, wall mount  | 1    | 38       | 113279   | PLUG, tube fitting;<br>5/32 in. (4 mm) OD tube                            | 2         |
| 2        | 234450   | MIX MANIFOLD; see 310654   | 1    | 39       | 113505   | NUT, keps, hex hd; 10-24  | 2         |
| 3        | 287230   | CONTROL, air; see page 45  | 1    | 40       | 551787   | SCREW, cap, button hd;<br>10-32 x 3/8 in. (10 mm)                         | 4         |
| 4        | 109544   | ELBOW, pipe; 3/8 npt (mbe)   | 3    | 42       | 15D998   | TUBE, fluid, A component; see<br>pages 40 and 41                          | 1         |
| 5        | 116756   | ELBOW, street, 45°;<br>3/8 npt (m x f)   | 1    | 43       | 15D999   | TUBE, fluid, B component; see<br>pages 40 and 41                          | 1         |
| 6        | 155665   | UNION, adapter; 3/8 npsm(f) x<br>3/8 npt(m)  | 1    | 44       | 114104   | SCREW, machine; 1/4-20 x<br>1-1/2 in. (38 mm)                             | 1         |
| 7        | 117629   | FILTER, air; 5 micron  | 1    | 45       | 115942   | NUT, hex, flange hd; 1/4-20   | 7         |
| 8        | 114316   | ELBOW; 3/8 npt(m) x<br>3/8 in. (10 mm) OD tube fitting   | 1    | 50       | 102656   | MUFFLER   | 2         |
| 9        | 15D795   | FILTER, air; 40 micron   | 1    | 53       | 101754   | PLUG; 3/8 npt   | 2         |
| 10       | 248270   | PNEUMATIC CONTROL;<br>see page 47  | 1    | 54       | 100721   | PLUG; 1/4 npt   | 6         |
| 11       | 234621   | USER INTERFACE; see page 44  | 1    | 56       | 598095   | TUBE; nylon; 5/32 in. (4 mm) OD;<br>clear; see pages 40 and 41            | 6.8<br>ft |
| 12       | 273011   | PUMP; see 310672   | 1    | 57       | 054753   | TUBE; nylon; 5/32 in. (4 mm) OD;<br>black; see pages 40 and 41            | 6.8<br>ft |
| 13       | 100361   | PLUG, pipe; 1/2 npt  | 3    | 58       | 054754   | TUBE; nylon; 5/32 in. (4 mm) OD;<br>red; see pages 40 and 41              | 2 ft      |
| 14       | 15D873   | BRACKET, support, fluid manifold   | 1    | 59       | 054757   | TUBE; nylon; 5/32 in. (4 mm) OD;<br>green; see pages 40 and 41            | 2 ft      |
| 15       | 114110   | ELBOW; 1/2 npt(m) x<br>1/2 in. (13 mm) OD tube fitting   | 3    | 61       | 061134   | TUBE; nylon; 1/2 in. (13 mm) OD;<br>see pages 40 and 41                   | 5.8<br>ft |
| 16       | C19038   | WASHER, lock; 1/4  | 5    | 68       | 114129   | FITTING; 3/8 npt(m) x<br>1/2 in. (13 mm) OD tube fitting                  | 1         |
| 17       | 112925   | SCREW, cap, button hd;<br>1/4-20 x 3/8 in. (10 mm)   | 5    | 69       | 100081   | BUSHING, pipe; 1/2 npt(m) x<br>3/8 npt(f)                                 | 3         |
| 18       | 155494   | ELBOW, swivel; 3/8 npt(m) x<br>3/8 npsm(f)   | 4    | 70       | 054123   | TUBE; nylon; 1/4 in. (6 mm) OD;<br>see pages 40 and 41                    | 3.5<br>ft |
| 19       | 156849   | NIPPLE; 3/8 npt  | 9    | 71       | 112958   | NUT, hex, flange hd; 3/8-16   | 16        |
| 20       | 103196   | SCREW, machine, phillips;<br>8-32 x 7/16 in. (11 mm)   | 4    | 72       | 116935   | SCREW, cap; 3/8-16 x<br>3 in. (76 mm)                                     | 6         |
| 21       | 15D987   | PLATE, side  | 2    | 80       | XTR702   | GUN, spray, airless; see 310743   | 1         |
| 22       | 119291   | SCREW, self-tapping  | 20   | 81       | 113436   | RING, retaining   | 3         |
| 23       | 113802   | SCREW, hex hd, flanged;<br>3/8-16 x 5/8 in. (16 mm)  | 8    | 86       | H53850   | HOSE, fluid; nylon; 3/8 in. (10<br>mm) ID; 3/8 npsm(fbe); 50 ft<br>(15 m) | 1         |
| 24       | 220598   | HOSE, air; nitrile; 1/2 in. (13 mm)<br>ID; 1/2 npt (mbe); 18 in. (457<br>mm); see also pages 40 and 41 | 1    | 87       | 15D775   | CART  | 1         |
| 25       | C19024   | ELBOW, swivel; 1/2 npt(m) x<br>1/2 npsm(f)   | 1    | 88       | 15D974   | PLATE, rear   | 1         |
| 26       | 15D607   | CABLE, sensor; see <b>Electrical<br/>Schematic</b> , page 22   | 2    | 89       | 101242   | RING, retaining   | 2         |
| 27       | 15D794   | HARNESS, connector; see <b>Elec-<br/>trical Schematic</b> , page 22                                    | 2    | 90       | 106123   | SCREW, cap, hex hd;<br>1/2-13 x 4 in. (102 mm)                            | 4         |
| 28▲      | 290331   | LABEL, warning   | 1    | 92       | 113796   | SCREW, hex hd, flange;<br>1/4-20 x 3/4 in. (19 mm)                        | 4         |
| 31       | 101765   | GROMMET  | 2    | 93       | 15C567   | BRACKET, hopper   | 2         |
| 32       | 100451   | COUPLING; 1/8 npt (fbe)  | 2    | 94       | 15D875   | BRACKET, hopper, mount  | 2         |
| 33       | 115671   | CONNECTOR; 1/8 npt(m) x<br>1/4 in. (6 mm) OD tube  | 2    | 95       | 119363   | ELBOW, swivel; 1 in. npt(m) x<br>1 in. npsm(f)                            | 2         |
| 34       | 15D966   | BRACKET, muffler   | 2    | 96       | 150287   | ADAPTER; 1/4 npt(m) x 3/8 npt(f)  | 1         |
| 35       | 157705   | UNION, swivel; 1/4 npt(m) x<br>3/8 npsm(f); cst  | 2    |          |          |   |           |
| 37       | 244524   | GROUND WIRE  | 1    |          |          |   |           |

Parts

| Ref. No. | Part No. | Description  | Qty. | Ref. No. | Part No. | Description   | Qty. |
|----------|----------|--|------|----------|----------|---|------|
| 97       | 117366   | VALVE, ball, 3 way; 1-1/4 npt (f)                                  | 2    | 126      | 15B729   | COUPLING; 3/8 npsm(m) x 3/8 npt(f)  | 1    |
| 98       | 154628   | WASHER   | 3    | 127      | 195889   | BUSHING, strain relief  | 2    |
| 100      | 15A892   | BEARING, bronze  | 2    | 129      | 15A818   | COVER, sensor   | 2    |
| 101      | 234097   | HOPPER, A component; green   | 1    | 130      | C20272   | O-RING  | 2    |
| 102      | 113807   | WHEEL  | 2    | 131      | 15E383   | BUSHING, strain relief  | 2    |
| 103      | 101044   | WASHER; 1/2  | 10   | 132      | 552180   | VALVE, solenoid; 12 Vdc   | 1    |
| 104      | 15E143   | SUPPORT, wheel   | 1    | 133      | 287222   | VALVE, circulation; see 310655  | 2    |
| 105      | 191824   | WASHER   | 4    | 134      | H53803   | HOSE; nylon; 3/8 npt(fbe); 3/8 in. (10 mm) ID; 3 ft (0.9 m); see also pages 40 and 41 | 4    |
| 106▲     | 193185   | LABEL, warning   | 2    |          |          |   |      |
| 107      | 500054   | BUSHING, hex hd; 1 in. npt(f) x 1-1/4 in. npt(m)                   | 2    | 135      | 100023   | WASHER, flat; 3/8   | 8    |
| 108      | 246127   | HANDLE, cart   | 1    | 136      | 198175   | Y-CONNECTOR, push-in tube; 5/32 in. (4 mm) OD tube                                    | 2    |
| 109      | H72506   | HOSE, fluid; nylon; 1/4 in. (6 mm) ID; 1/4 npsm(fbe); 6 ft (1.8 m) | 1    | 137      | 100195   | NIPPLE; 3/8 npt; cst  | 2    |
| 110      | 511352   | MIXER, static  | 1    | 138      | 105690   | TEE; 3/8 npt(f); cst  | 2    |
| 111      | 801020   | NUT, lock, hex   | 4    | 139      | 15E391   | SPACER, heater mount  | 8    |
| 112      | C19660   | BUSHING; 1-1/4 in. npt(m) x 1/2 npt(f)                             | 2    | 140      | 107557   | SCREW, cap, hex hd; M8-1.25 x 75 mm   | 8    |
| 113      | 234017   | HOPPER, B component; blue  | 1    | 141      | 15E272   | ELBOW, tube; 1/2 npt(m) x 5/8 in. (16 mm) OD tube; cst                                | 2    |
| 114      | 111194   | SCREW, cap, flange hd; 3/8-16 x 2 in. (51 mm)                      | 6    | 142      | 15E273   | ELBOW, tube; 3/8 npt(f) x 5/8 in. (16 mm) OD tube; sst                                | 2    |
| 115      | 111218   | CAP, tube  | 2    | 143      | 245863   | HEATER, fluid; see 309524; used on 240V models only                                   | 2    |
| 116      | 113362   | WHEEL  | 2    |          | 245864   | HEATER, fluid; see 309524; used on 480V models only                                   | 2    |
| 117      | 15B755   | SPACER   | 2    | 144      | 165198   | NIPPLE, reducing; 1/4 npt(m) x 3/8 npt(m)   | 2    |
| 118      | 238782   | FILTER, fluid; stainless steel; 30 mesh screen                     | 2    |          |          |   |      |
| 119      | 15A912   | AXLE   | 1    |          |          |   |      |
| 120      | 15A913   | AXLE   | 1    |          |          |   |      |
| 121      | 15E187   | LIFT RING  | 2    |          |          |   |      |
| 122      | 100338   | NUT, jam; 1/2-13   | 2    |          |          |   |      |
| 123      | 113956   | BOLT, carriage; 3/8-16 x 1 in. (25 mm)                             | 4    |          |          |   |      |
| 124      | 114606   | PLUG   | 4    |          |          |   |      |
| 125      | 114552   | CAP, square  | 1    |          |          |   |      |


▲ Replacement Danger and Warning labels, tags, and cards are available at no cost.

### Tube Connections, Non-heated Units

Find the keys on the drawing to ensure proper connections.

| Key | Description                   | Ref. No. | Length, in. (mm) |
|-----|-------------------------------|----------|------------------|
| A1  | Dispense Valve A OFF          | 56       | 24 (610)         |
| A2  | Dispense Valve A ON           | 57       | 24 (610)         |
| B1  | Dispense Valve B OFF          | 59       | 24 (610)         |
| B2  | Dispense Valve B ON           | 58       | 24 (610)         |
| C1  | Air to Pneumatic Control (10) | 61       | 8 (203)          |
| D1  | Air Filter (9) Drain Tube     | 70       | 24 (610)         |
| D2  | Air Filter (7) Drain Tube     | 70       | 18 (457)         |

| Key | Description                            | Ref. No. | Length, in. (mm) |
|-----|--|----------|------------------|
| E1  | Pump A Exhaust                         | 61       | 8 (203)          |
| E2  | Pump B Exhaust                         | 61       | 12 (305)         |
| L1  | Fluid Line, Pump A to Dispense Valve A | 42       | molded tube      |
| L2  | Fluid Line, Pump B to Dispense Valve B | 43       | molded tube      |
| M1  | Air Filter (9) to Air Control (3)      | 24       | 18 (457)         |
| P1  | Pump A Input Air                       | 61       | 18 (457)         |
| P2  | Pump B Input Air                       | 61       | 24 (610)         |




T15281a

### Tube Connections, Heated Units

Find the keys on the drawing to ensure proper connections.


| Key | Description                              | Ref. No. | Length, in. (mm) |
|-----|--|----------|------------------|
| A1  | Dispense Valve A OFF                     | 56       | 24 (610)         |
| A2  | Dispense Valve A ON                      | 57       | 24 (610)         |
| B1  | Dispense Valve B OFF                     | 59       | 24 (610)         |
| B2  | Dispense Valve B ON                      | 58       | 24 (610)         |
| C1  | Air to Pneumatic Control (10)            | 61       | 8 (203)          |
| D1  | Air Filter (9) Drain Tube                | 70       | 24 (610)         |
| D2  | Air Filter (7) Drain Tube                | 70       | 18 (457)         |
| E1  | Pump A Exhaust                           | 61       | 8 (203)          |
| E2  | Pump B Exhaust                           | 61       | 12 (305)         |
| H1  | Fluid Line, Heater A to Dispense Valve A | 134      | 36 (915)         |

| Key | Description                              | Ref. No. | Length, in. (mm) |
|-----|--|----------|------------------|
| H2  | Fluid Line, Heater B to Dispense Valve B | 134      | 36 (915)         |
| L1  | Fluid Line, Pump A to Heater A           | 134      | 36 (915)         |
| L2  | Fluid Line, Pump B to Heater B           | 134      | 36 (915)         |
| M1  | Air Filter (9) to Air Control (3)        | 24       | 18 (457)         |
| P1  | Pump A Input Air                         | 61       | 18 (457)         |
| P2  | Pump B Input Air                         | 61       | 24 (610)         |
| R1  | Circulation Valve A OFF                  | 56       | 36 (915)         |
| R2  | Circulation Valve A ON                   | 57       | 36 (915)         |
| R3  | Circulation Valve B OFF                  | 56       | 20 (508)         |
| R4  | Circulation Valve B ON                   | 57       | 20 (508)         |



TI5282a


# Pneumatic Schematic




## 248270 Pneumatic Control

| Ref. No. | Part No. | Description  | Qty. | Ref. No. | Part No. | Description                                      | Qty. |
|----------|----------|--|------|----------|----------|--|------|
| 301      | 248349   | CIRCUIT BOARD, main                                | 1    | 306m     | 110207   | • ELBOW; 1/8 npt (mbe)                           | 1    |
| 302      | 100035   | SCREW, machine, phillips; 8-32 x 5/16 in. (8 mm)   | 8    | 306n‡    | 104765   | • PLUG, pipe; 1/8 ptf                            | 6    |
| 304      | 245854   | MODULE, alternator; includes items 304a-304e       | 1    | 306p     | 517449   | • MUFFLER  | 1    |
| 304a     | 193154   | • GASKET; LDPE foam                                | 1    | 306qt†   | 112512   | • WIRE FERRULE, orange (not shown)               | 8    |
| 304b     | 15A853   | • WIRE HARNESS                                     | 1    | 306r     | 117369   | • CONNECTOR, 12 position                         | 1    |
| 304c     | 111225   | • ELBOW; 1/8 npt(m) x 3/8 in. (10 mm) tube fitting | 2    | 306s     | 150278   | • ADAPTER, 1/4 x 1/8 npt                         | 1    |
| 304d     | 114380   | • SCREW; M5 x 25                                   | 4    | 306t     | 117480   | • SAFETY RELIEF VALVE, 26 psi (179 kPa, 1.8 bar) | 1    |
| 304e     | 249254   | • TURBINE ALTERNATOR                               | 1    | 306u     | 552183   | • PLATE  | 2    |
| 305      | 109466   | NUT, lock, w/nylon insert; 8-32                    | 2    | 307      | 15A800   | GASKET; neoprene                                 | 1    |
| 306      | 248268   | MODULE, solenoid; includes items 306a-306u         | 1    | 308      | 114421   | BUSHING, strain relief                           | 2    |
| 306a     | 15A822   | • MANIFOLD   | 1    | 309      | 106084   | SCREW, machine; M5 x 0.8; 10 mm                  | 2    |
| 306b     | 117356   | • VALVE, 12 VDC, IS                                | 2    | 310      | 590385   | TUBE, poly-flo                                   | 1 ft |
| 306c     | 114263   | • FITTING; 1/8 npt x 5/32 in. (4 mm) tube          | 6    | 311      | 113505   | NUT, keps; 10-24                                 | 1    |
| 306d‡    | 156971   | • NIPPLE; 1/4 npt                                  | 1    | 312      | 104029   | CLAMP, ground                                    | 1    |
| 306e     | 115243   | • AIR REGULATOR; 1/4 npt                           | 1    | 313      | 15A849   | HARNESS, wire, alarm                             | 1    |
| 306f     | 115841   | • ELBOW; 1/4 npt x 3/8 in. (10 mm) tube fitting    | 3    | 314      | 117442   | CONNECTOR, plug, 18 position                     | 1    |
| 306g     | 160701   | • ELBOW, street; 1/8 npt(m x f)                    | 1    | 315      | 15B090   | WIRE, grounding, door                            | 1    |
| 306h     | 108190   | • GAUGE  | 1    | 317      | 111307   | WASHER, lock, external tooth; M5                 | 1    |
| 306j‡    | 15A798   | • GASKET, neoprene                                 | 1    | 318      | 065213   | WIRE, copper                                     | 3 ft |
| 306k‡    | 15A799   | • GASKET, neoprene                                 | 1    | 320      | 118132   | TERMINAL, lug, lockwasher                        | 1    |
|          |          |  |      | 321      | 118129   | SPACER   | 1    |
|          |          |  |      | 322      | 114213   | HARNESS, connector                               | 1    |
|          |          |  |      | 323      | 246899   | CIRCUIT BOARD                                    | 1    |
|          |          |  |      | 324      | 112512   | FERRULE, wire                                    | 2    |


### 248270 Pneumatic Control, continued



### Alternator Module (304) Detail





### Solenoid Module (306) Detail



### 234621 User Interface


| Ref. No. | Part No. | Description                                  | Qty. |
|----------|----------|--|------|
| 401      | 15B062   | DISPLAY                                      | 1    |
| 403      | 15A851   | HARNESS, wire                                | 1    |
| 404      | 15A801   | GASKET; neoprene                             | 1    |
| 405      | 15D853   | KNOB, control                                | 1    |
| 406      | 15A850   | HARNESS, wire                                | 1    |
| 407      | 15A852   | HARNESS, wire, switch                        | 1    |
| 408      | 15D796   | LABEL, control, upper                        | 1    |
| 409      | 15D798   | LABEL, control, lower                        | 1    |
| 410      | 245706   | CIRCUIT BOARD, display; includes jam nut (N) | 1    |

| Ref. No. | Part No. | Description                                | Qty. |
|----------|----------|--|------|
| 411      | 112546   | SCREW, machine; 4-40 x 3/8 in. (10 mm)     | 2    |
| 412      | 15A856   | PANEL, display                             | 1    |
| 413      | C27076   | NUT, lock, w/nylon insert; 4-40            | 4    |
| 414      | 111907   | MOUNT, tie wrap                            | 3    |
| 416      | 15A854   | HARNESS, wire, display                     | 1    |
| 418      | 188438   | WASHER; 0.120 in.                          | 4    |
| 419      | 101366   | SCREW, set; socket hd; 10-24 x 5/16 (8 mm) | 1    |



### 287230 Pump Air Control

| Ref. No. | Part No. | Description  | Qty. | Ref. No. | Part No. | Description                                    | Qty. |
|----------|----------|--|------|----------|----------|--|------|
| 201      | 15D814   | MANIFOLD, air  | 2    | 207      | 113498   | VALVE, safety relief; 110 psi (0.8 MPa, 8 bar) | 1    |
| 202      | 206197   | REGULATOR, air; 1/2 npt(f) inlet and outlet; see manual 308168 | 1    | 208      | 119246   | STANDOFF                                       | 4    |
| 203      | 119240   | CAP, pipe, 1/2 in. (13 mm)                                     | 1    | 209      | 100081   | BUSHING, pipe; 1/2 npt(m) x 3/8 npt(f)         | 1    |
| 204      | 101689   | GAUGE, air pressure  | 2    | 210      | C19024   | ELBOW, swivel; 1/2 npt(m) x 1/2 npsm(f)        | 1    |
| 205      | 112678   | PLUG; 1/4 npt  | 3    |          |          |  |      |
| 206      | 118762   | VALVE, ball, bleed-type; 1/2 npt(fbe)                          | 1    |          |          |  |      |



TI4601a



A series of horizontal lines for writing, consisting of 25 evenly spaced lines that span the width of the page.

# Technical Data

|  |   |
|--|---|
| Mix ratio range  | 0.1:1-10:1 (in 0.1 increments),   |
| Ratio tolerance range  | up to +/- 1%  |
| Flow rates   |   |
| Minimum  | 0.02 qt/min (0.02 lpm)*   |
| Maximum  | 1 gpm (3.8 lpm)   |
| Pump size  | 92 cc/cycle   |
| Pump cycle length<br>(one cycle = one upstroke and one downstroke) | 7.6 in. (193 mm)/cycle  |
| Fluid viscosity range  | 50-20,000 cps (heavier viscosities can be mixed with use of optional heaters, heated hoses, and hardware)   |
| Fluid filtration   | 60 mesh (238 micron) standard   |
| Maximum fluid working pressure                                     | 4700 psi (32 MPa, 324 bar)  |
| Air supply pressure range  | 60-110 psi (420-800 kPa, 4.2-8 bar)   |
| Maximum air consumption at 100 psi (0.7 MPa, 7 bar)                | 63.0 scfm at 1 gpm (1.76 m <sup>3</sup> /min at 3.8 lpm)  |
| Ambient temperature range  |   |
| Operating  | 32-104° F (0-40° C)   |
| Storage  | 30-160° F (-1-71° C)  |
| External Power Supply Requirements                                 | 85-250 Vac, 50/60 Hz, 2 amps maximum draw<br>15 amp maximum circuit breaker required<br>14 AWG power supply wire gauge                            |
| Heater Power Requirements  | 240 Vac Heater: 16.2 A each heater, 32.4 A total<br>480 Vac Heater: 8.3 A each heater, 16.6 A total   |
| Environmental Conditions Rating                                    | Indoor/outdoor<br>Altitude up to 4000 meters<br>Maximum relative humidity to 99% up to 40° C<br>Pollution degree (1)<br>Installation category (2) |
| Sound pressure   | 98 dBA at 100 psi (0.7 MPa, 7 bar)  |
| Wetted parts   |   |
| Pumps  | See 310662  |
| Dispense Valves  | See 310655  |
| Mix Manifold   | See 310654  |
| PC Communications  | RS-232  |

\* Minimum flow rate is dependent on the material being sprayed and mixing capability. Test your material for specific flow rate.

# Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

**THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.**

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

**GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO.** These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

## **FOR GRACO CANADA CUSTOMERS**

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

# Graco Information

**TO PLACE AN ORDER**, contact your Graco distributor or call to identify the nearest distributor.

**Phone:** 612-623-6921 **or Toll Free:** 1-800-328-0211, **Fax:** 612-378-3505

*All written and visual data contained in this document reflects the latest product information available at the time of publication.  
Graco reserves the right to make changes at any time without notice.*

This manual contains English. MM 310666

**Graco Headquarters:** Minneapolis  
**International Offices:** Belgium, China, Japan, Korea

**GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441**

www.graco.com

310666G

5/2007