

# HydraMix™ Pumps


310672 rev.C



## Important Safety Instructions

Read all warnings and instructions in this manual.  
Save these instructions.

See page 2 for model information, including maximum working pressure and approvals.





TI4596a

PROVEN QUALITY. LEADING TECHNOLOGY.

# Contents

<b>Warning</b> .....	<b>3</b>	<b>Troubleshooting</b> .....	<b>10</b>
<b>Setup</b> .....	<b>5</b>	<b>Repair</b> .....	<b>11</b>
Grounding .....	5	Pump and Motor .....	11
Accessories .....	5	Air Motor .....	13
Flush Before Using Equipment .....	5	Solenoid Replacement .....	15
<b>Operation</b> .....	<b>7</b>	Sensor Replacement .....	16
Pressure Relief Procedure .....	7	Sensor Repair .....	17
Trigger Lock .....	7	<b>Parts</b> .....	<b>18</b>
Flushing .....	7	<b>Technical Data</b> .....	<b>20</b>
Priming .....	8	<b>Dimensions</b> .....	<b>21</b>
Shutdown .....	8	<b>Graco Standard Warranty</b> .....	<b>22</b>
<b>Maintenance</b> .....	<b>9</b>	<b>Graco Information</b> .....	<b>22</b>

## Manual Conventions


**WARNING**


**WARNING** indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

Warnings included in instructions generally have a symbol indicating the hazard. Follow the instructions and read the hazard section on warning pages 3 to 4 for additional information.

<b>CAUTION</b>
<b>CAUTION</b> indicates a potentially hazardous situation which, if not avoided, may result in property damage or destruction of equipment.

### Note







A note indicates additional helpful information.





## HydraMix Models

Part No.	Series	Description	Pressure Ratio	Maximum Air Input Pressure psi (MPa, bar)	Maximum Working Pressure psi (MPa, bar)
248572	A	HydraMix 500 cst Pump	24:1	100 (0.7, 7.0)	2400 (16, 166)
248573	A	HydraMix 500 sst Pump	24:1	100 (0.7, 7.0)	2400 (16, 166)
248574	A	HydraMix 600 cst Pump	34:1	100 (0.7, 7.0)	3400 (23, 234)
248575	A	HydraMix 600 sst Pump	34:1	100 (0.7, 7.0)	3400 (23, 234)
248576	A	HydraMix 700 cst Pump	47:1	100 (0.7, 7.0)	4700 (32, 324)
248577	A	HydraMix 700 sst Pump	47:1	100 (0.7, 7.0)	4700 (32, 324)
273011	A	HydraMix 700 TUFF cst Pump	47:1	100 (0.7, 7.0)	4700 (32, 324)

# Warnings

The following general warnings are related to the safe setup, use, grounding, maintenance, and repair of this equipment. More specific warnings are included in the text where applicable.

 <b>WARNING</b>	
	<p><b>FIRE AND EXPLOSION HAZARD</b></p> <p>Flammable fumes, such as solvent and paint fumes, in work area can ignite or explode. To help prevent fire and explosion:</p> <ul style="list-style-type: none"> <li>• Use equipment only in well ventilated area.</li> <li>• Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static arc).</li> <li>• Keep work area free of debris, including solvent, rags and gasoline.</li> <li>• Do not plug or unplug power cords or turn lights on or off when flammable fumes are present.</li> <li>• Ground equipment and conductive objects in work area. See <b>Setup</b> instructions.</li> <li>• Use only grounded hoses.</li> <li>• Hold gun firmly to side of grounded pail when triggering into pail.</li> <li>• If there is static sparking or you feel a shock, <b>stop operation immediately</b>. Do not use equipment until you identify and correct the problem.</li> <li>• Keep a fire extinguisher in the work area.</li> </ul>
	<p><b>SKIN INJECTION HAZARD</b></p> <p>High-pressure fluid from gun, hose leaks, or ruptured components will pierce skin. This may look like just a cut, but it is a serious injury that can result in amputation. <b>Get immediate surgical treatment.</b></p> <ul style="list-style-type: none"> <li>• Do not point gun at anyone or at any part of the body.</li> <li>• Do not put your hand over the spray tip.</li> <li>• Do not stop or deflect leaks with your hand, body, glove, or rag.</li> <li>• Do not spray without tip guard and trigger guard installed.</li> <li>• Engage trigger lock when not spraying.</li> <li>• Follow <b>Pressure Relief Procedure</b> in this manual, when you stop spraying and before cleaning, checking, or servicing equipment.</li> </ul>
	<p><b>MOVING PARTS HAZARD</b></p> <p>Moving parts can pinch or amputate fingers and other body parts.</p> <ul style="list-style-type: none"> <li>• Keep clear of moving parts.</li> <li>• Do not operate equipment with protective guards or covers removed.</li> <li>• Pressurized equipment can start without warning. Before checking, moving, or servicing equipment, follow the <b>Pressure Relief Procedure</b> in this manual. Disconnect power or air supply.</li> </ul>

 <b>WARNING</b>	
	<p><b>EQUIPMENT MISUSE HAZARD</b></p> <p>Misuse can cause death or serious injury.</p> <ul style="list-style-type: none"> <li>• Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See <b>Technical Data</b> in all equipment manuals.</li> <li>• Use fluids and solvents that are compatible with equipment wetted parts. See <b>Technical Data</b> in all equipment manuals. Read fluid and solvent manufacturer's warnings.</li> <li>• Check equipment daily. Repair or replace worn or damaged parts immediately.</li> <li>• Do not alter or modify equipment.</li> <li>• For professional use only.</li> <li>• Use equipment only for its intended purpose. Call your Graco distributor for information.</li> <li>• Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces.</li> <li>• Do not kink or overbend hoses or use hoses to pull equipment.</li> <li>• Comply with all applicable safety regulations.</li> </ul>
	<p><b>TOXIC FLUID OR FUMES HAZARD</b></p> <p>Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed.</p> <ul style="list-style-type: none"> <li>• Read MSDS's to know the specific hazards of the fluids you are using.</li> <li>• Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.</li> </ul>
	<p><b>PERSONAL PROTECTIVE EQUIPMENT</b></p> <p>You must wear appropriate protective equipment when operating, servicing, or when in the operating area of the equipment to help protect you from serious injury, including eye injury, inhalation of toxic fumes, burns, and hearing loss. This equipment includes but is not limited to:</p> <ul style="list-style-type: none"> <li>• Protective eyewear</li> <li>• Clothing and respirator as recommended by the fluid and solvent manufacturer</li> <li>• Gloves</li> <li>• Hearing protection</li> </ul>

# Setup

## Grounding

 **WARNING**

Your system must be grounded. Read warnings, page 3.

**Pump:** connect ground wire and clamp to a true earth ground.

**Air and fluid hoses:** use only electrically conductive hoses.

**Air compressor:** follow manufacturer's recommendations.

**Spray gun:** ground through connection to a properly grounded fluid hose and pump.

**Fluid supply container:** follow local code.

**Object being sprayed:** follow local code.

**Solvent pails used when flushing:** follow local code. Use only conductive metal pails, placed on a grounded surface. Do not place the pail on a nonconductive surface, such as paper or cardboard, which interrupts grounding continuity.


**To maintain grounding continuity when flushing or relieving pressure:** hold metal part of the spray gun firmly to the side of a grounded metal pail, then trigger the gun.



## Accessories

Install the following accessories in the order shown in FIG. 1, using adapters as necessary.

### Air Line

- **Bleed-type master air valve (D):** required in your system to relieve air trapped between it and the air motor when the valve is closed.

 **WARNING**

Trapped air can cause the pump to cycle unexpectedly, which could result in serious injury from splashing or moving parts.

Be sure the valve is easily accessible from the pump and located downstream from the air regulator.

- **Pump air regulator (E):** to control pump speed and outlet pressure. Locate it close to the pump.
- **Air line filter (C):** removes harmful dirt and moisture from compressed air supply.

### Fluid Line

- **Fluid drain valve (G):** required in your system, to relieve fluid pressure in the hose and gun.


 **WARNING**



Read warnings, page 3.

## Flush Before Using Equipment

The equipment was tested with lightweight oil, which is left in the fluid passages to protect parts. To avoid contaminating your fluid with oil, flush the equipment with a compatible solvent before using the equipment. See **Flushing**, page 7.



TI4791a



**FIG. 1: Typical Installation, shown in a wall mounted, air-assisted proportioning system**

**Key:**

- |  |                              |
|--|------------------------------|
| A Main Air Supply Line                   | H Component A Fluid Supply   |
| B Air Shutoff Valve                      | J Component B Fluid Supply   |
| C Pump Air Filter (inside cabinet)       | K Gun Air Pressure Regulator |
| D Bleed-type Master Air Valve (required) | L Gun Air Supply Line        |
| E Pump Air Regulator                     | M Gun Fluid Supply Line      |
| F HydraMix Pumps                         | N Air-Assisted Spray Gun     |
| G Fluid Mix Manifold                     | P Ground Wire                |

# Operation

## Pressure Relief Procedure


**WARNING**





Follow **Pressure Relief Procedure** when you stop spraying and before cleaning, checking, servicing, or transporting equipment. Read warnings, page 3. Also follow the **Pressure Relief Procedure** in your separate system manual.

1. Engage trigger lock.
2. Close the bleed-type master air valve.
3. Disengage the trigger lock.
4. Hold a metal part of the gun firmly to a grounded metal pail. Trigger the gun to relieve pressure.
5. Engage the trigger lock.
6. Open all fluid drain valves in the system, having a waste container ready to catch drainage. Leave drain valve(s) open until you are ready to spray again.
7. If you suspect the spray tip or hose is clogged or that pressure has not been fully relieved after following the steps above, VERY SLOWLY loosen tip guard retaining nut or hose end coupling to relieve pressure gradually, then loosen completely. Clear hose or tip obstruction.

## Trigger Lock

Always engage the trigger lock when you stop spraying to prevent the gun from being triggered accidentally by hand or if dropped or bumped.

## Flushing


**WARNING**



Read warnings, page 3. Follow **Grounding** instructions, page 5.

Flush before changing colors, before fluid can dry in the equipment, at the end of the day, before storing, and before repairing equipment.

Flush at the lowest pressure possible. Check connectors for leaks and tighten as necessary.

Flush with a fluid that is compatible with the fluid being pumped and the equipment wetted parts.

1. Follow **Pressure Relief Procedure**, page 7.
2. Remove spray tip from the gun.
3. Change the fluid source to solvent.
4. Set the pump to the lowest possible fluid pressure, and start the pump.
5. Hold a metal part of the gun firmly to a grounded metal pail. Trigger the gun until clean solvent flows from the gun.
6. Follow **Pressure Relief Procedure**, page 7.

## Priming



Do not install the gun spray tip yet. Use the lowest possible pressure while priming, to avoid splashing.

1. Connect fluid supply hose to pump fluid inlet.
2. Set pump air regulator to 0.
3. Start the pump, and set it to the lowest possible fluid pressure.
4. Hold a metal part of the gun firmly to a grounded metal pail. Trigger the gun until fluid flows smoothly from the gun.
5. Follow **Pressure Relief Procedure**, page 7.

## Shutdown

Follow this procedure before prolonged shutdown or servicing equipment.

1. Follow **Pressure Relief Procedure**, page 7. Engage trigger lock, set air regulator to 0, and close main air shutoff valve. Remove spray tip.
2. Follow **Flushing**, page 7.
3. Follow **Pressure Relief Procedure**, page 7. Engage trigger lock.
4. *Before prolonged shutdown:* cap fluid outlets to keep solvent in the lines. Fill pump wet cup with throat seal liquid (TSL).

# Maintenance

## Air Filters

Check weekly. Drain and clean as necessary.

## Preventive Maintenance Schedule

Establish a preventive maintenance schedule, based on the pump's repair history.

## Wet Cup

Check wet-cup daily. Keep filled with Graco Throat Seal Liquid (TSL), Part No. 206995, to prevent material from hardening on displacement rod.

## Storage

Before storing the pump, always flush it, page 7. Relieve the pressure, page 7.

# Troubleshooting

**WARNING**


Read warnings, page 3-4.

Problem	Cause	Solution
Pumps do not run.	Air pressure to pump too low	Increase pressure to 50 psi (0.35 MPa, 3.5 bar).
	Air pilot lines are obstructed	Check pilot lines for kinks or pinches.
	Solenoid valve stuck.	Actuate solenoid manually, if it does not operate, replace solenoid. Page 15.
	Dispense valve not opening.	Service or replace valve(s). See system manual.
	Paint cured in pump/valves.	Repair displacement pump. See 310662.
	Pump packings swollen.	Use different flushing solvent.
Pump test volume is not correct.	Air pressure to pump too low	Increase pressure to 50 psi (0.35 MPa, 3.5 bar).
	Sensor not functioning properly.	Check position of sensor. Check board calibration and recalibrate if necessary. See system manual. Replace sensor. Page 16.
	Pump cavitating excessively.	Check for air in lines caused by loose fitting or use of agitator. Material too viscous. Use heater.
Paint does not cure consistently.	Pump not operating correctly.	Observe whether pump is loading and checking correctly, if not, clean and repair displacement pump. See 310662.
Pump runs erratically.	Air filter clogged.	Clean. Replace element.
	Air supply hoses undersized.	Replace hoses with appropriate size.
	Air compressor undersized.	Use larger air compressor.
	Rod moves up when not dispensing; worn piston valve or packings.	Repair displacement pump. See 310662
	Rod moves down when not dispensing; worn intake valve.	Repair displacement pump. See 310662
Pump leaking.	Worn packings.	Replace packings. See 310662.
Flow rate too low.	Inadequate air supply.	Use larger CFM compressor.
	Air pressure to pumps too low.	Increase pressure.
	Fluid filter plugged.	Clean filter.
	Spray tip too small.	Relieve pressure. Install larger tip. Follow gun manual instructions.
	Fluid hose partially plugged or too restrictive.	Inspect for cured material. Clean or replace, or use larger hose


# Repair

Follow **Shutdown** procedure, page 8, if service time may exceed pot life time, before servicing fluid components, and before transporting equipment to a service area.

Repair Kits are available for your pump. The kits must be ordered separately. Parts included in the kits are marked with an asterisk, for example (103\*). See page 19.


**WARNING**





Read warnings, page 3.

## Pump and Motor

### Disassembly


**WARNING**





Read warnings, page 3.


1. Flush pump, page 7.
2. Follow **Pressure Relief Procedure**, page 7.
3. Remove the pump from the system as explained in the system manual.
4. Push retaining spring (154) up. Push pin (155) out. See FIG. 2.
5. Mark the orientation of the pump's fluid outlet (G) on the bracket (152), for later reference.
6. Loosen star-shaped locknut (158) by hitting firmly with a non-sparking hammer and punch, and screw locknut all the way down onto displacement pump (159). Unscrew pump from adapter plate (156). See manual 310662 to repair displacement pump.
7. Remove nuts (157) and slide adapter plate (156) off tie rods (160). Remove tie rods, screws (153), and bracket (152) from air motor (100). To repair air motor, see page 13.

## Reassembly

1. Install tie rods (160) in air motor (100), see FIG. 2.  
Torque to 30-35 ft-lb (41-47 N•m).
2. Align large notch (N) in bracket with air manifold (127). Attach with screws (153).
3. Slide adapter plate (156) onto tie rods (160) and secure with nuts (157). Torque to 50-60 ft-lb (68-81 N•m).
4. Ensure star-shaped locknut (158) is screwed on pump with flat side up. Screw pump into adapter plate (156) until pin hole aligns with hole in connecting rod (118). Push pin (155) in. Pull retaining spring (154) down. See FIG. 2.
5. Turn pump in/out of adapter plate (156) until top of pump's outer cylinder is flush with top of plate. Then adjust pump in either direction to align pump fluid outlet (G) as desired (see step 5 on page 11). Screw star-shaped locknut (158) up against adapter plate (156). Tighten by hitting firmly with a non-sparking hammer and punch.
6. Reconnect fluid inlet and outlet lines to displacement pump (159). Return pump to service.

⚠ 1 Torque to 30-35 ft lb (41-47 N•m).

⚠ 2 Torque to 50-60 ft lb (68-81 N•m).



T14597a

**FIG. 2. Pump and Motor**

# Air Motor

## Disassembly

1. Follow **Pressure Relief Procedure**, page 7.
2. Remove the pump from the system. Disconnect air motor, page 11.
3. Clamp bottom cylinder cap (116) in a vise, taking care not to damage piston rod (114).

### CAUTION

When removing the sensor (101), lift it straight up out of the cylinder. Be careful not to bend the shaft.

4. Remove sensor (101), see page 16.
5. Remove air manifold (127), see page 15.
6. Using two wrenches, remove nuts (105) and washers (125) from bolts (119).
7. With twisting, rocking motion, pull off top cylinder cap (106) and cylinder (108). Gently use a rubber hammer if necessary to loosen these parts. Do not pry them off with a screwdriver or similar tool.
8. Remove o-rings (107) from both cylinder caps (106, 116). Remove piston o-ring (113).
9. To access piston rod seal (115):
  - a. Remove retaining spring (154, see FIG. 2) from connecting rod (118). Place connecting rod in vise. Attempt to remove nut (111); nut will come loose or rod (114) will unscrew from connecting rod (118). Remove rod (114) from bottom cap (116).
  - b. Remove seal (115) from bottom cap (116), using a wood or plastic pick. If bottom cap bearing is excessively worn, replace bottom cap (116).

10. Inspect piston rod (114) and inner surface of cylinder (108) for wear, scratches, or other damage. Replace as necessary.



If piston (112) is still attached to rod (114) and either part needs replacement, place flats of rod in vise and unscrew nut (111). Disassemble piston.

## Reassembly


1. Install rod seal (115\*) in bottom cylinder cap (116) with its lips facing up toward the cylinder. Lubricate piston rod (114) and bearing (inside the bottom cap) with oil (not grease). Insert rod through bottom cap, making sure it doesn't catch the lips of seal (115).
2. Apply Loctite to connecting rod (118) threads, then screw connecting rod into bottom of piston rod (114).
3. If piston was removed, place connecting rod (118) in a vise so piston rod (114) faces up. Apply Loctite to piston rod (114) threads, reassemble piston assembly (126, 112, 126), and torque nut (111) to 120 ft-lb (162 N•m).
4. Install piston o-ring (113\*) and cylinder cap o-rings (107\*). Liberally apply grease to o-rings and ends and inner surface of cylinder (108).
5. Press the piston o-ring (113) into its groove so the excess portion protrudes toward you. Tip the cylinder (108) toward you and pass it over the piston so the far side holds the o-ring in place and the near side allows it to protrude. Rotate the cylinder to a vertical position with a rocking motion, seating the o-ring in its groove.




If the o-ring is properly seated, the cylinder will move up and down.

6. Press the cylinder (108) securely over the o-ring (107) of the bottom cap (116). Press the top cap (106) onto the cylinder, twisting so it aligns with the bottom cap.
7. Install bolts (119), washers (125), and nuts (105) fingertight, just until all clearance is removed.

8. Install air manifold (127), see page 15. Reorient cylinder caps (106, 116) as necessary to ensure that screws (129) do not bind and draw manifold fully against cylinder (108). Then loosen screws (129) about 1/8 turn, to allow cylinder caps to draw together in step 9.
9. Using two wrenches, torque each bolt/nut (119, 105) in rotation, incrementally to 10, 20, 35, then 50 ft-lb (14, 27, 47, 67 N•m).
10. Verify that piston moves freely in cylinder, then retighten air manifold screws (129).
11. Install sensor (101), see page 16.
12. Install retaining spring (154) on connecting rod (118).
13. Reconnect air motor, page 12. Reinstall pump in the system.

 This tightening procedure must be followed exactly, to prevent cylinder misalignment, excessive wear, and reduced performance.



T14588a


**FIG. 3. Air Motor**

# Solenoid Replacement



Depending on which solenoid is being replaced, it may be possible to make repairs without removing the air manifold (127) from the pump, or the pump from the system.

1. Follow **Pressure Relief Procedure**, page 7.
2. Note location of solenoid wire harnesses. Press tab on connectors and remove wire harnesses. FIG. 4.
3. If necessary, remove the pump from the system.
4. Mark which air line connects to top of manifold (127), which to bottom. Press on collars of tube connectors (131, 132) and pull on tubing to release air lines.
5. Remove screws (129) and pull manifold (127) away from air motor (100). Remove o-rings (134) from the manifold or the cylinder caps (106, 116).
6. Loosen four screws holding solenoid (128) to manifold (127). Ensure that solenoid's gasket does not adhere to manifold.
7. Apply grease to counterbores in top and bottom cylinder caps, then install o-rings (134\*).
8. Install new solenoid (128). Ensure solenoid gasket is in grooves; use grease as necessary to hold in place.
9. Reinstall in reverse order. Ensure that air tubes and wire harnesses are connected to the proper solenoids.



TI4939a

**FIG. 4. Air Cylinder and Solenoids**


# Sensor Replacement

1. Follow **Pressure Relief Procedure**, page 7.
2. Remove the pump from the system.
3. Unscrew sensor (101) from air motor (100). If pliers or wrench is required, apply near bottom of sensor to avoid damaging housing. FIG. 5.

## CAUTION

When removing the sensor (101), lift it straight up out of the cylinder. Do not bend the shaft.

4. Lift sensor (101) straight out of cylinder (108). Ensure that o-ring (103) is on the sensor shaft and did not fall off.
5. Liberally grease the new sensor's threads and the tubing at the end of its shaft. Ensure that the o-ring (103\*) is in place on the shaft. Carefully insert the sensor into the cylinder, then screw into the top cylinder cap handtight. Do not overtighten.
6. Record the new sensor's calibration value. Install the pump in the system.
7. Recalibrate sensor. See system manual.



- 1 Lift sensor (101) straight up. Do not bend shaft.
- 2 Screw sensor into cylinder handtight. Do not overtighten.
- 3 Calibration value location.

TI4940a


**FIG. 5. Sensor Replacement**

# Sensor Repair


## CAUTION

To avoid damaging board, wear a grounding strap.


1. Follow **Pressure Relief Procedure**, page 7.
2. Remove sensor, page 16.
3. Unscrew sensor cap (101a) from nut (101h). FIG. 6.
4. Disconnect cable.
5. Remove screws (101k) and cover (101b).
6. Disconnect sensor cable from board (101c).
7. Remove and replace parts as needed.
8. Install sensor, page 16.
9. Recalibrate sensor. See system manual.



TI4595a



TI4593a



TI4594a

△1 Torque to 60 in-lb (7 N•m).

△2 Plug sensor cable into connector on board (101c).

△3 Calibration value location.

**FIG. 6. Sensor Repair**

## Complete Pump



## HydraMix Pumps

248572 Carbon Steel HydraMix 500 Pump

248573 Stainless Steel HydraMix 500 Pump

248574 Carbon Steel HydraMix 600 Pump

248575 Stainless Steel HydraMix 600 Pump

248576 Carbon Steel HydraMix 700 Pump

248577 Stainless Steel HydraMix 700 Pump

273011 Carbon Steel HydraMix 700 Pump TUFF

Ref. No.	Part No.	Description	Qty.	Ref. No.	Part No.	Description	Qty.
100	287236	MOTOR, air, HydraMix 500; 248572 and 248573 only; includes items 101-134	1	116	248578	. CAP, cylinder, bottom; 287236 only; includes item 115	1
	287274	MOTOR, air, HydraMix 600; 248574 and 248575 only; includes items 101-134	1		248579	. CAP, cylinder, bottom; 287274 only; includes item 115	1
	287211	MOTOR, air, HydraMix 700; 248577 and 248576 only; includes items 101-134	1		248580	. CAP, cylinder, bottom; 287211 only; includes item 115	1
101	248553	. SENSOR, displacement; includes items 101a-101k	1	118	15D174	. ROD, connecting	1
101a	196280	. . CAP	1	119	119050	. BOLT, cap, hex hd; 1/2-13 x 8 in. (203 mm)	3
101b	196282	. . COVER	1	125	113962	. WASHER; 1/2	6
101c	243500	. . BOARD	1	126	119241	. SHIM	2
101d	115925	. . SPACER	2	127	15D762	. MANIFOLD, air	1
101e	196279	. . TUBE	1	128	248552	. VALVE, solenoid, 93A	2
101f	115917	. . SENSOR	1	129	116138	. SCREW, cap, socket hd; 5/16-18; 1-3/4 in. (44 mm)	2
101g	110004	. . O-RING; PTFE	1	131	114114	. ELBOW, tube; 3/8 npt(m) x 1/2 in. (13 mm) OD tube	1
101h	196289	. . NUT	1	132	114129	. FITTING, tube; 3/8 npt(m) x 1/2 in. (13 mm) OD tube	1
101j	116024	. . TAB TERMINAL	1	133	100721	. PLUG	2
101k	112546	. . SCREW; 4-40 taptite	2	134*	514315	. O-RING; fluoroelastomer	2
103*	118605	. O-RING; nitrile	1	152	15D882	BRACKET	1
105	801020	. NUT, lock, w/nylon insert; 1/2-13	3	153	113802	SCREW, hex hd, flanged; 3/8-16 x 5/8 in. (16 mm)	3
106	15D330	. CAP, cylinder, top; 287236 only	1	154	183169	SPRING, retaining	1
	15D828	. CAP, cylinder, top; 287274 only	1	155	197443	PIN, pump	1
	15D144	. CAP, cylinder, top; 287211 only	1	156	15D188	PLATE, adapter	1
107*	118765	. O-RING; nitrile; 287236 only	2	157	101712	NUT, lock; 5/8-11	3
	119243	. O-RING; nitrile; 287274 only	2	158	193394	NUT, retaining	1
	118606	. O-RING; nitrile; 287211 only	2	159	248542	PUMP, displacement; carbon steel; 248572, 248574, and 248576 only; see manual 310662	1
108	248548	. CYLINDER; 287236 only	1		248543	PUMP, displacement; stainless steel; 248573, 248575, and 248577 only; see manual 310662	1
	248549	. CYLINDER; 287274 only	1		249360	PUMP, TUFF displacement; carbon steel; 273011 only; see manual 310662	1
	248550	. CYLINDER; 287211 only	1		15D186	ROD, tie	3
111	248646	. NUT, piston; with magnets	1				
112	15D334	. PISTON; 287236 only	1				
	15D831	. PISTON; 287274 only	1				
	15D141	. PISTON; 287211 only	1				
113*	118766	. O-RING; nitrile; 287236 only	1				
	119244	. O-RING; nitrile; 287274 only	1				
	119258	. O-RING; nitrile; 287211 only	1				
114	248547	. ROD, piston	1				
115*	118599	. PACKING, v-block; nitrile	1				

\* Included in repair kits 248434 (HydraMix 500), 248435 (HydraMix 600), and 248436 (HydraMix 700).

## Technical Data

### Flow rates

Minimum . . . . . 0.02 qt/min (0.02 lpm)\*

Maximum . . . . . 3/4 gpm (2.8 lpm)

### Maximum fluid working pressure

24:1 . . . . . 2400 psi (16 MPa, 166 bar)

34:1 . . . . . 3400 psi (23 MPa, 234 bar)

47:1 . . . . . 4700 psi (32 MPa, 324 bar)

Air supply pressure range. . . . . 50-100 psi (345-700 kPa, 3.5-7.0 bar)

### Maximum air consumption at 100 psi (0.7 MPa, 7 bar)

24:1 . . . . . 40.5 scfm at 1 gpm (1.13 m<sup>3</sup>/min at 3.8 lpm)

34:1 . . . . . 54.7 scfm at 1 gpm (1.53 m<sup>3</sup>/min at 3.8 lpm)

47:1 . . . . . 63.0 scfm at 1 gpm (1.76 m<sup>3</sup>/min at 3.8 lpm)

cc/cycle. . . . . 92 cc/cycle

### Pump cycle length


(one cycle = one upstroke and one downstroke) . . . . . 7.6 in. (193 mm)/cycle

Wetted parts . . . . . See manual 310662.

\* *Minimum flow rate is dependent on the material being sprayed and mixing capability. Test your material for specific flow rate.*

# Dimensions

- A** 10.5 in. (267 mm)
- B** 8.5 in. (216 mm)
- C** 19.5 in. (495 mm)
- D** 11.3 in. (287 mm)
- E** 30.8 in. (782 mm)
- F** 1 in. npsm(m)
- G** 3/8 npt(f)
- H** 1/2 in. (13 mm) OD air tube fittings



T14596a

# Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

**THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.**

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

**GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO.** These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

## **FOR GRACO CANADA CUSTOMERS**

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présent document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

# Graco Information

**TO PLACE AN ORDER,** contact your Graco distributor or call to identify the nearest distributor.

**Phone:** 612-623-6921 **or Toll Free:** 1-800-328-0211, **Fax:** 612-378-3505

*All written and visual data contained in this document reflects the latest product information available at the time of publication.  
Graco reserves the right to make changes at any time without notice.*

MM 310672

**Graco Headquarters:** Minneapolis  
**International Offices:** Belgium, China, Japan, Korea

**GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441**

[www.graco.com](http://www.graco.com)

Printed in USA 310672C

4/2007