


Pump Mounting Bracket

Model 236–778

Includes hardware to mount a stubby-size 1/4:1 ratio Dyna-Star™ Pump or 1:1 Power-Star™ Pump to a wall.

Model 203–987

Includes hardware to mount a stubby-size 1:1 Dyna-Star, 1:1 Fast-Ball, 10:1 President, 3:1 Eagle, or 5:1 ratio Fire-Ball Pump to a wall.



01357

Installation

Mounting the Pump Bracket (Fig. 1)

1. When determining where to mount the bracket, consider the following things:
 - a. Location of the permanent supply lines from the pump to the outlet
 - b. Type of connections required
 - c. Ease in moving drums
 - d. Stress caused on the wall by the weight of the pump, pumping operation, hoses, and fluid
2. See Fig. 2. Refer to the following table for nominal screw size to mount the pump bracket. Use screws and lock washers of the appropriate type and length for your installation.

Model	Screw Size, in. (mm)
236–778	1/2 (12)
203–987	3/8 (10)

Dimensions

Model	X in. (mm)	Y in. (mm)	Z in. (mm)
236–778	6-1/4 (159)	6-1/4 (159)	9/16 (14)
209–987	4-1/8 (105)	5-1/8 (130)	7/16 (11)




Fig. 1

02312

Installation

Mounting the Pump (See Fig. 2)

1. Remove the screws (2), lock washers (1) and pump support strap (4).
2. Mount the pump in the pump mounting support (3) and position approximately 1 in. (25 mm) down the pump cylinder as shown in Fig. 2.
3. Reinstall the pump support strap, lock washers and screws.

Pump and Connecting Hoses Not Included




Fig. 2


Parts

Pump Mounting Bracket 236-778

Ref. No.	Part No.	Description	Qty.
1	100-133	WASHER, lock; 3/8"	4
2	102-637	SCREW, cap; 3/8-16 x 1-1/2"	4
3	189-713	SUPPORT, pump mounting	1
4	189-721	STRAP, pump support	1
5	189-836	PAD, pump mounting	1

Pump Mounting Bracket 203-987

Ref. No.	Part No.	Description	Qty.
1	100-214	WASHER, lock; 5/16"	2
2	100-450	SCREW, cap; 5/16-18 x 1"	2
3	160-846	SUPPORT, pump mounting	1
4	160-847	STRAP, pump support	1
5	168-716	PAD, pump mounting	1



Graco Phone Numbers

TO PLACE AN ORDER, contact your Graco distributor, or call Graco: **1-800-367-4023 Toll Free**

FOR TECHNICAL ASSISTANCE, service repair information or answers about the application of Graco equipment: **1-800-543-0339 Toll Free**

Sales Offices: Atlanta, Chicago, Dallas, Detroit, Los Angeles, Mt. Arlington (N.J.)
Foreign Offices: Canada; England; Korea; Switzerland; France; Germany; Hong Kong; Japan

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441

PRINTED IN U.S.A. 308-394 7/94