

Instructions – Parts List



25–GALLON (95–LITER)

Oil King™ and Coolant King™

308667 Rev.K

This equipment is intended for collection of petroleum lubricants or antifreeze only. Any other use or collection of any other fluids could result in damage to the equipment or serious bodily injury.

Used–Oil Receiver

Model 238866, Series C

Used–Anti–Freeze Receiver

Model 248632, Series C

Funnel Kit

Model 243650, Series A

U.S. Patent No. Des. 395,439


NOTE: These used-fluid receivers can be used with the Graco used-oil receiver evacuation system and accessories documented in instruction manuals 308719 and 307870.



Read warnings and instructions.

Table of Contents

Warnings	2
Operation	3
Parts Drawing	4
Parts List	5
Technical Data	5
Graco Standard Warranty	6
Graco Information	6



T10414

PROVEN QUALITY. LEADING TECHNOLOGY.

Symbols

Warning Symbol



This symbol alerts you to the possibility of serious injury or death if you do not follow the instructions.

Caution Symbol



This symbol alerts you to the possibility of damage to or destruction of equipment if you do not follow the instructions.

WARNING



INSTRUCTIONS

EQUIPMENT MISUSE HAZARD

Equipment misuse can cause the equipment to malfunction and result in serious injury.

- This equipment is for professional use only.
- Read all instruction manuals before you operate this equipment.
- Use the equipment only for its intended purpose. If you are not sure, contact your Graco distributor.
- Do not alter or modify this equipment.
- Check equipment daily. Repair or replace worn or damaged parts immediately.
- This equipment is intended for collection of petroleum lubricants or antifreeze only. Any other use or collection of any other fluids could result in damage to the equipment or serious bodily injury.
- Always wear protective eyewear, gloves, clothing, and respirator as recommended by the fluid and solvent manufacturer.
- Comply with all applicable local, state, and national fire, electrical, and safety regulations.
- Dispose of waste fluids according to all local, state, and national guidelines.



FIRE AND EXPLOSION HAZARD

Poor ventilation, open flames, or sparks can cause a hazardous condition and result in a fire or explosion and serious injury.

- If you are using this unit with an evacuation system, make sure the pumping system is installed and grounded according to the manufacturer's recommendation.
- Provide fresh air ventilation to avoid the buildup of flammable fumes.
- Extinguish all open flames in the work area.
- Do not smoke in the work area.

United States Government safety standards have been adopted under the Occupational Safety and Health Act. You should consult these standards—particularly the General Standards, Part 1910.

Operation

Refer to parts drawing. Squeeze the handles together on the torsion spring (8), and slide the funnel up or down to achieve the proper height.

WARNING

To lower the center of gravity and reduce the possibility of tipping, make sure you lower the funnel before you roll the unit anywhere.

To ensure that the funnel does not plug and fill up, keep the strainer (24) clean.

- To drain the unit, use the lower drain, or use an evacuation system as described in instruction manual 308719.

WARNING


To prevent spill, do not fill unit above the 25 gallon indication on the sight tube.

CAUTION

NOTE: If you will use the lower drain, remove the pipe plug (12) from the tee (10), and replace it with the drain valve (25) **before you put any fluid into the unit.**

- For ease in positioning the unit during use, it is best to guide the unit by the front handle, because the pivoting casters are on the front.

Parts Drawing



TI0415

Parts List

Used-Oil Receiver (black tank), Model 238866, Series C

Used-Anti-Freeze Receiver (green tank), Model 248632, Series C

Ref. No.	Part No.	Description	Qty.	Ref. No.	Part No.	Description	Qty.
1		TANK; 25 gallon (95 liter)	1	10	113655	TEE, pipe;	
2	243650	FUNNEL ASSEMBLY	1			3/4 in. x 3/4 in. x 3/4 in.	1
2a		FUNNEL	1	11	113656	NIPPLE, pipe; 3/4 in. x 3/4 in.	1
2b		SCREW, machine, pan head, 5/16–18 UNC	4	12	113657	PLUG, pipe; 3/4 in.	1
			4	13	113648	FILL CAP, vented	1
2c	111959	O-RING	4	14	113783	SCREW, machine, panhead; 1/4–20 UNC–2A	4
2d		TUBE, drain	1				
2e	116092	GASKET	1	15	113908	CLAMP, hose; 1.25 in. (32 mm)	2
2f	196562	STRAINER	1	16	113649	ADAPTER, hose	2
3	113645	CASTER, polyurethane; 3 in. (76 mm)	2	17	113658	CREST NUT, hat	2
			2	19		BOLT, hex hd; 5/16–18 x 3/4 in.	8
4	113647	WHEEL, semi-pneumatic, synthetic rubber; 10.5 in. (267 mm)	2	20	100214	WASHER, lock; 5/16 in.	8
			2	21	191824	WASHER, spacer; 0.66 in. I.D. x 0.25 in. thick	2
6	191748	COLLAR, funnel	1				
7	191752	AXLE	1	22	111841	WASHER, plain; 5/8 in.	4
8	104820	SPRING, torsion	1	25	113895	VALVE, drain; 3/4 in.	1
9	192871	TUBE, sight; 1.29 in. O.D x 1 in. I.D. x 29 in.	1	26	113902	COUPLING, cam, male; 3/4 in.	1
			1	27	113907	COUPLING, cam, female; 3/4 in.	1

Technical Data

Length	24 in. (610 mm)
Width	24 in. (610 mm)
Height	
with bowl at lowest adjustment	45 in. (1143 mm)
with bowl at highest adjustment	69 in. (1573 mm)
Dry Weight	54 lb (24.5 kg)
Fluid inlet/inspection port size	3 in. (76 mm) buttress
Fluid outlet fitting size	3/4 in. npt
Wetted parts	linear low-density polyethylene (LLDPE), zinc-plated steel, brass, nylon, polypropylene, PVC, Buna-N, polyurethane
Recommended operating temperature	30° to 105° F (–1° to 41° C)

Graco Standard Warranty

Graco warrants all equipment manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

Graco makes no warranty, and disclaims all implied warranties of merchantability and fitness for a particular purpose in connection with accessories, equipment, materials or components sold but not manufactured by Graco. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Information

TO PLACE AN ORDER, contact your Graco distributor, or call this number to identify the distributor closest to you:

1-800-533-9655 Toll Free

612-623-6928

612-378-3590 Fax

*All written and visual data contained in this document reflects the latest product information available at the time of publication.
Graco reserves the right to make changes at any time without notice.*

Graco Headquarters: Minneapolis
International Offices: Belgium, Korea, China, Japan

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441

www.graco.com

PRINTED IN USA 308667 10/1996, Revised 10/2004