INSTRUCTIONS



For detailed sprayer information and warnings, see Operating Instructions manual 309225 included with MAGNUM sprayers or 309388 included with 150 RPX Roller and Spray System.



First choice when quality counts.™

309327

Rev C

This manual contains kit installation instructions only.

Control Board Kit for

Missing dx Airless Sprayers and RPX 150 Roller and

Spray System

Control Board Replacement Kit: 245079, 245677, 245986

Pressure Relief Procedure

WARNING



To help prevent injection injuries, follow this procedure when you stop spraying and before you service or clean the sprayer, remove parts, or repair leaks.

- 1. Turn Power switch OFF. Unplug sprayer.
- 2. Turn Spray/Prime valve to PRIME to relieve pressure. Turn PRessure Control knob left (counterclockwise) to minimize pressure.
- 3. Put trigger safety in SAFETY ON position.

NOTE: Leave Spray/Prime valve in the PRIME position until you are ready to spray again.



9565/

If you suspect that the spray tip or hose is completely clogged or that pressure has not been fully relieved after following the steps above, VERY SLOWLY loosen the tip guard retaining nut or hose end coupling to relieve pressure gradually. Then loosen it completely. Clear the tip or hose obstruction.

ti1093A

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441




Fig. 1

Disassembly (Fig. 1)

- Unplug electrical cord.
- Relieve Pressure by following the procedure described on page 1, or see the Operating Instructions manual 309225.
- 3. Tip unit on its back.
- 4. Remove 3 motor enclosure screws using a T–20 torx or straight blade screw driver.
- Disconnect motor harness, electrical cord, and pressure control knob leads
- Remove 2 screws (A) that mount control board to housing using a T–20 torx or straight blade screw driver.
- 7. Lift the control board out of the housing.
- 8. Remove switch cover (B) and save.
- 9. Discard old control board (C).

Assembly (Fig. 1)

- 1. Place switch cover (B) over switch on new control board (C).
- 2. Insert new control board (C) into housing.
- 3. Replace 2 control board mounting screws (A).



ti1093A

Fig. 2

- 4. Connect motor harness, electrical cord and pressure control knob leads. (Fig. 2)
- 5. Replace cover and screws. Before tightening, be sure switch cover is aligned with two grooves in motor enclosure.

All written and visual data contained in this document reflects the latest product information available at the time of publication.

Graco reserves the right to make changes at any time without notice.

Sales Office: Minneapolis International Offices: Belgium, Korea, Hong Kong, Japan

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441

www.graco.com