## **INSTRUCTIONS-PARTS LIST**



309331

Rev. A



Refer to your SuperCat manual (308803, 308881, or 308925) for important warnings and information. READ AND KEEP FOR REFERENCE.

First choice when quality counts.™

# **High Pressure Sensor Kit 244786**

### For SuperCat™ Proportioning Packages

This kit includes one Part No. 193467 high pressure sensor, which attaches to the proportioner's adapter manifold in the fluid valve control assembly. Order two kits to replace both sensors.

#### **Pressure Transducer Calibration**

- 1. Follow the **Pressure Relief Procedure** in your separate proportioner manual (308803, 308881, or 308925).
- Replace the High Pressure Transducer (208) following the instructions under Replacing the High Pressure Sensors in the **Service** section in the proportioner manual (308803, 308881, or 308925). Make sure that the transducer is not over-torqued when screwing into the adapter manifold (213). The transducer should only be torqued to 20–25 ft-lb (27–34 N•m). A small amount of grease can be used with o-ring insertion.
- 3. Turn on the controller.
- 4. Open the drain valves (204) on the high pressure fluid filters to ensure that there is no pressure on the sensors. Verify this on the gauges (207).
- 5. Read the values on the display.
- 6. Use the security key to go into the setup mode of the controller.
- 7. Move to level 7, in the Pressure Icon column. See Fig. 1 for the location of the Pressure Icon button.
- 8. Initially, the display will show "7———".
- Press and hold the Pressure button (Fig. 1) until a zero appears on the right-most digit of the display (i.e., "7——0"). This will take approximately five seconds.
- 10. Release the button and exit the setup mode using the security key.
- 11. Observe the pressures on the digital display. They should read less than 50 psi (0.345 MPa, 3.45 bar).




Fig. 1 \_\_\_\_\_




Fig. 2

# **Graco Standard Warranty**

Graco warrants all equipment manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale by an authorized Graco distributor to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non–Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

### THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

Graco makes no warranty, and disclaims all implied warranties of merchantability and fitness for a particular purpose in connection with accessories, equipment, materials or components sold but not manufactured by Graco. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

#### FOR GRACO CANADA CUSTOMERS

The parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés à la suite de ou en rapport, directement ou indirectement, avec les procedures concernées.

### **Graco Phone Numbers**

**TO PLACE AN ORDER**, contact your Graco distributor, or call on of these numbers to identify the distributor closest to you:

1-800-367-4023 Toll Free 612-623-6921 612-378-3505 Fax

All written and visual data contained in this document reflects the latest product information available at the time of publication.

Graco reserves the right to make changes at any time without notice.

Sales Offices: Minneapolis, Detroit
International Offices: Belgium, Korea, Hong Kong, Japan
GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440–1441