



Validity Extend Notice

6 YYY 205 E

Rev E

AIR-POWERED Variable Ratio Hydra-Cat®

Model SWO-B00073

Model SWO-B00089

Model 6710898

Model 6792378

Model SWO-B00087

Model SWO-B00103

Model SWO-B00042

Model 6791987

Model SWO-B00141

Model SWO-B00155

Model SWO-B00172

Model SWO-B00174

Model SWO-B00175

Model SWO-B00188



These products are similar to the product described in Manual 6 000 205. These sheets make this manual also valid for the products above. Please note the deviations and keep these sheets with your manual.

Model No.	Similar Product	Part of Deviation	Ref. No.	Part Description	Description of deviation
SWO-B00073	098-229	6773317	62	Ratio Monitor & Shut-Off	Not included with the unit.
SWO-B00089	098-229	222-012	124	Secondary Displacement Pump	Pump is exchanged with the lower P/N 222-019
6710898 and 6792378	098-229	6773317	62	Ratio Monitor & Shut-Off	Ratio Monitor without Shut-Off P/N 6773174 is used.
			62 (Ref)	Shut-Off Valve	Not included with the unit.
		166-443	18	Nipple	Not included with the unit.
		222-012	124	Secondary Displacement Pump	222-019 is used. <i>See manual 307-944 for parts.</i>
		165-767	114	Tube, suction	Not included with the unit.
		214-960	115	Hose, suction	Not included with the unit.
		156-823	85	Swivel	Not included with the unit.
		164-672	87	Nipple	Not included with the unit.
		512-506	88	Mixer	Not included with the unit.
		155-677	90	Swivel, 90°	Not included with the unit.
		210-659	91	Ball Valve	Not included with the unit.
		177-021	108	Nipple	Not included with the unit.
		161-077	92	Swivel Union	Not included with the unit.
6710898	098-229	215-255	118	Bulldog Air Motor	208-356 is used. <i>See manual 307-049 for parts.</i>
		222-012	123	Primary Displacement Pump	222-017 is used. <i>See manual 307-944 for parts.</i>
		215-690	125	Mounting Plate	Not included with the unit.
		164-417	126	Locknut	192-174 is used.
		098-260	119	Sampling Valve	108-233 is used.
6792378	098-229	6779009	93	Plate, adapter	Not included with the unit.
		6779011	94	Coupling	168-211 is used.
		161-544	95	Nut, swivel	168-210 is used.
		6779010	116	Tie Rod	6778951 is used.
		215-692	121	Connection Rod	6778950 is used.
		222-012	123	Primary Displacement Pump	946-196 is used.
		215-690	125	Mounting Plate	621-218 is used.
		164-417	126	Locknut	946-216 is used.
		105-751	14	Bearing	6773232 used for 1 of 2.
		177-086	27	Spacer	6779195 used for 2 of 4.
		177-101	32	Manifold	6779885 used for 1 of 2.
		155-665	79	Union	Not included with the unit.
		161-077	92	Swivel Union	157-705 is used.



Validity Extend Notice

6 YYY 205 E

Rev E

Model No.	Similar Product	Part of Deviation	Ref. No.	Part Description	Description of deviation
SWO-B00087	6792378	222-019	124	Secondary Displacement Pump	222-015 is used. See manual 307-944 for parts.
SWO-B00103	6792378	6773174	62	Ratio Monitor	Ratio Monitor & Shut-Off P/N 6773317 is used. See manual 6000198 for parts.
SWO-B00042	6792378	215-255	118	Bulldog Air Motor	King Motor P/N 220-106 is used. See manual 307-741 for parts.
		6773174	62	Ratio Monitor	Not included with the unit.
		215-626	120	Manifold	Not included with the unit.
6791987	6792378	946-196	123	Primary Displacement Pump	6791558 is used. See manual 6000180 for parts.
		621-218	125	Mounting Plate	6778949 is used.
		946-216	126	Locknut	6778550 is used.
		6778950	121	Connection Rod	6779161 is used.
		6779885	32	Manifold	6779162 is used.
SWO-B00141	6791987	215-255	118	Bulldog Air Motor	King Motor P/N 220-106 is used. See manual 307-741 for parts.
		6791558	123	Primary Displacement Pump	6791551 is used. See manual 6000179 for parts.
		206-197	13	Air Regulator	207-755 is used.
		206-205	19	Manifold	207-675 is used.
SWO-B00155	6791987	215-255	118	Bulldog Air Motor	King Motor P/N 220-106 is used. See manual 307-741 for parts.
		222-019	124	Secondary Displacement Pump	222-012 is used. See manual 307-944 for parts.
		206-197	13	Air Regulator	207-755 is used.
		206-205	19	Manifold	207-675 is used.
SWO-B00172	098-229	222-012	123	Primary Displacement Pump	6791559 is used. See 6000178 for parts.
		6779009	93	Plate, adapter	Not included with the unit.
		6779011	94	Coupling	168-211 is used.
		161-544	95	Nut, swivel	168-210 is used.
		177-086	27	Spacer	6779195 used for 2 of 4.
		6779010	116	Tie Rod	6778951 is used.
		215-692	121	Connection Rod	6778950 is used.
		164-417	126	Locknut	6778550 is used.
		215-690	125	Mounting Plate	6778949 is used.
		105-751	14	Bearing	6773232 used for 1 of 2.
SWO-B00174	SWO-B00172	6791559	123	Primary Displacement Pump	6791551 is used. See 6000178 for parts.
		222-012	124	Secondary Displacement Pump	948640 is used. See 684004 for parts.
SWO-B00175	SWO-B00174	6791551	123	Primary Displacement Pump	6791558 is used. See 6000180 for parts.
SWO-B00188	SWO-B00172	222-012	124	Secondary Displacement Pump	222-015 is used. See 307-944 for parts.
		6773317	62	Ratio Monitor/shut-off	Not included with the package.