

Precision Mix[®] Simulator

Model: 949-699

I. Remove pendant and cables.

II. Remove top foam section.

III. Remove simulator.

IV. Attach cables to simulator.

V. Booting Procedures.

A. Single Recipe.

1. Power Off.
2. Operator switch in "Mix".
3. All other switches "off".
4. Hold in "Reset" button on back of simulator while turning on power.
5. Hold button in for 5 seconds.
6. Release button. Follow instructions on pendant:
 - a) Move operator switch to standby.
 - b) Set all parameters.

B. Multiple recipes - same as above except:

3. Color 1 "on", all other switches "off".

C. Note: 1. Rotating flow rate dial clockwise decreases flow rate.
Rotating flow rate dial counter-clockwise increases flow rate.

2. In multiple recipes and recipe select from I.O., all colors off represents recipe 00, color 1 represents recipe 01, color 2 represents recipe 02, etc.

D. 1. Flow "on" represents paint pressure to the system.
2. Gun "on" represents gun trigger pulled, air flow switch on.

E. All screens are detailed in 308-344.

F. Purge cycle cannot be programmed for volume counts. Use time elements only.